

Assembling Mechanism	Models 5-29-30-31-32				
8-148 Assembler slide stop screw 8-32 x 5/16"	5-29-30-31-32	D=3413 Assemble			

Assembler Slide 235

	Assembler slide stop screw 8-32 x 5/16" . 5-29-30-31 32	D-3413 Assembles	slide clamp, assembled (40 cicero) 29-30-31-32
	Assembler slide stop (30 em) . 5-29-30-31-32	D-3856 Assembler	slide finger 5-29-30-31-32
D- 156	Assembler slide clamp adjusting	D-4379 Assembler	slide (30 em) (large assembler star) 29 30 32
	screw (42 em) 8-32 x 7/8" 29-30-31-32	D-4380 Assembler	slide (42 em) (large assembler star) 29-30 32
D- 354	Assembler slide brake operating lever hinge screw 5-29-30-31-32	D-4411 Assembler	slide stop screw 4-48 x 1/8" 5.00.30.31.32
D- 532	Assembler slide brake operating lever screw 29-30-31-32	D-4757 Assembler	slide, reverse, scale (30 cm) 5-29-20-31-32
D- 802	Assembler slide brake operating lever adjusting	D-4758 Assembler	slide, reverse, scale (42 em) 29-30-31-32
	screw nut 8-32 x 5/16" 5-29-30-31-32	D-5197 Assembler	slide, reverse, em scale screw 4-48 x 1/8" 5-29-30-31-32
D- 802	Assembler slide clamp adjusting screw nut 8-32 x 5/18" 5:29:30:31:32	D-5198 Assembler	slide (30 cm) (small assembler star) 29 31
	Assembler slide scale (30 em) . 5 · 29 · 30 · 31 · 32	D-5199 Assembler	slide (30 em) (large assembler star) 29-20 22
D-1152	Assembler slide bracket pawl spring 5-29-30-31-32	D-5200 Assembler	slide (42 em) (small assembler star) 29 31
D-1170	Assembler slide scale (28 cicero) 5-29-30-31-32	D-5201 Assembler	slide (42 em) (large assembler star) 29-30 32
D-1227	Assembler slide clamp spring 5-29-30-31-32	D-5222 Assembler	slide (28 cmicero) (small assembler star) 29 31
D-1377	Assembler slide brake trip screw . 5-29-30-31-32	D-5223 Assembler	slide (40 cicero) (small assembler star) 29 31
D-1462	Assembler slide brake operating lever spring 5.99.30.31.39	D-5233 Assembler	slide (28 cicero) (large assembler star) . 29-30 32
D-1653	Assembler slide (30 em) (small assembler star) 29 31	D-5237 Assembler	slide (40 cicero) (large assembler star) . 29-30 32
D-1656	Assembler slide clamp 5-29-30-31-32	D-5677 Assembler	slide, reverse, em scale pointer 5-29-30-31-32
D-1657	Assembler slide clamp trigger 5-29-30-31-32	D-5678 Assembler	slide (small assembler star) (30 em) 5-29 31
D-1658	Assembler slide clamp bracket 5.90.30.31.39	D-5679 Assembler	slide (large assembler star) (30 em) 29-30 32
D-1659	Assembler slide clamp, assembled (30 cm) 5-29-30-31-32	D-5680 Assembler	slide (42 em) (small assembler star) 29 21
D-1660	Assembler slide clamp adjusting	D-5681 Assembler	slide (42 em) (large assembler star) 29-30-31-32
	screw (30 em) 8-32 x 1" 5-29-30-31-32	D-5686 Assembler	slide, reverse, em scale (42 em) 29-30-31-32
D-1662	Assembler slide bracket pawl 5 29 30 31 32	D-5722 Assembler	slide brake operating lever and
D-1663	Assembler slide bracket pawl screw 5-20-20-21-20	point	er, assembled
D-1722	Assembler slide (28 cicero) (small assembler star) 29 31	D-5727 Assembler	slide brake operating lever, assembled 5-20-30-31-32
D-1723	Assembler slide (didot) clamp .5-29-30-31-32	D-5988 Assembler	slide brake operating lever screw 5.99.90.91.99
	Assembler slide clamp, assembled (28 cicero) 5-29-30-31-32	E- 192 Assembler	slide em scale screw 4-48 x 1/8" 5-29-30-31-32
D-1966	Assembler slide brake trip 5-29-30-31-32	G- 139 Assembler	slide brake spring hook 5-29-30-31-32
D-2172	Assembler slide brake operating lever adjusting	G- 142 Assembler	slide, reverse, em scale pointer
	SCTEW 8-32 x 13/16"	screv	6-48 x 5/32" 5-20-30-31-32
D-2440	Assembler slide stop (42 em)	G- 167 Assembler	slide bracket dowel 1/18" x .439" 5-29-30-31-32
D-2802	Assembler slide (42 em) (small assembler star) 29 31	G- 274 Assembler	slide bracket screw 8-32 x 3/8" 5-29-30-31-32
D-2803	Assembler slide scale (42 em)	I - 788 Assembler	slide brake operating lever spring rivet 5-29-30-31-32
D-2913	Assembler slide clamp, assembled (42 cm) 29-30-31-32	J- 136 Assembler	slide clamp pin 1/16" x 1/2" 5-29-30-31-32
D-2922	Assembler slide (40 cicero) (small assembler star) . 29 31	J- 136 Assembler	slide clamp trigger pin 1/18" x 1/2" . 5-29-30-31-32
D-2923	Assembler slide scale (40 cicero)		
D-3067	Assembler slide finger screw 8-32 x 7/18"		Parts Not Illustrated
D-3070	Assembler slide stop (40 cicero) (small assembler slide) 29 31		slide, assembled (30 cm) (small
D-3072	Assembler slide bracket 5-29-30-31-32	assen	bler star)
D-3073	Assembler slide anti-friction roll 5-29-30-31-32	D-5683 Assembler	slide, assembled (30 em) (large
D-3074	Assembler slide anti-friction roll stud	assen	bler star) 29-30 32
D-3075	Assembler slide bracket, assembled . 29:30:31:32	D-5684 Assembler	slide, assembled (42 em) (small
D-3292	Assembler slide spring, auxiliary, stud . 5-29-30-31-32	assen	bler star)
D-3374	Assembler slide stop (40 cicero) (large assembler star) 29:30 32	D-5685 Assembler	slide, assembled (42 em) (large
D-3375	Assembler slide (40 cicero) (large assembler star) . 29.30 32	assen	bler star) 29-30-31-32
D-3400	Assembler slide (28 cicero) (large assembler star) 29-30 32		


Assembling Mechanism	Madels 5-29-30	-31-32 Assemble	Slide	237
A- 38 Assembler slide roll bracket screw 14-24 x 3/4"	29-30-31-32 D-45	40 Assembler slide brake, assembled (with fiber shoe)	5.20.2	0.91.99
D- 215 Assembler slide brake screw		12 Assembler slide return spring clip cap	90.9	10-31-32
D- 218 Assembler slide roll bracket dowel 1/8" x 1/2"	5 · 29 · 30 · 31 · 32 D-53	93 Assembler slide roll bracket and finger, assembled	. 40.0	10.91.92
D- 802 Assembler slide release extension screw		(with D-5394 finger) (42 em)	20.2	0.31.32
nut 8-32 x 5/15"	5-29-30-31-32 D-53	94 Spaceband buffer finger (42 em)	20.2	0-31-32
D- 802 Assembler slide release extension hinge stud	D-54	22 Assembler slide brake facing (fiber)	5.20.2	
nut 8-32 x 5/16"	5 · 29 · 30 · 31 · 32 D - 54	41 Spaceband buffer finger	20.3	0.51.32
D- 983 Assembler slide return spring stud spring	5-29-30-31-32 D-54	79 Assembler slide return spring extension fastener		0.31.32
D-1378 Assembler slide brake spring .		B1 Assembler slide return spring extension and clip,		0.01.02
D-1386 Spaceband buffer finger screw	5 - 29 - 30 - 31 - 32	assembled (with woven band)	5,70.2	0-31-32
D-1459 Assembler slide brake facing (steel)	29:30:31:32 D-55	98 Assembler slide return spring extension, assembled	5.20.3	0-31-32
0-1473 Assembler slide roll bracket (42 em)		39 Spaceband buffer finger (30 em)	E-00-3	0.31.32
0-2954 Assembler slide roll		58 Spaceband buffer finger screw	5.20.2	0.01.02
3-3248 Spaceband buffer finger (42 em)	29:30:31:32 E-	12 Assembler slide roll cotter pin	E-20-3	0-31-32
0-3249 Assembler slide roll bracket and finger,		92 Assembler slide return spring cover screw 4-48 x 1/8	0.20.0	0.01.05
assembled (42 em)	29 · 30 · 31 · 32   E = 3	56 Assembler slide return spring extension	0.29.0	0.31.32
D-3250 Spaceband buffer finger	29 - 20 - 21 - 32	screw 4-48 x 3/32"	00.0	0 01 00
0-4351 Assembler slide roll bracket	5-29-30-31-32 E- 3	56 Assembler slide return spring screw 4-48 x 3/32"	5 00 0	0.91.95
0-4354 Assembler slide roll bracket and finger, assemble		23 Assembler slide return spring strew was x 3/32	2.39.3	0.31.32
0-4390 Assembler slide brake		16 Assembler slide release extension hinge stud	. 0.29.3	0.31.32
9-4427 Assembler slide return spring stud bearing	5-29-30-31-32	lock washer .	5-29-3	
		17 Assembler slide roll washer	5 29 3	0.31.32
0-4429 Assembler slide return spring stud	5-29-30-31-32 F-24	15 Assembler slide return spring stud knob lock washe	0.58.3	0.31.32
0-4430 Assembler slide return spring drum		55 Assembler slide return spring extension	r 5.29.30	0.31.32
0-4431 Assembler slide return spring	5-29-30-31-32	screw 4-48 x 3/18"		
0-4432 Assembler slide return spring stud lock plate	5 · 29 · 30 · 31 · 32   G = 1	25 Assembler slide brake facing screw 8-48 x 1/2"	5 29 31	0.31.32
9-4434 Assembler slide return spring extension clip was		33 Assembler slide return spring stud lock plate	0.29.30	0.91.32
0-4435 Assembler slide return spring clip	5-29-30-31-32	screw 5-40 x 3/16"		
D-4436 Assembler slide return spring cover .		Assembler slide release extension screw 8-32 x 11/16	5 - 29 - 30	0.31.32
D 4427 Assembles slide extension to the t		**************************************	. 5.29.30	0.21.35

D-4495 Assembler slide return spring clip serew 4-48 x.140\* 29-30-31-32 nut 10-32 x.5/18\* 5-29-30-31-32 D-4499 Assembler slide release extension finger, assembled 5-29-30-31-32 J-2751 Assembler slide return spring stud bearing rivet . 5-29-30-31-32 Please Give Model and Serial Number When Ordering

. 5-29-30-31-32 J-1228 Assembler slide return spring stud nut lock

D-4437 Assembler slide return spring stud knob


D-4502 Assembler slide release extension linger, assembled 5-29-30-31-32



Models 5-29-30-31-32	Face	Plate	Cover	and	Assembler	Slide	239


	Models J-LJ-3	30-31-32 Face Flate Cover and Assembler Slide 23
A- 112 Face plate frame cover screw 8-32 x 3/8"	29-30	D-5193 Face plate frame cover and assemb, slide return spring
BB-148 Face plate frame cover screw 8-32 x 5/16"	29.30.31.32	stud bearing, assembled (four main and two aux.) 30
B8-148 Face plate frame cover bracket screw 8-32 x 5/18	29:30	D-5194 Face plate frame cover and assembler slide return
D- 159 Face plate frame cover extension screw 8-32 x 3/	18" 30	spring, assembled (four main and two auxiliary) 30
D- 159 Face plate frame cover (r.h. section) screw 8-32	x 3/18" 30	D-6440 Face plate frame cover window cover latch 29-30
D- 549 Face plate frame cover window cover handle	29:30	D-6441 Face plate frame cover window cover stud 29-30
D-4383 Face plate frame cover screw 8-32 x 3/16"	29 - 30	D-6443 Face plate frame cover and assembler slide return
D-4425 Face plate frame cover and assembler slide return	rn	spring stud bearing, assembled 29
spring, assembled	5 31-32	D-6444 Face plate frame cover and assembler slide return
D-4426 Face plate frame cover and assembler slide return	rn	spring, assembled 29
spring stud bearing, assembled	5 31.32	D-6449 Face plate frame cover and assembler slide return
D-4505 Face plate frame cover stud	5-29-30-31-32	spring stud bearing, assembled 30
D-4715 Face plate frame cover and assembler slide retur	rn	D-6450 Face plate frame cover and assembler slide return
spring stud bearing, assembled (42 cm)	31-32	
D-4716 Face plate frame cover and assembler slide retur	m	spring, assembled 30 D-6451 Face plate frame cover window cover 29:30
spring, assembled (42 em)	31-39	D-6452 Face plate frame cover window cover, assembled 29:30
D-4725 Face plate frame cover bracket	30	
D-474B Face plate frame cover and assembler slide retur	n .	
spring stud bearing, assembled		
D-4914 Face plate frame cover and assembler slide retur	70	D-64/4 Face plate frame cover extension, assembled 30 D-6642 Face plate frame cover and assembler slide return
spring, assembled	30	stud boaring assembled
D-4940 Face plate frame cover bracket	29	stud bearing, assembled
D-4996 Assembler entrance, upper, finger key shift cove	r	5-0037 Face plate frame cover and assembler singe return
lower, fastening piece, short	20	spring, assembled
D-4997 Face plate frame cover and assembler slide retur	n	E- 119 Face plate frame cover extension fastening piece
spring stud bearing, assembled .		screw 8-48 x 1/4" 30
D-5002 Face plate frame cover and assembler slide retur		F-1125 Face plate frame cover window cover latch washer . 5-29-30
spring, assembled	20	F-3854 Face plate screw, r.h., washer 5-29-30-31-32
2-0,	40	


Assembling Mechanism



Check Parts by Referring to Detail Pages.

C-LINOTYPE-






ing Mechanism	Models 5-29-30-31
mg mechanism	Madeis

## 19-30-31-32 Assembling Elevator 243

	,,,ade.3 3 L	Assembling Elevarar 24:
D- 572 Assembling elevator dowel 3/18" x 13/16"	29:30	Parts Not Illustrated
D- 846 Assembling elevator matrix support rail cam		
SCTeW 8-48 x 5/16"	39-30-31-32	D-5113 Assembling elevator, assembled (30 em) (large
D-2929 Assembling elevator plate, back (43 em)	29 - 30	assembler star) 29-30
D-3670 Assembling elevator plate, back (30 em)	29-30	D-5114 Assembling elevator, assembled (30 em) (small
0-4211 Assembling elevator matrix support rail cam	29 - 30 - 31 - 33	assembler star) 29
D-4363 Assembling elevator duplex rail, long, finger (30 e	m)	D-5141 Assembling elevator, assembled (30 em) (large
(used with assembling elevator hand stick of	nly) 5-29-30-31-33	assembler star) from serial No. 52397 29:30:31:3
-4364 Assembling elevator hand stick (30 em)	5 - 29 - 30 - 31 - 32	D-5148 Assembling elevator, assembled (30 em) (small
2-4365 Assembling elevator hand stick jaw, l.h. (30 em)	5-29-30-31-32	assembler star) from serial No. 52397 29 at
2-4366 Assembling elevator hand stick jaw, r.h. (30 em)	5-29-30-31-32	D-5185 Assembling elevator, assembled (42 em) (large
2-4367 Assembling elevator hand stick, assembled (30 cm	5 - 29 - 30 - 31 - 32	assembler star) from serial No. 51244 29-30
0-4372 Assembling elevator hand stick scale (30 em)	5-29-30-31-32	D-5189 Assembling elevator, assembled (42 em) (small
9-4373 Assembling elevator hand stick scale		assembler star) from serial No. 51244
screw 4-48 x 5/32"	5-29-30-31-32	D-5360 Assembling elevator, assembled (42 em) (small
9-4413 Assembling elevator shield	5-29-30-31-32	assembler star) from serial No. 52397 29 31
5-5109 Assembling elevator plate, front (30 em)	29-30	D-5370 Assembling elevator, assembled (42 em) (large
-5124 Assembling elevator plate, front, location		assembler star) from serial No. 52397 29 - 30 - 31 - 3
screw 3/8"-16 x 15/32"	5-29-30-31-32	D-5856 Assembling elevator, assembled (30 em) (small
-5139 Assembling elevator plate, front (30 em)	5 - 29 - 30 - 31 - 32	assembler star) from serial No. 53894 29 31
-5140 Assembling elevator plate, back (30 em) (large		D-5887 Assembling elevator, assembled (30 em) (large
assembler star)	5-29-30-31-32	assembler star) from serial No. 53894 . 29-30 3
-5187 Assembling elevator plate, front (42 em) .	29:30	D-6065 Assembling elevator, assembled (30 em) (small
-5364 Assembling elevator plate, front (+3 em)	29-30-31-32	
-5365 Assembling elevator plate, back (42 cm) (large	***************************************	assembler star) from serial No. 55835 5-29 31  D-6066 Assembling elevator, assembled (30 em) (large
assembler star)	29 - 30 - 31 - 32	
-5855 Assembling elevator plate, back (small	*9.90.91.90	assembler star) from serial No. 55835 29-30 3: D-6078 Assembling elevator, assembled (42 cm) (small
assembler star)	29-30-31-32	
-6051 Assembling elevator plate, back (small	49.30.31.32	assembler star) from serial No. 54889 29 31  D-6088 Assembling elevator, assembled (42 em) (large
	5 - 29 - 30 - 31 - 32	
-6073 Assembling elevator plate, back (42 em) (small	9.88.90.91.98	assembler star) from serial No. 55835 29-30 3
	29 - 30 - 31 - 32	D-6660 Assembling elevator, assembled (30 em) (small
-6583 Assembling elevator plate, back (large	39.30.31.32	assembler star) from serial No. 64387 5 29 31
assembler star)	5-29-30-31-32	D-6661 Assembling elevator, assembled (30 cm) (large
-6585 Assembling elevator plate, back (42 em) (large	5-29-30-31-32	assembler star) from serial No. 84387 29-30 3
assembler star)		D-6679 Assembling elevator, assembled (42 em) (small
- 38 Assembling elevator screw 3/8"-18 x 7/8"	29 - 30 - 31 - 32	assembler star) from serial No. 84387 . 29 31
- 119 Assembling elevator shield screw 8-48 x 1/4"		D-6680 Assembling elevator, assembled (42 cm) (large
- 353 Assembling elevator hand stick law, r.h.,	5-29-30-31-32	assembler star) from serial No. 84387 39-30 33
screw 8-32 x 3/8"	5 - 29 - 30 - 31 - 32	



Assen	nbling Mechanism	Models	5-29-30-3	11-32 Assembling	Elev	ator	245
	Assembling elevator gate hinge rod screw 8-32 x 3/8"	5-29-30-3	1-32 D-5361	Assembling elevator gate and stop pin, assemble	1		
	Assembling elevator gate spring screw 8-32 x 1/4°	5-29-30-3	1-32	(42 em) (small assembler star)		29	21
D~ 82	Assembling elevator gate hinge rod (30 em)	5-29-30-3	1-32 D-5369	Assembling elevator gate spring (42 em)			0.31.32
D- 120	Assembling elevator em scale screw 4-48 x .145"	5-29-30-3	1-32 D-5372	Assembling elevator gate and stop pin, assembles	1		0 01 02
D- 570	Assembling elevator gate banking pin	29:30		(42 cm) (large assembler star)		20.5	0.31.32
D- 663	Assembling elevator gate pawl (42 em) (small		D-5524	Assembling elevator gate, assembled (30 em)		29	31
	assembler star)	29	D-5525	Assembling elevator gate, assembled (30 cm)			0.31.32
D- 664	Assembling elevator gate pawl hinge pin .069" x 3/8"	5-29-30-3	1-32 D-5526	Assembling elevator gate, assembled (42 em)		29	31
D- 922	Assembling elevator gate spring (30 em)	29:30	D-5527	Assembling elevator gate, assembled (42 cm)			0.31.32
D- 923	Assembling elevator gate spring roll	5-29-30-3	1-32 D-6052	Assembling elevator gate and stop pin, assembled			
D- 924	Assembling elevator gate spring roll stud	5-29-30-3	1 - 32	(large assembler star)		29 - 3	0 32
D-1453	Assembling elevator scale (30 em)	5-29-30-3	1-32 D-6056	Assembling elevator gate and stop pin, assembled			-
D-1454	Assembling elevator scale (28 cicero)	29 - 30 - 3	1.32	(90 character) (small assembler star)		5.29	21
D-2422	Assembling elevator gate pawl (42 em) (large		D-6064	Assembling elevator gate operating cam adjustin	g		0.1
	assembler star)	29-30		screw 4-48 x 9/84"		5.29.3	0.31.32
D-2731	Assembling elevator gate matrix fender	29 - 30 - 3	1-32 <b>D</b> -6068	Assembling elevator gate operating cam		5.29.3	0.31.32
D-2791	Assembling elevator gate hinge rod (42 em)	29:30:3	1-32 D-6076	Assembling elevator gate and stop pin, assembled			
	Assembling elevator scale (42 em)	29:30:3		(90 character) (small assembler star)		29	31
	Assembling elevator scale (40 cicero)	29.30.3	1-32 D-6081	Assembling elevator gate and stop pin, assembled			
D-3231	Assembling elevator gate spring (42 em)	29-30		(large assembler star)		29.3	32
D-3287	Assembling elevator gate handle	5 - 29 - 30 - 33	1-32 D-6083	Assembling elevator gate operating cam		29-3	0.31.32
D-3831	Assembling elevator gate pawl spring	29 - 30		Assembling elevator gate em scale strip		5-29-3	0.31.32
D-3852	Assembling elevator gate matrix fender	5-29-30-3	1-32 D-6530	Assembling elevator gate em scale strip		29.3	0.31.32
D-4218	Assembling elevator gate pawl (20 em) (small assembler star)		D-6664	Assembling elevator gate and stop pin, assembled			
		29		(large assembler star)		. 29.3	32
D-4222	Assemblnig elevator gate pawl (30 em) (large		D-6668	Assembling elevator gate and stop pin, assembled			
	assembler star)	29.30				5-29	31
D-5112	Assembling elevator gate and stop pin,		E- 192	Assembling elevator scale screw 4-48 x 1/8"		5-29-3	31.32
	assembled (30 em)	29-30	E- 192	Assembling elevator gate matrix fender			
D-5129	Assembling elevator gate pawl (large assembler star)			screw 4-48 x 1/8"		5-29-3	1.31.32
D-5131	Assembling elevator gate pawl spring	5-29-30-31		Assembling elevator gate pawl spring			
	Assembling elevator gate spring (30 cm)	5 - 29 - 30 - 31		screw 4-48 x 1/8"		5 - 29 - 31	-31-32
D-5138	Assembling elevator gate and stop pin, assembled		G-1053	Assembling elevator gate stop adjusting screw			

screw 4-48 x 3/16" ..... 5-29-30-31-32

G-1053 Assembling elevator gate operating cam adjusting

J- 182 Assembling elevator gate stop adjusting

(30 em) (large assembler star)


D-5143 Assembling elevator gate pawl (small assembler star) 5:29 31

D-5147 Assembling elevator gate and stop pin, assembled

D-5186 Assembling elevator gate and stop pin,

(30 em) (small assembler star) .

assembled (42 cm)



A	sem	nbling	Mechanism	Madels 5-29-30	-31-32 Assembling Eleve	ror	241
8-			oling elevator latch spring screw 4-49 x 1/	4" 5·29·30·31·32 D-42	17 Assembling elevator back rail pawl (30 em)		
В-	96		oling elevator matrix retaining rail		(small assembler star)	29	
		sc	rew (30 em) 4-48 x 1/4"	. 5-29-30-31-32 D-42	21 Assembling elevator back rail pawl (30 em)		
8-	96		oling elevator gate separating cam		(large assembler star)	29 - 30	
		sc	crew (42 em) 4-48 x 1/4"	29·30·31·32 D-42	25 Assembling elevator back rail (20 em)	29.30	,
D-			oling elevator latch		25 Assembling elevator back rail (30 em)		
D-			oling elevator latch spring	5 - 29 - 30 - 31 - 32	(large assembler star)	29:30	0.31.32
D-				. 5-29-30-31-32 D-51	30 Assembling elevator back rail pawl		
D-	85		oling elevator matrix retaining rail		(large assembler star)	29.30	91.32
			crew (42 cm) 4-48 x 3/18"	5 · 29 · 30 · 31 · 32   D-51	42 Assembling elevator back rail pawl		
D-	102		oling elevator back rail pawl stop		(small assembler star)	5 - 29	31
		pi	in 1/16 "x 3/16"	5-29-30-31-32 D-51	44 Assembling elevator back rail (30 em)		
			oling elevator em scale sliding pointer			5-29	31
D-	672		oling elevator back rail pawl (42 em)		57 Assembling elevator back rail (42 cm)		
			small assembler star)		(small assembler star)	29	31
			oling elevator back rail hinge pin	5-29-30-31-32 D-53	58 Assembling elevator back rail (42 em)		
D-	846		oling elevator matrix support rail spring		(large assembler star)	29:30	-31-32
		bl	lock screw (30 cm) 8-48 x 5/18"	29·30·31·32 D-554	48 Assembling elevator back rail, assembled (30 em)		31
D-	1898	Assemb	oling elevator latch screw (42 em)	5 · 29 · 30 · 31 · 32 D - 554	49 Assembling elevator back rail, assembled (30 em)	29:30	9:31:32
D-:	2423	Assemb	oling elevator back rail pawl (42 em)		30 Assembling elevator back rail, assembled (42 em)	20	31
		(1	large assembler star) .	29 · 30 D-55!	1 Assembling elevator back rail, assembled (42 em)	29 - 30	.31.32
D-:	2790	Assemb	oling elevator back rail (42 em)	29·30 D-55	7 Assembling elevator em scale sliding pointer spacer	29:30	-31-32
			oling elevator back rail screw 8-32 x 11/32			5 - 29 - 30	.31.32
D-:	3663	Assemb	oling elevator matrix support rail (30 em)	29 - 30 - 31 - 32 D-604	33 Assembling elevator matrix retaining rail		
D-:	3664	Assemb	oling elevator matrix support rail spring	(30 em) 29 - 30 - 31 - 32		5-29-30	-31-32
			oling elevator matrix support rail spring		77 Assembling elevator matrix retaining rail (42 em)	29:30	.31.32
			lock (30 em)		34 Assembling elevator matrix retaining rail		
D-:	3669		oling elevator latch screw (30 cm)	. 29 · 90 · 31 · 32 D-658		5 29 30	
D-	1212	Assemb	oling elevator matrix support rail spring		94 Assembling elevator matrix retaining rail	0 20 00	01 011
			etaining pin (30 em)		SCTEW 4-48 x 3/8"	5 - 29 - 30	-31-32


D-3345

D-1229 (LH ) (42 (M)


D-646 D-102

D-3667 E-466 D-3346

BB-148	Assembling elevator gib, r.h., screw 8-32 x 5/18" 5-29-30-31-1		Assembling elevator gib, r.h. 5-29-30-31-32
	Assembling elevator duplex rail, long, ball 5-29-30-31-3		Assembling elevator duplex rail cap (42 em) 29-30-31-32
C- 471	Assembling elevator duplex rail, short, ball 5-29-30-31-3		Assembling elevator stop bar banking plate (42 em) 29-30-31-32
D- 34	Assembling elevator gib, l.h., screw 8-32 x 1/2" 5-29-30-31-3	2 D-2919	Auxiliary line safety lever cam 29-30
D- 85	Assembling elevator matrix detaining plate, front,	D-2933	Assembling elevator stop bar (42 em) 29-30-31-32
	SCTCW 4-48 x 3/16" 5-29-30-31-5	2 D-2934	Assembling elevator stop bar screw 8-32 x 5/8" 29-30-31-32
D- 86	Assembling elevator gib, l.h., screw (42 cm) 8-32 x 9/32" 29:30:31:3		Assembling elevator stop bar, assembled (42 cm) 29-30-31-32
D- B7	Delivery slide releasing wire 29-30-31-3	2 D-3047	Assembling elevator duplex rail, short 5-29-30-31-32
	Delivery slide releasing wire bushing 29-30-31-1	2 D-3142	Assembling elevator duplex rail, long, operating lever 5-29-30-31-32
D- 93	Assembling elevator gib, l.h. (30 em) 5-29-30-31-3	2 D-3230	Assembling elevator duplex rail, long (42 em)
	Assembling elevator stop 5-29-30-31-3		Assembling elevator duplex rail, long, lever
	Assembling elevator matrix detaining plate, back		rod (42 em) 29 · 30 · 31 · 32
	(small assembler star) 5-29 31	D-3234	Assembling elevator duplex rail, long, lever
D- 101	Assembling elevator matrix detaining plate, front,		rod, assembled (42 em) 29-30-31-32
	screw 4-48 x 3/16" 29-30	D-3345	Assembling elevator matrix buffer, back 5-29-30-31-32
D- 105	Assembling elevator matrix buffer, front,		Assembling elevator matrix buffer, back (42 em) 29:30:31:32
	dowel 1/18" x 3/18" 5-29-30-31-3	2 D-3621	Assembling elevator matrix detaining plate, back
D. 166	Assembling elevator matrix buffer, front,		(large assembler star) 29:30:31:32
D- 100	screw 4-48 x 1/4"	2 D-3666	Assembling elevator matrix buffer, lower section,
D. 166	Assembling elevator matrix buffer, upper section,		back (80 em)
D- 100	back, screw 4-48 x 1/4" 5-29-30-31-1	2 D.3667	Assembling elevator matrix buffer, lower section,
D- 166	Assembling elevator matrix buffer, back,		back, screw (30 cm) 2-64 x .1863" 29-30-31-32
D- 100	screw 4-48 x 1/4" 5-29-30-31-1	2 D-3668	Assembling elevator matrix buffer, upper section,
D. 526	Assembling elevator matrix detaining plate, back,		back (30 em) 29-30-31-32
D. 010	screw 4-48 x 3/18" 5-20-30-31-1	D-4205	Assembling elevator stop bar (30 em) 5-29-30-31-32
D. 567	Assembling elevator duplex rail cap		Assembling elevator stop bar banking plate (30 em) 5-29-30-31-32
D- 501	screw 4-48 x 11/32" 5-29-30-31-1		Assembling elevator stop bar, assembled (30 em) 5-20-30-31-32
D. 567	Auxiliary line safety lever cam screw 4-48 x 11/32* 5-29-30-31-		Assembling elevator duplex rail, long, finger (30 em)
	Assembling elevator duplex rail guide plate 5-29-30-31-		(used with assembling elevator hand stick only) 29-30-31-32
	Assembling elevator duplex rail, short, lever 5-29-30-31-3		Delivery slide releasing wire adjusting
	Assembling elevator duplex rail, short, lever fulcrum	2 0 - 400 1	screw 8-32 x 3/8"
D- 3/2	pin 3/16" x 13/18" 5-29-30-31-3	D-5126	Auxiliary line safety lever cam 5-29-30-21-32
D- 575	Assembling elevator duplex rail, long, lever 5-29-30-31-1		Assembling elevator matrix detaining plate, front
	Assembling elevator gib, r.h. and l.h.,		(small assembler star)
D- 001	dowel 1/8" x 13/32" 5-29-30-31-3	D.5550	Assembling elevator matrix detaining plate, front
D 646	Assembling elevator matrix buffer, front 5-29-30-31-3		(large assembler star) 29-30-31-32
	Assembling elevator stop bar banking plate		Assembling elevator gib, r.h. 5-29-30-31-32
D. /15	dowel 3/32" x 7/32" 5-29-30-31-3		Assembling elevator duplex rail, long, lever
0 1046	Assembling elevator duplex rail, long, finger 5-29-30-31-		pin 1/16" x 7/16"
	Assembling elevator gib, l.h. (42 cm) 29-30-31-3	E- 192	Assembling elevator stop bar banking plate
	Assembling elevator gib, i.n. (42 cm) 29-30-31-3 Assembling elevator duplex rail cap (30 cm) 5-29-30-31-3		screw 4-48 x 1/8"
D 2316	Assembling elevator duplex rail cap (so em)		Assembling elevator matrix buffer, lower section,
D-2210	rod (30 em) 5-29-30-31-5		back pin (30 em) 1/16" x 1/4"
D 2211	Assembling elevator duplex rail, long, lever		Assembling elevator stop bar screw 8-32 x 7/18" 29-30-31-32
D-2211	rod, assembled (30 cm) 5 · 29 · 30 · 31 · 5		Assembling elevator duplex rail, long, finger
D 2214	Assembling elevator duplex rail, long (30 em) 5-29-30-31-3		screw nut 4-48 x 3/18" 5-29-30-31-32
	Assembling elevator duplex rail, long (30 em) 5-29-30-31-3		Assembling elevator stop bar dowel .125" x 5/8" 5-29-30-31-32
	Assembling elevator duplex rail, long, spring 5-29-30-31-3 Assembling elevator duplex rail, short, spring 5-29-30-31-3		Masternaming execution stop but do Net 1120 X 0/0 0 24 00 01 02
D-2317	Assembling elevator duplex ran, short, spring 5-29-30-31-3	2	




Models 5-29-30	-31-32	Assembling	Elevator	Lever	251
					0-31-32
D-53	92 Assembling elevato	r lever link	a enrina		0.31.32
5-29-30-31-32	screw 6-48 x 1	/4"			
5·29·30·31·32 H- 3	74 Assembling elevato	r counterbalance spi	ring	29 - 30	31-32
	5·29·30·31·32 B8-4 6·29·30·31·32 B8-7 D-53 29·30·31·32 G-1 5·29·30·31·32 H-3 5·29·30·31·32 H-3 6·29·30·31·32 H-39	5-29-30-31-32 B-7-13 Assembling elevato D-5392 Assembling elevato D-5392 Assembling elevato Screw 6-68 x I. Sc	5-29-30-31 32 88-480 Assembling elevator lever, assembled 5-29-20-31 32 88-713 Assembling elevator lever what sleeve 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-29-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-20 15-39-30-31-30 15-39-30 15-	8-29-30-31 32 88-480 Assembling elevator lever, assembled 8-29-30-31 28 88-713 Assembling elevator lever darkt sleve 9-39-30-31-28 (8-29-30-31-28) 48-713 Assembling elevator lever that sleve 9-39-30-31-29 Assembling elevator lever link retaining spring 8-29-30-31-32 Assembling elevator lever link retro, lower 9-39-30-31-32 48-39-30-30-30-30-30-30-30-30-30-30-30-30-30-	8-29-90-31-32 88-460 Assembling elevator lever, assembled 8-29-30-31-32 88-373 Assembling elevator lever shaft sleeve 8-29-30-31-32 88-373 Assembling elevator lever shaft sleeve 9-29-30-30-32 88-373 Assembling elevator lever link retaining spring 8-29-30-31-32 8-29-30-30-31-32 8-29-30-30-30-31-32 8-29-30-30-31-32 8-29-30-30-31-32 8-29-30-30-31-32 8-29-30-30-31-32 8-29-30-30-31-32 8-29-30-30-31-32 8-29-30-30-31-32 8-29-30-30-30-30-30-30-30-30-30-30-30-30-30-



Assembling	Mechanism	Models 5-29-30-31-32
Assembling	Mechanism	Models 3-29-30-31-32

Delivery	Slide	253

rissembing internation	******		., ,, ,	Delivery	Jilue	200
C- 93 Delivery slide stop adjusting screw check			D-5248	Delivery slide, assembled (40 cicero)		
nut 3/8"-18 x 1/2"	5.29	-30-31-32		(small assembler star)	. 29	31
	5-29	-30-31-32	D-5488	Delivery slide long finger block locking rack	5 - 29 -	30-31-33
D- 802 Assembling elevator releasing bar screw			D-5496	Delivery slide long finger block		30-31-32
nut 8-32 x 5/16"	5 - 29	-30-31-32	D-5498	Delivery slide and assembling elevator releasing bar,		
D- 965 Delivery slide bar dowel 5/32" x 1/2"	5-29	-30-31-32		assembled (30 cm) (large assembler star)	29 -	30 30
D-1434 Delivery slide bar (80 cm)	29	-30-31-32	D-5499	Delivery slide and assembling elevator releasing bar,		
D-1548 Delivery slide stop	5.29	-30-31-32	1	assembled (small assembler star)	29	31
D-1574 Delivery slide bar screw 10-32 x 1/2"	5-29	-30-31-32	D-5501	Delivery slide and assembling elevator releasing bar,		
	29	-30-31-32		assembled (42 em) (large assembler star)	29+	30 32
D-1637 Delivery slide short finger block	5 - 29	-30-31-32	D-5502	Delivery slide and assembling elevator releasing bar,		
D-1639 Delivery slide short finger and block, assembled				assembled (42 em) (small assembler star)	29	31
(30 em) (large assembler star)	29	-30-31-32	E- 90	Delivery slide stop screw 3/8"-16 x 1 1/4"	5 : 29 :	30-31-32
D-1651 Delivery slide long finger block, assembled (30 em		-30-31-32	E- 194	Delivery slide stop adjusting screw 3/8"-16 x 1 3/15"	5-29-1	30 - 31 - 32
D-1886 Assembling elevator releasing bar, assembled (30	em) 5-29	-30-31-32	E-3816	Assembling elevator releasing bar screw lock washer	5 : 29 -:	30-31-32
D-2778 Delivery slide bar (42 em)	29	30-31-32	F-2791	Delivery slide bar extension		
D-2782 Delivery slide bar extension (42 em)	29	30:31:32	1	screw (42 em) 1/4"-24 x 3/8"	29:1	30-31-32
D-2823 Assembling elevator releasing bar, assembled (42		-30-31-32	F-6155	Delivery slide long finger block locking rack		
D-3269 Delivery slide, assembled (80 cm) (large assemble:	r star) 29	-30-31-32		screw 4-48 x 3/16"	5-29-1	0.31.32
D-3327 Delivery slide long finger and block,			G- 163	Delivery slide long finger block locking rack		
assembled (30 em)	29	30-31-32		dowel 3/32" x .190"	5-29-1	90-31-32
D-3361 Delivery slide, assembled (42 cm)			G-1783	Delivery slide long finger block locking pawl		
(large assembler star)	29	30-31-32		operating cam screw 6-32 x 1/2"	29-1	0.31.32
D-3818 Delivery slide short finger block	. 29	-30-31-32	G-3875	Delivery slide long finger block locking pawl		
D-4170 Delivery slide, assembled (30 em)				stud pin .041" x 1/4"	29 - 1	10-31-32
(small assembler star)	29	31	H- 167	Delivery slide bar extension screw		
D-4202 Delivery slide short finger and block, assembled			1	pin (42 em) 1/16" x 5/8"	29 - 5	0 31-32
(30 em) (small assembler star)	29	31	J- 511	Delivery slide stop dowel 3/16" x 1/2"	5 29 5	10-31-32
D-4203 Delivery slide, assembled (42 em)				Delivery slide long finger block locking pawl		
(small assembler star)	29	31		actuating spring screw lock washer	5.29.5	0.31.32
D-5227 Delivery slide long finger block (40 cicero)						
(small assembler star)	29	31				



D-1435

D-1224

D-5489 B
"Small Assembler Star.
"\*Large Assembler Star.

B-799

1-2031

D-5492

D-1402

J-136

ssembling Mechanism	Madels 5-29-30-31-

## -32 Deliv

livery	Slide	255

7 10001	moning meenaman	madeia J-z		1.32	Delivery	Sinde	233
8- 217	Delivery pawl spring screw 8-32 x 1/4" .	29-30-31-32	D-3358	Delivery slide long finger, assembled (4)	em)		
8- 799	Delivery slide, long, finger locking pawl actuating		1	(large assembler star)		29:1	30-31-32
	spring screw 4-48 x 3/16"		D-3359	Delivery slide long finger screw (42 em)	10-32 x 9/18°		
	Delivery slide releasing wire			(large assembler star)		29:1	30-31-32
D- 88	Delivery slide releasing wire bushing	. 5 - 29 - 30 - 31 - 32	D-3624	(large assembler star) Delivery slide head Delivery slide long finger matrix retain		5 - 29 - 3	30-31-32
D- 206	Delivery slide releasing pin	5 - 29 - 30 - 31 - 32	D-3814	Delivery slide long finger matrix retain	ng spring	29.8	30 - 31 - 32
D- 214	Delivery pawl serew Delivery pawl serew Delivery pawl spring Delivery slide rod pin 3/32" x 3/8"	5 · 29 · 30 · 31 · 32	D-3819	Delivery slide short finger Delivery slide long finger friction spring		29 - 3	30-31-32
D- 215	Delivery pawl screw	5 - 29 - 30 - 31 - 32	D-3821	Delivery slide long finger friction spring		5-29-8	30-31-32
D- 216	Delivery pawl spring	5 · 29 · 30 · 31 · 32	D-5481	Delivery slide bar		5 - 29 - 2	30-31-32
D- 239	Delivery slide rod pin 3/32" x 3/8"	5 - 29 - 30 - 31 - 32	D-5489	Delivery slide long finger block locking	pawl		
D- 847	Delivery slide short finger (small assembler star)	5.29 31		actuating spring		5 29 8	30-31-32
D-1063	Delivery slide long finger friction		D-5490	Delivery slide long finger block locking	pawl		
D-1064	Delivery slide long finger friction screw	5.29.30.31.32		actuating spring spacer		5.29.3	30-31-32
D-1065	Delivery slide long finger friction spring	5 - 29 - 30 - 31 - 32	D-5491	Delivery slide long finger block locking	pawl	5 29 5	30-31-32
D-1221	Delivery slide head	29.30.31.32	D-5492	Delivery slide long finger block locking	pawl stud	5-29-3	30-31-32
D-1224	Delivery slide clamp bracket	5 - 29 - 30 - 31 - 32	D-5494	Delivery slide long finger, lower, assemb	led	29:3	0.31.32
D-1227	Delivery slide clamp spring	5 - 29 - 30 - 31 - 32	D-5495	Delivery slide long finger, assembled		29-3	0.31.32
D-1401	Delivery slide short finger screw, long 8-32 x 9/18"	5 - 29 - 30 - 31 - 32	D-5500	Delivery slide long finger block locking	nawl		
D-1402	Delivery slide short finger screw, short 8-32 x 7/16"	5 - 29 - 30 - 31 - 32		operating cam Delivery slide bar (42 cm) Delivery slide bar extension (42 cm)		5-29-3	0.31.32
D-1404	Delivery lever link screw (30 cm)	5 - 29 - 30 - 31 - 32	D-5503	Delivery slide bar (42 cm) .		29 - 3	0.31.32
D-1435	Delivery slide clamp	5 - 29 - 30 - 31 - 32	D-5504	Delivery slide bar extension (42 cm)		29-3	10 - 31 - 32
D-1436	Delivery slide clamp, assembled	5 - 29 - 30 - 31 - 32	D-5505	Delivery slide long finger block locking	rack (42 em)	29:3	10-31-32
D=1638	Delivery slide rod (30 cm)	5-29-30-31-32	D-5506	Delivery slide long finger block locking			
D-1657	Delivery slide clamp trigger	5 - 29 - 30 - 31 - 32	1	operating cam (42 cm)		29:3	10-31-32
D-1752	Delivery slide long finger stop screw 4-48 x .200"	29-30-31-32	D-6402	Delivery slide, assembled (30 cm)			
D-2299	Assembling elevator releasing bar screw	5-29-30-31-32		(small assembler star)		5-29	31
D-2779	Delivery slide rod (42 em)	29 - 30 - 31 - 32	D-6403	Delivery slide, assembled (42 em)			
D-2780	Delivery lever link screw (42 cm)	29 - 30 - 31 - 32		(large assembler star)		29:3	0.31.32
D-3259	Delivery slide long finger, upper	5 29 30 31 32	D-6404	Delivery slide, assembled (30 em)			
D-3260	Delivery slide long finger, lower	5 - 29 - 30 - 31 - 32		(large assembler star)		29-3	0.31.32
D-3261	Delivery slide matrix straightening spring	5 - 29 - 30 - 31 - 32	D-6405	Delivery slide, assembled (42 cm)			
D=3262	Delivery slide matrix straightening spring rivet	5 - 29 - 30 - 31 - 32		(small assembler star)		29	31
D-3263	Delivery slide long finger, lower, assembled	5 - 29 - 30 - 31 - 32	E- 424	Delivery slide long finger friction spring			
D=3264	Delivery slide long finger pin 1/8" x 7/18"	5.29.30.31.32		screw 1/4"-24 x 13/64"		. 5.29.3	0:31-32
D-3265	Delivery slide long finger, assembled	5 - 29 - 30 - 31 - 32	H- 167	Delivery lever link screw pin 1/18" x 5/8"		5.29.2	0.31.32
D-3266	Delivery slide long finger spring, long	5 - 29 - 30 - 31 - 32	1-2031	Delivery slide long finger screw (30 cm)	10-32 x 1/2"	5.29.3	0.31.32
D-3267	Delivery slide long finger spring, short	5 - 20 - 30 - 31 - 32	J- 136	Delivery slide clamp pin 1/16" x 1/2"		5-29-3	0.31.32
D-3348	Delivery slide short finger (large assembler star)	29 - 30 - 31 - 32	J~ 136	Delivery slide clamp trigger pin 1/16" x 1	/2"	5-29-3	0.31.32
D-3357	Delivery slide long finger, upper (42 em)						
	(large assembler star)	29-30-31-32					












\*Small Assembler Star.
\*\*Large Assembler Star.

A- 112	Delivery channel, back, rail screw 8-32 x 3/8"	5-29-30-31-32	D-5563 Delivery channel plate, back (30 cm) 6-29-30-31-3
	Delivery channel plate, front,		D-5767 Delivery channel plate, back, scale sight 5-29-30-31-3
	screw (42 em) 3/8"-16 x 7/8"	29-30-31-32	D-5768 Delivery channel plate, back, scale sight drive screw . 6-20-30-31-3
D- 34	Delivery channel, front, rail screw 8-32 x 1/2"		D-5769 Delivery channel plate, back, assembled 5-29-30-31-3
	Mold disk shield support screw		D-6068 Assembling elevator gate operating cam 5-29-30-31-3
	Delivery channel dowel (30 cm) 1/8" x 9/18"	5-29-30-31-32	
D- 331	Delivery channel dowel, long (42 em) 1/8" x 9/16" .	29-30-31-32	D-6659 Delivery channel, front, rail 5-29-30-31-3 E- 38 Delivery channel plate, front, screw 3/8"-16 x 7/8" 5-29-30-31-3
		. 5-29-30-31-32	E- 100 Delivery channel screw (30 em) 3/6"-16 x 3/4" 5-29-30-31-3
D- 601	Delivery channel dowel, short (42 em) 1/8" x 13/32"	29-30-31-32	E- 100 Delivery channel screw, long (42 em) 3/6"-16 x 3/4" 29-30-31-3
	Delivery channel, front, rail	5-20-30-31-32	G-1635 Auxiliary line safety lever screw, lower, bracket
	Delivery channel, front, rail, assembled		screw 6-48 x 7/16" 5-29-30-31-3
	(small assembler star)	5.29 31	
D-1301	Delivery channel aligning piece screw	5 - 29 - 30 - 31 - 32	Parts Not Illustrated
	Delivery channel aligning piece (small assembler star	) 5-29-30-31-32	D-2949 Delivery channel, assembled (30 cm) (small
	Delivery channel plate, front (30 em)		assembler star; to serial No. 53001 29 31
D-1549	Delivery channel plate, back (30 em)	29-30-31-32	D-2951 Delivery channel, assembled (42 cm) (small
	Delivery channel, back, rail (small assembler star)	5.29 31	assembler star) to serial No. 55834 29 31
	Delivery channel screw, short (42 em) 3/8"-18 x 19/32"	20-30-31-32	D-3211 Delivery channel, assembled (30 em) (large
	Auxiliary line safety lever (30 em)		assembler star) to serial No. 53001 29-30-31-3
D-2916	Auxiliary line safety lever screw, upper	5 - 29 - 30 - 31 - 32	D-3354 Delivery channel, assembled (42 em) (large
	Auxiliary line safety lever spacer		assembler star) to serial No. 55364 29:30:31:3
D-2925	Delivery channel, back, rail (40 cicero)		D-3356 Delivery channel, assembled (40 cicero)
	(small assembler star)	29 31	(large assembler star) 29-30-31-3
D-2944	Auxiliary line safety lever screw, lower		D-5572 Delivery channel, assembled (30 em) (small assembler
	Auxiliary line safety lever screw, lower,		star) from serial No. 53902 to serial No. 55834 29-30-31-3
	bracket (30 em)	5 - 29 - 30 - 31 - 32	D-5574 Delivery channel, assembled (30 em) (large assembler
D-2978	Auxiliary line safety lever screw, lower,		star) from serial No. 53002 to serial No. 55634 29-30-31-3
	bracket (42 em)	29 - 30 - 31 - 32	D-6406 Delivery channel, assembled (42 em) (small assembler
D-2996	Auxiliary line safety lever (42 em)	29:30:31:32	star) from serial No. 55835 to serial No. 64368
	Delivery channel aligning piece (large assembler star		D-6407 Delivery channel, assembled (42 em) (large assembler
	Delivery channel, front, rail, assembled	,	star) from serial No. 55635 to serial No. 64386 . 29-30 3
	(large assembler star)	29-30 32	D-6408 Delivery channel, assembled (small assembler star)
D-3210	Delivery channel, back, rail (large assembler star)	5-29-30-31-32	from serial No. 55835 to serial No. 5-29 31
	Delivery channel, front, rail (40 cicero)	20:30:31:32	D-6410 Delivery channel, assembled, from serial No. 55835 5-29-30-31-3
D-3351	Delivery channel, back, rail (40 cicero)		D-6686 Delivery channel, assembled (42 em) (small assembler
	(large assembler star)	29:30:31	star) from serial No. 64387 to serial No 29 31
D-3352	Delivery channel plate, front (42 em)	29 - 30 - 31 - 32	D-6687 Delivery channel, assembled (42 cm) (large assembler
	Delivery channel plate, back (42 em)		star) from scrial No. 64387
	Delivery channel plate, back (40 cicero)		



Assembling	Mechanism	Models 5-2	9-30-31-32	Delivery	Lever	259
A- 112 Deliver	y lever plate screw 8-32 x 3/8"	5-29-30-31-32	B- 913 Delivery lever cam roll arm shaft .		5 - 20 - 3	0.21.2
A- 901 Deliver	y lever shaft oil hole cover	5 - 29 - 30 - 31 - 32	B- 917 Delivery lever cam roll arm and shaf		0.10.0	, 01 . 0.
B- 33 Deliver	v lever spring	29.30	assembled (30 em)		5 - 29 - 31	0.91.9
B- 35 Deliver	y lever spring hook y cam roll	5 - 29 30 - 31 - 32	B- 919 Delivery lever (30 cm)		5 29 3	
B- 43 Deliver	y cam roll	5-29-30-31-32	B- 920 Delivery lever bushing (30 em)		5 - 29 - 30	
B- 44 Deliver	y lever pin .539" x 2 5/16"	5 - 29 - 30 - 31 - 32	BB-148 Delivery cam roll pin screw 8-32 x 5/1	44	5-29-30	
B- 111 Deliver	y lever shaft	5-29-30-31-32	C-1502 Delivery lever spring pulley bracket	ecresy	0.20.00	1.91.9
B- 217 Deliver	y lever link, l.h., section, return spring	*	lock washer (42 em)			31 - 3:
sc sc	Tew (30 em) 8-32 x 1/4"		D- 514 Delivery lever link stud (42 em)		29 - 31	0.31.3
B- 237 Deliver	y lever spring hook nut (42 em) 1/4"-24 x 1/2"	31 - 32	D-1015 Delivery lever link spring (42 em)		29 - 30	0-31-3
B- 295 Deliver	y lever cam roll arm clamping		D-1402 Delivery lever plate screw (30 em) 8-3	2 x 3/8"	5 - 29 - 30	0.21.3
sc	rew 1/2"-12 x 1 1/2"	5 - 29 - 30 - 31 - 32	D-1404 Delivery lever link screw (30 cm)		20:30	3-31-3
B- 322 Deliver	y cam roll pin, assembled	. 5 - 29 - 30 - 31 - 32	D-2780 Delivery lever link screw (42 em)		29:30	0.31.3
B- 326 Deliver	y lever cam roll arm (30 cm)	5 - 29 - 30 - 31 - 32	D-3396 Delivery lever link and stud, assemble	ed (42 em)	29:30	0.31.3
B- 327 Deliver	y lever (30 em)	5 - 20 - 30 - 31 - 32	D-3397 Delivery lever link, assembled (42 em	1	29:30	0.31.3
B- 328 Deliver	y lever plate	5 · 29 · 30 · 31 · 32	D-4067 Delivery lever link stud (30 em)		5.20.20	0.81.8
B- 364 Deliver	y lever spring arm (30 em)	5 - 29 - 30 - 31 - 32	D-4069 Delivery lever link spring stop pin (30	em)	5 - 20 - 30	3-31-3
<ul> <li>366 Deliver</li> </ul>	y lever spring arm pin .539" x 1 3/4"	5 - 29 - 30 - 31 - 32	D-4070 Delivery lever link and stud, r.h. secti	on.		
B- 369 Deliver;	y lever and shaft, assembled (30 cm)	5-29-30-31-32	assembled (30 em)		5-29-30	0.31.3
<ul><li>531 Deliver;</li></ul>	y lever cam roll arm (42 em)	29-30-31-32	D-4071 Delivery lever link, l.h. section (30 cm	1	5-99-90	0.91.9
<ul><li>532 Deliver;</li></ul>	y lever (42 em)	29-30-31-32	D-4072 Delivery lever link spring (30 em)		5.29.30	0.31.3
3- 533 Deliver;	y lever and shaft, assembled (42 cm)	29 - 30 - 31 - 32	D-4073 Delivery lever link, l.h. section, return	spring (30 em)	5-20-20	0.91.9
B- 603 Deliver:	y lever spring arm (42 em)	29 - 30 - 31 - 32	D-4074 Delivery lever link, assembled (30 em	opining (oo citi)	5.29.30	
B- 827 Deliver:	lever spring (30 em)	5 31-32	D-4103 Delivery lever link spring screw (30 c.	m) 10-94 v 1/4"	5 - 29 - 30	
B- 845 Deliver:	/ lever spring (42 em)	. 31-32	E- 165 Delivery lever spring pulley bracket	,	0 20 00	
B- 846 Deliver	lever spring pulley bracket	31:32	nut (42 em) 3/8"-18 x 5/8"			31 - 32
8- 647 Delivery	lever spring pulley bracket screw (42 em)	31:32	F- 14 Delivery lever spring hook bracket			01.03
8- 848 Delivery	lever spring hook (42 em)	31 - 32	screw (42 em) 1/4"-24 x 1/2"			31 - 33
3- 649 Deliver;	y lever spring hook bracket (42 em)	31 - 32	F- 717 Delivery lever spring pulley screw wa	sher (49 em)		31 - 35
8- 850 Deliver	lever spring chain (42 em)	31-32	F-3230 Delivery lever link spring screw (42 er	m) 10-94 × 1/4"	20.20	31 - 32
8- 851 Delivery	lever spring screw plug (42 em)	31-32	H- 167 Delivery lever link screw pin 1/18" x t	/0"	29:30	
8- 852 Delivery	lever spring chain plug stud (42 em)	31-32	1- 590 Delivery lever spring chain plug stud			31 - 3
- 853 Delivery	lever spring pulley (42 em)	31-32	J- 175 Delivery lever link, Lh. section, guide	Avec (42 em)		91.9
- 854 Delivery	lever spring pulley ball bearing (42 em)	31 - 32	pin (30 em) 1/8" x 3/8"		E - 20 - 20	
- 855 Delivery	lever spring pulley ball bearing spacing	01.08	J- 463 Delivery lever spring pulley screw		. 0.29.30	.01.3
W	sher (42 em)	31:32	nut (42 em) 1/4"-24 x 3/8"			
- 856 Delivery	lever spring pulley screw (42 em)	31.32				31 - 32
- 908 Delivery	lever (30 em)	5.90.90.91.99	Parts Not Illustrate	d		
- 909 Delivery	lever cam roll arm (20 am)	5.00.00.01.00	8- 857 Delivery lever spring pulley, assemble			
Delivery	reserved and the control of the cont	0.70.00.31.37	b- 657 Delivery lever spring pulley, assemble	a (az em)		31 - 33









B-217





D-1891 (WITH H-699) D-4574 (WITH H-4578)









D-697



D-6

Assembling Mechanism	Models 5-29-30-31-32	Delivery Air Cushion Cylinder 261
B. 9b Delivery air cushion pation packing ring crow-4-sis 1.14* Belivery air cushion rent screw s-2s 1.14* Delivery air cushion pation De 690 Delivery air cushion pation De 692 Delivery air cushion pation packing mg De 694 Delivery air cushion pation packing ring De 694 Delivery air cushion pation packing ring De 695 Delivery air cushion pation high ring De 695 Delivery air cushion pation high ring De 695 Delivery air cushion pation high high general rent pation link high ring pin collar	5-29-30-31-32 D-1888 Delivery air 5-29-30-31-32 D-1889 Delivery air 5-29-30-31-32 D-1890 Delivery air 6-29-30-31-32 D-1891 Delivery air 5-29-30-31-32 D-3225 Delivery air 0-4573 Delivery air 0-4574 Delivery air 0-1889 Delivery	





































Distributing Mechanism	Models 5-29	-30-31-32	First	Elevator	Slide	Guid	e 263
8- 237 Elevator transfer slide releasing lever adjusting screw nut 1/4"-24 x 1/2"	29:30:31:32	D-1806 First elevator : D-1806 Intermediate b	slide guide screv	/ 3/8"-18 x 2"		. 5.1	29 - 30 - 31 - 32
88-148 Elevator transfer slide releasing lever hinge		D-2159 First elevator	dide guide	x 2.		5.5	89-30-31-32
pin screw 8-32 x 5/18"	5-29-30-31-32	D-2262 First elevator	slide guide, asser	nbled (30 en	1)	5.5	99-30-31-39
D- 99 First elevator slide guide adjusting screw 8-32 x 3/8	5-29-30-31-32	D-2327 Intermediate b	ar facing		,	5.0	00.20.21.22
D- 107 First elevator slide guide adjusting strip screw was	ner 29-30-31-32	D-2332 Intermediate b	ar (30 em)			5-5	9-30-31-32
D- 107 Intermediate bar screw washer	5 - 29 - 30 - 31 - 32	D-2333 Intermediate b	ar, assembled (	0 em)		5.0	9.30.21.22
D- 107 First elevator slide guide screw washer	5-29-30-31-32	D-2806 Intermediate b	ar (42 em)				9-30-31-32
D- 107 First elevator slide guide adjusting strip screw was	ner 5-29-30-31-32	D-2807 Intermediate b	ar, assembled (4	2 em)			9-30-31-32
D- 148 Elevator transfer slide releasing lever (30 em)	5 - 29 - 30 - 31 - 32	D-2808 Elevator trans:	fer slide releasin	g lever (42 e	m)		9-30-31-32
D- 150 Intermediate bar pawl		D-2809 First elevator :					9-30-31-32
D- 153 Elevator transfer slide releasing lever hinge		E- 90 First elevator	slide guide adjus	ting strip	,		0.00.01.02
pin, assembled	5 - 29 - 30 - 31 - 32		"-16 x 1 1/4"			5.5	9-30-31-32
D- 154 Elevator transfer slide releasing lever spring	5 - 29 - 30 - 31 - 32	E- 240 Intermediate b	ar pawl pin, up	er 1/16" x 3/	8"		9 - 30 - 31 - 32
D- 156 Intermediate bar adjusting screw 8-32 x 7/8"		F-7847 First elevator ;					9-30-31-32
D- 331 Elevator transfer slide releasing lever guide		G- 910 Elevator trans					
pin 1/8" x 9/18"	5-29-30-31-32		"-24 x 1 3/4"			5.0	9-20-21-22
D- 430 Intermediate bar pawl pin, lower 1/18" x 3/8"		G-3999 First elevator :	dide guide screw	lock washe		5.0	9 - 30 - 31 - 32
D- 582 First elevator slide guide adjusting strip	5-29-30-31-32	G-3999 First elevator s	lide guide adjus	ting strip sc	rew		

lock washer

5-29-30-31-32 G-3999 Intermediate bar screw lock washer

G-3999 First elevator slide gib screw lock washer . 29-30-31-32

5-29-30-31-32

. 5-29-30-31-32

D- 583 First elevator jaw duplex rail lever operating block

D- 584 First elevator jaw duplex rail lever operating block

screw 1/4"-24 x 1/2"

D- 601 Intermediate bar facing dowel 1/8" x 13/32"



Distri	buting	Mechanism	Models	5-29-30	-31-32	Elevator Transfer and Spaceband Le	vers 265
		transfer lever spring hook		5 29 - 30 - 31 - 32	C- 93	Spaceband lever turnbuckle eyebolt, r.h., lock	
		transfer lever pin .539" x 2 5/16"		5 - 29 - 30 - 31 - 32		nut 3/8"-18 x 1/2"	5-29-30-31-32
		transfer lever spring		5-29-30-31-32	D- 168	Elevator transfer slide finger screw 4-48 x 1/4"	5-29-30-31-32
		nd lever turnbuckle eyebolt, r.h.		5-29-30-31-32	D- 222	Elevator transfer slide link (30 em)	5-29-30-31-32
		nd lever turnbuckle eyebolt, l.h.		5-29-30-31-32	D- 463	Elevator transfer slide, assembled (mention if	
B- 58		nd lever turnbuckle eyebolt, l.h., hing	e			"Self-Quadder" is used)	5-29-30-31-32
		a, assembled		5-29-30-31-32	D- 802	Elevator transfer slide adjusting screw nut 8-32 x 5/18	5-29-30-31-35
8- 58	Spaceba	nd lever turnbuckle eyebolt, r.h., hing	e		D-2813	Elevator transfer slide link (42 em)	31 - 35
		a, assembled		5-29-30-31-32	D-3154	Elevator transfer slide finger, assembled	5-29-30-31-32
8- 61	Elevator	transfer cam roll		29-30-31-32		Elevator transfer slide and finger, assembled	
3- 96	Elevator	transfer slide link hinge pin set				(mention if "Self-Quadder" is used)	5-29-30-31-32
	sci	rew 4-48 x 1/4"		5 - 29 - 30 - 31 - 32	D-5211	Elevator transfer slide link (42 em)	29:30
3- 108	Elevator	transfer slide link hinge pin	1	5-29-30-31-32		Elevator transfer slide link hinge screw	5-29-30-31-32
- 113	Elevator	transfer lever shaft		5-29-30-31-32		First elevator jaw line stop transfer rod (30 em)	5-29-30-31-32
8- 264	First ele	vator jaw line stop transfer rod			E-3848	First elevator jaw line stop transfer rod (42 em)	5-29-30-31-32
		ew 8-32 x 5/18*		5-29-30-31-32		First elevator jaw link stop transfer rod guard (30 em)	
8- 292	Elevator	transfer cam roll lever		5 - 29 - 30 - 31 - 32		First elevator jaw line stop transfer rod guard (42 em)	29-30-31-32
3- 293	Elevator	transfer cam roll pin, assembled		5-29-30-31-32		First elevator jaw line stop transfer rod cover (30 em)	5-29-30-31-32
3- 358	Elevator	transfer lever		5 - 20 - 30 - 31 - 32		First elevator jaw line stop transfer rod guard (90 em)	
3- 360	Elevator	transfer lever, assembled		5-29-30-31-32		First elevator jaw line stop transfer rod cover	0.20.00.01.02
		transfer lever spring arm		-29-30-31-32	8-4400	hinge pin	5-29-30-31-32
3- 366	Elevator	transfer lever spring arm pin .539" x 1	3/4" 1	5-29-30-31-32	E-4457	First elevator jaw line stop transfer rod cover (42 em)	29 - 30 - 31 - 32
		transfer cam roll lever clamping				First elevator jaw line stop transfer rod guard (42 em)	29 - 30 - 31 - 32
	ser	ew 1/2"-12 x 2"		-29-30-31-32		First elevator jaw line stop transfer rod guard screw	20.00.01.02
3- 471	Elevator	transfer slide adjusting screw 8-32 x 7		5-29-30-31-32	1-2440	lock washer	20:30:31:32
		nd lever operating handle		-29-30-31-32	E-6195	Elevator transfer lever shaft oil hole cover	5 20 30 31 32
				-29-30-31-32		Elevator transfer slide banking screw	5-29-30-31-32
		nd lever turnbuckle eyebolt, l.h., check				First elevator jaw line stop transfer rod cover screw	29 - 30 - 31 - 32
		t 3/8"-16 x 1/8"		-29-30-31-32		First elevator jaw line stop transfer rod guard	29.30.31.32
- 826	Spacebar	nd lever turnbuckle		-29-30-31-32	1233	screw 10-32 x 1/2"	5-29-30-31-32
		transfer lever pin .526" x 2"		-29-30-31-32		Sciew 10-34 x 1/a	0.20.30.31.32
a- 910	Spacebar	nd lever operating handle (30 em)		-20-30-31-32		Parts Not Illustrated	
B-148	Spacebar	nd lever turnbuckle eyebolt, l.h., hinge	pin			ranto Not intistrated	
		ew 8-32 x 5/16"		-29-30-31-32	E-4456	First elevator jaw line stop transfer rod guard,	

29 - 30 - 31 - 32

assembled, from serial No. 53323

assembled (42 em) from serial No. 53323

. 5-28-30-31-32 E-4459 First elevator jaw line stop transfer rod guard.

5-29-30-31-32


29-30-31-32

88-148 Spaceband lever turnbuckle eyebolt, r.h., hinge pin

88-148 Elevator transfer cam roll nin screw 8-32 x 5/18" 5-20-30-31-32


screw 8-32 x 5/18"

88-148 First elevator jaw line stop transfer rod screw 8-32 x 5/18\*



Distributing Mechanism	Models 5-29-30-31-32	Spaceband Levers 267

A- 112 Spaceband lever pawl hinge bushing set screw	B- 763 Spaceband lever pawl spring rod (42 em) 2" long 29:30:31:32
(30 em) 8-32 x 3/8" 5-29-30-31-32	B- 764 Spaceband lever pawl spring (42 em) 2 5/8" long 29-30-31-32
B- 85 Spaceband lever set screw 3/8"-16 x 3/4" 5-29-30-31-32	B- 787 Spaceband lever pawl guide (30 em) . 29-30-31-32
B- 99 Spaceband lever pawl screw (42 em) 8-32 x 3/8" 29-30-31-32	B- 798 Spaceband lever pawl guide (43 em) 29-30-31-32
B- 100 Spaceband lever pawl hinge pin (30 em) 5/32" x .860" 5-29-30-31-32	B- 799 Spaceband lever pawl guide screw (42 cm) 4-48 x 3/16" 29:30:31:32
B- 101 Spaceband lever pawl hinge bushing (30 em) 5-29-30-31-32	B- 800 Spaceband lever pawl, assembled (42 em) 29:30:31:32
B- 102 Spaceband lever shaft collar 5-29-30-31-32	B- 828 Spaceband lever pawl guide piece
B- 103 Spaceband lever shaft collar set screw 1/4"-24 x 1/2" 5-29-30-31-32	screw (30 cm) 8-32 x 3/8" 5-29-30-31-32
B- 104 Spaceband lever pawl spring (30 em) 5-29-30-31-32	
B- 112 Spaceband lever shaft 5-29-30-31-32	B- 828 Spaceband lever pawl screw (42 cm) 8-32 x 3/8" 29-30-31-32 B- 834 Spaceband lever pawl spring rod guide (42 cm) 29-30-31-32
B- 234 Spaceband lever buffer washer, assembled 5-29-30-31-32	
B- 235 Spaceband lever buffer 5-29-30-31-32	B- 835 Spaceband lever pawl bracket (42 em) 29:30:31:32 B- B36 Spaceband lever pawl bracket
B- 243 Spaceband lever pawl (30 em)	
B- 244 Spaceband lever pawl guide piece (30 em) 5-29-30-31-32	screw (42 cm) 10-32 x 11/16" 29-30-31-32
B- 246 Spaceband lever pawl guide screw (30 em) 5-29-30-31-32	B- 837 Spaceband lever, assembled (42 em) 29-30-31-32
B- 247 Spaceband lever pawl, assembled (30 cm) 5-29-30-31-32	B- 859 Spaceband lever pawl guide (30 em) 5-29-30-31-32
	B- 68B Spaceband lever pawl, assembled (30 cm) 5-29-30-31-32
	B- 889 Spaceband lever pawl 5-29-30-31-32
	D- 239 Spaceband lever pawl guide piece
B- 605 Spaceband lever (42 em) 29-30-31-32	dowel (42 em) 3/32" x 3/8" 29-30-31-32
B- 606 Spaceband lever pawl bracket (42 cm) . 31-32	D- 657 Spaceband lever pawl spring rod guide
B- 607 Spaceband lever pawl hinge pin (42 cm) 5/32" x .860" 29:30:31:32	dowel (42 em) 3/32" x 1/4" 29-30-31-32
B- 610 Spaceband lever pawl guide piece (42 em) 29 30 31 32	E-4691 Spaceband lever pawl guide screw lock washer 5-29-30-31-32
B- 611 Spaceband lever pawl, assembled (42 em) 29-30-31-32	F-6195 Spaceband lever shaft oil hole cover . 5-29-30-31-32
B- 612 Spaceband lever pawl spring rod (42 cm) \$ 1/4" long 31-32	G- 119 Spaceband lever pawl hinge pin set
B- 613 Spaceband lever pawl spring (42 em) 3 5/8" long 31-32	screw (42 em) 6-48 x 1/4" 29-30-31-32
B- 614 Spaceband lever pawl spring rod washer (42 em) 29:30:31:32	H- 207 Spaceband lever pawl spring rod guide
B- 615 Spaceband lever pawl bracket	screw (42 em) 8-32 x 1/4"
SCI'CW (42 cm) 10-32 x 1 3/18" 31-32	H-1138 Spaceband lever pawl guide screw (30 em) 5-40 x 1/4" 5-29-30-31-32



Distributing Mechanism			Models	5-29-30-3	1-32 Intermedia	Intermediate Channel 269		
В-	788	Spaceband lever pawl guide rail bearing screw (for first type guide rail)	29-30-3		Intermediate channel front plate extension screw 1/4"-24 x 1/2"			
B-	802	Spaceband lever pawl guide rail spring hook.	20.00.0		Intermediate channel front plate extension			0-31-32
		upper (42 em)	29-30-3	1-32 D-3149	Intermediate channel front plate extension	42 om)		0.31.32
B-	803	Spaceband lever pawl guide rail, assembled (42 em)	28:30:3		Intermediate channel matrix vertical aligning			0.31.32
		Spaceband lever pawl guide rail spring (42 em)	29-30-3		Intermediate channel matrix vertical aligniz		5.39.5	0.31.32
		Spaceband lever pawl guide rail screw (42 em)	29 - 30 - 3		piece gib	В	5.90.5	0.31.32
		Spaceband lever pawl guide rail stop stud (42 em)	29 - 30 - 3		Intermediate channel matrix vertical alignir	g niece		0-31-32
		Spaceband lever pawl guide rail, assembled (30 em)	5-29-30-3		Intermediate channel front plate (42 em)	8 piece		0.31.32
		Spaceband lever pawl guide rail bearing screw	5-29-30-3		Intermediate channel back plate, assembled	(42 em)		0 - 31 - 32
		Intermediate channel back plate screw 3/8"-16 x 3/4"	5 - 28 - 30 - 3		Intermediate channel front and back plate.	(	20.0	0.01.02
		Intermediate channel front plate			assembled (42 em)		99.5	0 - 31 - 32
		screw, short 1/4"-24 x 1"	5-29-30-3	1-32 D-4158	Intermediate channel spaceband friction gui			0.31.32
D-	145	Intermediate channel spaceband rail pin 1/8 " x 5/8"	5 - 29 - 30 - 33		Intermediate channel spaceband friction gui		,	0 01 02
D-	168	Intermediate channel matrix vertical aligning piece			screw (42 em)		20.5	0-31-32
		gib screw 4-48 x 1/4"	5.29.30.3	32 D-6688	Intermediate channel front plate (30 em)			0.31.32
D-	327	Intermediate channel front piece dowel 1/8" x 7/8"	5-29-30-33		Intermediate channel back plate, assembled			0.31.32
D-	331	Intermediate channel back plate dowel 1/8" x 9/16"	5 - 29 - 30 - 33		Intermediate channel front and back plate, a			0.31.32
D	401	Spaceband lever pawl stop pin (30 em) 1/8" x 7/16"	5 - 29 - 30 - 31		Spaceband lever pawl guide rail rest			
D-	717	Intermediate channel front plate			pin (30 cm) 1/8" x 1/2"		5-29-3	0.31.32
		screw, long 1/4"-24 x 1 3/16"	5-29-30-31	-32 G- 397	Intermediate channel front plate extension			

dowel 1/8" x 11/32"

28-30-31-32 G-2790 Spaceband lever pawl guide rail spring hook, 29-30-31-32 lower (42 cm) 5 - 29 - 30 - 31 - 32

29 - 30 - 31 - 32

5 - 29 - 30 - 31 - 32

5-29-30-31-32

D-2622 Intermediate channel spaceband rail (30 em)

D-3045 Intermediate channel spaceband rail (42 em)

D-3145 Intermediate channel front plate extension screw bushing

D-3046 Intermediate channel spaceband friction spring (42 em) 29-30-31-32


















Distributing Mechanism	Models 5-2	9-30-31-32	Intermediate	Channe	1 271
A- 863 Spaceband instruction plate	5 - 29 - 30 - 31 - 32	D-3061 Electric light holder bracke			9 - 30 - 31 - 32
A- 864 Spaceband instruction plate screw 4-48 x 1/4"	5 - 29 - 30 - 31 - 32	D-3062 Electric light holder and bro			9-30-31-32
D- 34 Electric light holder bracket screw 8-32 x 1/2"	5-29-30-31-32	D-3063 Electric light holder bracke			9.30.31.32
D- 386 Electric light holder bracket washer	5-29-30-31-32	D-3080 Electric light holder extensi			9-30-31-32
D- 717 Intermediate channel front plate		D-3288 Quad box (30 em)		5-2	9-30-31-32
screw, long 1/4"-24 x 3/16"	29 - 30 - 31 - 32	D-3289 Quad box (42 em)		21	9.30.31.32
D-1587 Second elevator guide, lower	5 31.32	D-4283 Quad box (30 em) (for use v	rith combination ha	nd stick) 2	9-30-31-32
D-1804 Second elevator guide, lower	29:30	D-4341 Quad box (42 em) (for use v	rith combination ha	nd stick) 2	9-30-31-32
D-3053 Electric light holder bushing	29 - 30 - 31 - 32	D-5247 Second elevator guide, lowe	r screw 1/4"-24 x 5/4	5 - 5 - 21	9-30-31-32
D-3055 Electric light holder screw	29 - 30 - 31 - 32	F-7847 Second elevator guide, lowe	r screw lock washe:		
D-3056 Electric light holder screw washer	29-30-31-32	G- 131 Quad box screw (42 em) 1/4	'-24 x 1/4"	21	9-30-31-32
D-3057 Electric light holder screw thumb nut	29 - 30 - 31 - 32	G- 932 Electric light holder extensi	on set screw 8-32 x	1/8" 21	9-30-31-32
D-3058 Electric light holder, complete	29-30-31-32				



5-29-30-31-32	

Second Elevator 273 Distributing Mechanism A- 116 Second elevator lever adjusting bolt nut 1/2"-12 x 7/8" 5-29-30-31-32 B. 435 Second elevator cam lever shaft 29:30 A- 901 Second elevator lever bracket oil hole cover 20.30 R. 456 Second elevator lever adjusting bolt 20:30 A- 901 Second elevator cam lever oil hole cover 20.30 B- 488 Second elevator lever (30 em) A. 901 Second elevator lever link oil hole cover 29 30 B- 489 Second elevator lever (30 em) 29:30 5-29-30-31-32 B. 539 Second elevator cam lever (42 em) A- 901 Second elevator lever bracket shaft oil hole cover 31:32 3 Second elevator lever adjusting bolt 1/2"-12 x 25/32" 31.32 B- 540 Second elevator lever (42 em) 31 - 32 4 Second elevator lever adjusting spring 31-32 B- 542 Second elevator lever bracket shaft (42 cm) 99-30-31-39 8 Second elevator cam roll 8- 557 Second elevator lever (42 em) 8. 559 Second elevator lever shaft (42 em) 9 Second elevator cam roll pin, assembled 31:32 29:30 8- 19 Second elevator starting spring bolt hinge screw 31.32 B- 591 Second elevator cam lever 29:30 8- 85 Second elevator lever set screw 3/8"-16 x 3/4" 5 - 29 - 30 - 31 32 B- 593 Second elevator lever link 29-20 8- 205 Second elevator lever adjusting bolt check nut 5 - 29 - 30 - 31 32 B- 594 Second elevator lever link lever (30 em) 29.30 8. 595 Second elevator lever adjusting spring B- 217 Second elevator adjusting spring screw 8-32 x 1/4" 5:29:30 31:32 29:30 B- 223 Second elevator lever shaft (30 em) 31 - 32 8- 601 Second elevator lever link lever (42 em) 29:30 B. 223 Second elevator lever bracket shaft (30 em) 29:30 8. 604 Second elevator starting spring 29 - 30

B- 237 Elevator transfer slide releasing lever adjusting screw nut 1/4"-24 x 1/2" 5-29-30-31-32 B- 238 Second elevator starting spring B- 264 Second elevator cam roll pin screw 8-32 x 5/16" 5.90-30-31-39 8- 264 Second elevator lever link pin screw 8-92 x 5/16" B- 307 Second elevator cam lever (30 em) 8- 309 Second elevator cam roll 8. 378 Second elevator starting spring bolt, assembled 8- 379 Second elevator starting spring bolt . . .

8- 380 Second elevator starting spring bolt cap

8. 395 Second elevator cam roll pin, assembled

R. 434 Second elevator lever shaft (30 em)

31.32 31 32 31.32 31.32 31.32 8. 393 Second elevator lever link pin, long, assembled 29:30 29:30 20:30 8- 395 Second elevator lever link pin, short, assembled 29:30 B- 600 Second elevator lever bracket (42 em)

F. 584 Second elevator cam lever shaft set 31.32 screw 1/4"+24 v 19/32" E- 584 Second elevator lever bracket shaft set screw 1/4"-24 x 19/32" G. 139 Second elevator adjusting spring hook G- 183 Second elevator adjusting spring G- 910 Elevator transfer slide releasing lever adjusting screw 1/4"-24 x 1 3/4" Parts Not Illustrated B- 592 Second elevator lever bracket (30 em)

E- 84 Second elevator starting spring bolt pin 3/16" x 1 3/16"

31 - 32

29 30

29 - 30


20:30

29-30

5 - 29 - 30 - 31 - 32

5-29-30-31-32

29-30-31-32



Distributing Mechanism	Models 5-2	9-30-31-32	Second	Eleva	tor 27	/5
8- 13 Second elevator bar link stop pin 1/4" x 2 3/8"	5-29-30-31-32	G-1821 Second elevator bar (30 em)			-29-30-31-	32
8B-138 Second elevator bar plate screw 8-32 x 1/2"	5-29-30-31-32	G-2041 Second elevator, assembled (30 em)			31	32
D- 239 Spaceband lever pawl cam dowel (42 em) 3/32" x 3/8"	29-30-31-32	G-2053 Second elevator bar link hinge pin		. 8	-29-30-31-	32
D- 713 Second elevator bar plate guide screw 4-48 x 5/32"	29:30	G-2670 Second elevator, assembled (30 em)			29-30	
D- 971 Spaceband lever pawl cam screw (42 em) 8-32 x 1/4"	29 - 30 - 31 - 32	G-2867 Second elevator bar plate (42 em)			31 -	32
E- 42 Second elevator bar link hinge pin cotter pin	5-29-30-31-32	G-2905 Second elevator bar plate (42 em)			29 - 30	
E - 175 Second elevator bar delivery pawl stud		G-2957 Second elevator bar delivery pawl (42	em)		29-30-31-	32
pin 1/16" x 7/16"	5 - 29 - 30 - 31 - 32	G-3197 Second elevator bar link (42 cm)			31 -:	32
G- 70 Second elevator bar link hinge pin rod 1/8" x 2 13/32"	5 - 29 - 30 - 31 - 32	G-3198 Second elevator, assembled (42 em)			31 -	32
G- 77 Second elevator bar delivery pawl (30 cm)	5-29-30-31-32	G-3199 Second elevator bar link (42 cm)			29:30	
G- 78 Second elevator bar delivery pawl spring (30 em)	5 - 29 - 30 - 31 - 32	G-3200 Second elevator, assembled (42 em)			29 - 30	
G- 79 Second elevator bar delivery pawl stud	5-29-30-31-32	G-3201 Spaceband lever pawl cam (42 em)			29-30-31-	32
G- 132 Second elevator bar delivery pawl plunger	5 - 29 - 30 - 31 - 32	G-3980 Second elevator bar link hinge pin (4)	em)		20.30	
G- 136 Second elevator bar plate (30 em)	5 31.32	H-1299 Second elevator bar delivery pawl spi			29-30-31-	32

1-1086 Second elevator har link hinge nin set

J-1228 Second elevator bar link hinge pin set

screw (42 em) 10-32 x 7/16"

screw nut (42 em) 10-32 x 1/6"

J-5498 Second elevator bar plate guide screw lock washer

29.30

29:30

29:30

G- 190 Second elevator bar delivery pawl spring

pin 1/16" x 9/32"

G-1269 Second elevator bar link (30 cm)

G-1371 Second elevator bar plate (30 em)

G-1372 Second elevator bar plate guide


G-1682 Second elevator bar link (30 em)

31 - 32 29:30 Please Give Model and Serial Number When Ordering

5 - 29 - 30 - 31 - 32

29 - 30

29:30



Distributing Mechanism	Models 5-29-30-31-32
Distributing Mechanism	Models 5-29-30-31-32

F-7847 Second elevator guide, lower, screw lock washer

G- 152 Second elevator guide, upper, screw 3/8"-18 x 1"

G- 240 Second elevator guide, upper, front, dowel 3/18" x 3/4" 29:30

#### Second Elevator 277 B- 20 Second elevator safety pawl hinge pin, assembled 91.89 G- 912 Second elevator guide, upper, screw 1/2"-12 x 1 1/8" B- 331 Second elevator safety pawl 91.99 G-1354 Second elevator guide, upper 31 - 32 B- 514 Second elevator safety pawl spring G-2015 Second elevator guide, upper, dowel 205" x 7/8" 29:30 31.32 B- 515 Second elevator safety pawl stud washer G-3094 Second elevator guide, upper, front (30 em) 29:30 90.30 B- 590 Second elevator safety pawl 29.30 G-3095 Second elevator guide, upper, back (30 em) 29:30 88-148 Second elevator safety pawl hinge pin G-3096 Second elevator guide, upper, back, screw 8-32 x 5/16" screw 3/8"-16 x 1 1/4" 31-32 29:30 BB-247 Second elevator safety pawl stud nut 5/8"-11 x 1 1/18" G-3137 Second elevator guide, upper, front (42 em) 20.30 C- 123 Second elevator safety pawl hinge pin cotter pin 31-32 G-3138 Second elevator guide, upper, back (42 em) 29:30 E- 184 Second elevator guide, upper, front, G-3398 Second elevator safety pawl adjusting dowel (30 em) 3/18" x 1" screw nut 1/4"-24 x 1/8" 29:30 F. 235 Second elevator safety nawl spring book

G-3414 Second elevator safety nawl stud

H- 352 Second elevator guide, upper, front, screw washer

H- 352 Second elevator guide, upper, screw washer

J-6084 Second elevator safety pawl adjusting

20:30


5.29.30

G- 240 Second elevator guide, upper, back, dowel 3/16" x 3/4" 29:30 screw 1/4"-24 x 9/10" Please Give Madel and Serial Number When Ordering


29.30

5-29-30-31-32

31-32



A-		Distributor shifter lever shaft oil hole cover 5.29.30.31.32	D- 802	Distributor shifter lever link screw, r.h.,	
В-		Distributor shifter lever screw 3/8"-16 x 5/8" 5-29-30-31-32		nut 8-32 x 5/16"	
B-	75	Distributor shifter cam rider spring 5-29-30-31-32		Distributor shifter lever link spring washer	
B-	76	Distributor shifter cam rider 5-29-30-31-32		Distributor shifter lever link spring washer cotter pin	31 - 32
B-	77	Distributor shifter cam rider stop screw 5-29-30-31-32	E- 42	Distributor shifter slide buffer cotter pin	29 - 30 - 31 - 32
B-	77	Distributor shifter cam rider hinge screw 5-29-30-31-32	E- 90	Distributor shifter lever spring screw 3/8"-16 x 1 1/4"	29-30-31-32
R.		Distributor shifter lever shaft 5-29-30-31-32	E- 525	Distributor shifter slide buffer washer	29 - 30 - 31 - 32
В-		Distributor shifter lever spring 5-29-30-31-32	G- 404	Distributor shifter slide safety stop pin	31 - 32
В-		Distributor shifter lever hub set screw 3/8"-16 x 3/4" 5-29-30-31-32		Distributor shifter slide spring	29.30
		Distributor shifter lever hub 5-29-30-31-32		Distributor shifter lever link spring	31-32
		Distributor shifter lever 5 31-32		Distributor shifter slide spring rod	
		Distributor shifter lever link (30 em) 29-30		Distributor shifter lever link screw	
		Distributor shifter lever link (42 em) 29-30		Distributor shifter slide	
				Distributor shifter slide, assembled	
В-	633	Distributor shifter lever link and bearing,		Distributor shifter lever link screw, r.h.	
		assembled (30 em) 5 31-32		Distributor shifter slide buffer, assembled	29-30-31-32
		Distributor shifter lever link rod 5 31-32		Distributor shifter slide	
		Distributor shifter lever link, assembled (30 em) 5 31-32		Distributor shifter slide, assembled	29.30
		Distributor shifter lever link screw, l.h	G-4090	Distributor shifter slide buffer spring	29 - 30 - 31 - 32
B -	63B	Distributor shifter lever link and bearing,	G-4112	Distributor shifter slide, assembled	5 31-32
		assembled (42 em) 31 · 32	J-1218	Distributor shifter slide spring pin 1/8" x 9/16"	29:30
В-	639	Distributor shifter lever link, assembled (42 em) 31-32		Parts Not Illustrated	
		Distributor shifter lever link screw, l.h.,			
-		nut 8-32 x 5/18" 5 31-32	B- 323	Distributor shifter lever, assembled	31 - 32
	802	Distributor shifter lever link screw nut 8-32 x 5/18" 29-30		Distributor shifter lever, assembled	29:30
D-	802	Distributor annier level link seren lines-on x 5/10		D. D	



Models	5-29-30-31-32	

Distributing Mechanism


Distributor Shifter 281

op screw 1/4\*-24 x 1/2\* 5 31-32

op screw 1/4\*-24 x 1/2\* 29-30

op screw 1/4\*-24 x 1/2\* 29-20

	Distributor shifter slide guide screw 5/8"-11 x 2 1/2" 29:30			31-32
A- 13	Distributor shifter slide guide screw 1/2"-12 x 1 3/4" 5 31-3		Distributor shifter slide stop screw 1/4"-24 x 1/2" 29-30	
D- 86	Distributor shifter slide guide adjustable bank		Distributor shifter slide safety stop screw 1/4"-24 x 1/2" 29-20	
	screw 8-32 x 9/32" 5 31-3			31.32
	Distributor shifter slide stop screw 8-32 x 1 1/4" 29-30		Distributor shifter slide guide (30 em) 29-30	
E-1654	Distributor shifter slide stop screw stud nut	G-3139	Distributor shifter slide guide (42 em) 29-30	
	lock washer 31-3			31.32
E-2800	Distributor shifter slide guide adjustable bank screw 31-3			31.32
E-3265	Distributor shifter slide stop screw lock nut 8-32 x 7/32" 29-30			31.32
	Distributor shifter slide stop screw 1/4"-24 x 1/2" . 5 31-3		Distributor shifter slide stop screw stud 29-30	
F- 723	Distributor shifter slide guide dowel 1/4" x 1 3/18" 29-30		Distributor shifter slide guide adjustable bank, r.h s	
F-5705	Distributor shifter slide stop bracket		Distributor shifter slide guide adjustable bank, l.h. 5	
	screw 1/4"-24 x 7/18" 5 31-1	G-4296	Distributor shifter slide guide adjustable	
F-6655	Distributor shifter slide stop screw stud lock washer 29-30		bank bushing 5	
	Distributor shifter slide stop screw 1/4"-24 x 1/4" 29:30		Distributor shifter slide stop screw	
	Distributor shifter slide latch screw 5-29-30-31-3			31 - 32
G- 198	Distributor shifter slide latch 5-29-30-31-3	32 J-1228	Distributor shifter slide stop screw	
	Distributor shifter slide guide (30 em)	32	stud lock nut 10-32 x 5/16" 29-30	




#### FRONT VIEW


G-1579 (5)

G-4642 (5) (PROM SERIAL NO. 62820)

G-3316 (32) (LARGE ASSEMBLER STAR) G-3645 (31) (SMALL ASSEMBLER STAR)

Check Parts by Referring to Detail Pages.







Distributin	g Mechonism	Models	5-31-32	Distributor	Box	285
D- 973 Distri	butor box back plate dowel, long .	5.31.32	G- 246 Distributor box locating pin	3/16" x 15/32"		31 - 32
	butor box front plate lower rail screw 6-48 x 3/16"	5 31.32	G- 354 Distributor box matrix lift le	ever hub screw 6-48 x 5/16		31-32
G- 90 Distri	butor matrix lift lever hub	31:32	G- 438 Distributor box front plate u	pper rail		
	butor box bolt, 3 3/4" long	5.31.32	spring rivet 1/16" x 1/6			31-32
	butor box bolt washer	5.31.32	G- 439 Distributor box front plate u			31 - 32
	butor box bolt handle	5.31.32	G- 645 Distributor box back plate le	ower rail		31 - 32
	butor box back plate screw 6-46 x 3/6"	5.31.32	G-1438 Distributor box bracket and			5
G- 118 Distri	butor box back plate lower rail		G-1460 Distributor box front plate le			5 - 31 - 32
	screw, long 6-46 x 5/16"	31 - 32	G-1461 Distributor box back plate le	ower rail		5
	butor box back plate lower rail		G-1479 Distributor box front plate u			5
	screw, short 6-46 x 1/4"	5.31.32	G-1480 Distributor box back plate u	pper rail		5
	butor box back plate upper rail screw 6-48 x 5/32"	5.31.32	G-1998 Distributor box front plate u	pper rail		
	butor box front plate upper rail screw 6-46 x 5/32"	5.31.32	screw (through brace)			5.31.32
G- 122 Distri	butor box back plate screw 6-46 x 1/4"	5.31.32	G-1998 Distributor box back plate le	ower rail		
G- 122 Distri	butor box back plate screw 6-46 x 1/4"	5.31.32	screw, long 6-46 x 11/32			31-32
G- 123 Distri	butor box front plate upper rail screw 6-46 x 5/32"	5.31.32	G-2362 Distributor box matrix lift, a			5
	butor box matrix lift lever hub set screw 8-32 x 5/16		G-2852 Distributor box back plate le			
G- 158 Distri	butor box plate dowel	5.31.32	lock washer			31:32
	butor box back plate dowel, short 3/32" x 1/4"	31.32	G-3311 Distributor box bracket and	locating pin, assembled		31 - 32
	butor box front plate dowel, short 3/32" x 1/4"	31.32	G-3313 Distributor box front plate,			31:32
G- 159 Distri	butor box back plate upper rail dowel 3/32" x 1/4"	31.32	G-3314 Distributor box back plate			31 - 32
	butor box front plate upper rail dowel 3/32" x .162"	31.32	G-3315 Distributor box back plate, a	ssembled		31 - 32
G- 163 Distri	butor box front plate lower rail dowel 3/32" x .190"	31.32	G-3318 Distributor box front plate u	pper rail spring, auxiliar	1	31 - 32
	butor box back plate dowel, long 3/32" x 3/6"	31.32	G-3581 Distributor box front plate u	pper rail, without springs		31.32
G- 216 Distri	butor box front plate, assembled	. 5	G-3582 Distributor box front plate u			31.32
	butor box back plate, assembled	. 5	G-3583 Distributor box back plate u	pper rail		31.32
G- 228 Distri	butor box back plate lower rail		G-4640 Distributor box front plate u	pper rail spring		5 - 31 - 32
	dowel, short 3/32" x 9/32"	31.32	H- 56 Distributor box bolt handle	pin 5/32" x 15/16"		5-31-32
	butor box back plate lower rail					
	dowel, long 3/32" x 11/32"	31.32				
	N Cl 1		Int Name to All the Control of the C			



Distributing Me	chanism	Models	5-31-3	2	Distributor	Box	287
C- 93 Distributor b	ox matrix lift cam lever adjusting		G- 435	Distributor box matrix lift cam lever	assembled		5-31-32
screw n	nut 3/8"-16 x 1/2"	5-31-32	G- 613	Distributor box font distinguisher stu			
D- 181 Distributor b	ox matrix lift cam pin 1/8" x 5/8"	5.31.32	Q- 614	Distributor box font distinguisher			31.32
	ox font distinguisher block		G-1459	Distributor box font distinguisher ble	ock		5
screw, I	long 6-48 x 3/16"	31-32	G-1806	Distributor box font distinguisher stu	ad spring plate		31.32
G- 95 Distributor b	ox bar stop pin 3/32" x 1 5/32"	5.31.32	G-1998	Distributor box back plate lower rail	and provide provide		
G- 96 Distributor b	ox matrix lift lever	5-31-32		screw, long 6-48 x 11/32"			31.32
G- 98 Distributor b	ox matrix lift spring	5-31-32	G-2042	Distributor box matrix lift cam			5-31-32
G- 99 Distributor b	ox matrix lift screw	5.31.32	G-2361	Distributor box matrix lift spring stu	ıd		31.32
	ox matrix lift lever hinge pin	5.31.32	G-2389	Distributor box font distinguisher stu	ad spring		31.32
G- 101 Distributor b	ox matrix lift cam roll	5-31-32	G-2413	Distributor box bar point (small asse	mbler star)		
	ox matrix lift cam roll stud	31.32	G-2415	Distributor box bar, assembled (small	ll assembler star)		5-31
G- 103 Distributor b	ox matrix lift cam roll stud pin .041" x .220"	5 31 - 32	G-2872	Distributor box font distinguisher stu	id rod, short		31-32
	ox font distinguisher block		G-2873	Distributor box font distinguisher stu	id rod, long		31-32
	short 6-48 x 5/32"	31-32	G-2874	Distributor box font distinguisher stu	id. assembled		31-32
	ox front plate brace screw 6-48 x 1/2"	5-31-32	G-3190	Distributor box matrix lift stop			31-32
G- 127 Distributor b	ox matrix lift cam lever adjusting		G-3192	Distributor box matrix lift, assemble	d		31-32
	/8"-16 x 5/8"	5-31-32	G-3193	Distributor box font distinguisher blo	ock		31-32
G- 144 Distributor b	ox font distinguisher stud nut spring		G-3308	Distributor box bar point (large asser	mbler star)		31-32
	ox font distinguisher stud nut	5	G-3309	Distributor box bar, assembled (large	e assembler star)		31-32
G- 155 Distributor b	ox matrix lift cam lever stop screw	5.31.32	G-4033	Distributor box matrix guard pawl sp	oring rivet		31 - 32
	ox matrix lift cam roll stud rivet .040" x .350	31.32	G-4034	Distributor box matrix guard pawl, a	ssembled		31 - 32
G- 158 Distributor b	ox bar hinge pin 3/32" x 7/8"	5.31.32	G-4036	Distributor box matrix guard pawl for	alerum stud		31 - 32
G- 160 Distributor b	ox matrix lift stop pin 3/32" x 7/32"	31.32	G-4037	Distributor box matrix guard pawl sp	pring		31 - 32
G- 164 Distributor b	ox front plate brace dowel, long 3/32" x 3/8"	31.32	G-4038	Distributor box matrix guard pawl sp	pring stud		31.32
G- 167 Distributor b	ox bar point rivet 1/16" x .439"	31.32	G-4040	Distributor box matrix guard bracket	t		31 - 32
G- 220 Distributor b	ox front plate brace, assembled	5.31.32	G-4041	Distributor box matrix guard, assemb	oled		31.32
G- 229 Distributor b	ox front plate brace dowel, short 3/32" x 11/	32" 31-32	G-4639	Distributor box bar point			5 - 31 - 32
G- 229 Distributor b	ox back plate lower rail		G-4641	Distributor box matrix lift cam lever	spring		5-31-32
dowel,	long 3/32" x 11/32"	31:32	H- 192	Distributor box matrix guard pawl st	op pin		31.32
G- 243 Distributor b	ox matrix lift lever returning spring	5.31.32	1-2540	Distributor box matrix guard screw v	washer		31 - 32
G- 244 Distributor b	ox back plate upper rail special screw	5.31.32	1-5036	Distributor box matrix guard screw			31 - 32
G- 432 Distributor b	ox matrix lift cam lever spring	5.31.32					




Distributing Mechanism	Models	31-32	Font	Distinguisher	Lever	289
D- 802 Distributor box font distinguisher indicator		G-1068 Distrib	tor box font distinguishe	er lever, short		31.32
screw nut 8-32 x 5/16"  E - 224 Distributor box font distinguisher indicator	31-32	G-1069 Distribu	tor box font distinguished	er lever, long		
bracket screw 5/16" x 11/18"	31-32	G-1071 Distribt	ttor box font distinguishe ttor box font distinguishe	er lever spring		31.32
E-1024 Distributor box font distinguisher lever	31.92	G 1400 Distribu	itor box font distinguishe			
bracket screw 1/4"-24 x 3/4"	31-32		tor box font distinguished			31.32
G- 163 Distributor box font distinguisher indicator			justing screw 1/4"-24 x 1			31-32
pin 3/32" x .190"	31-32	G-1404 Distribu	tor box font distinguishe	er lever shaft		31-32
G- 229 Distributor box font distinguisher lever, short,		G-3982 Distribu	tor box font distinguishe	er indicator bracket		31 - 32
pin 3/32" x 11/32"	31.32		tor box font distinguishe			
G- 240 Distributor box font distinguisher lever		bi	acket, assembled			31-32
bracket dowel 3/16" x 3/4"	31.32	G-3984 Distribu	tor box font distinguishe	er lever bracket		31.32
G- 702 Distributor box font distinguisher lever		G-3985 Distribu	tor box font distinguishe	er lever and		
collar pin 3/32" x 9/16"	31.32	bı	acket, assembled			31 - 32
G- 702 Distributor box font distinguisher lever, long,			tor box font distinguishe			
pin 3/32" x 9/16" G-1065 Distributor box font distinguisher indicator	31.32	bı	acket dowel 1/4" x 3/4"	25 25 27		31.32
G-1066 Distributor box font distinguisher indicator G-1066 Distributor box font distinguisher indicator spring			tor box font distinguishe			
G-1066 Distributor box iont distinguisher indicator spring	31.32	ac	justing screw nut 1/4"-24	x 3/8"		31.32




## FRONT VIEW

G-3891 MODELS (29-30) (RESDUE) 72 90 CHEV TO SERVE HICE )
G-3387 MODELS (29-30) (RESMUERIUL NO 54698 TO SERVE NO 5758 HICE.)
G-4546 MODELS (29-30) (RESMUERIUL NO 57555)



Check Parts by Referring to Detail Pages.



Distributing	Mechanism
--------------	-----------

## Models 29-30

# Distributor Box, Upper 293


- 239	Distributor box, upper, lower rail separating block		G- 532	Distributor box, upper, front plate dowel 3/32" x 15/32" 29:
	adjusting block, back, dowel 3/32" x 3/8"	29.30		Distributor box, upper, locating plate 29-
	Distributor box, upper, front plate dowel 3/32" x 13/18"	29:30	G-2896	Distributor box, upper, lower rail separating block
	Distributor box, upper, back plate dowel, short 3/32" x 13/16"	29-30		adjusting block 29-
-1029	Distributor box, upper, back plate dowel, long 3/32" x 13/16"	29:30	G-3226	Distributor box, upper, locating pin 29:
- 267	Distributor box, upper, front plate, lower		G-3231	Distributor box, upper, bracket . 29-
	rail screw 6-48 x 3/16"	29:30	G-3252	Distributor box, upper, front plate, upper rail spring, front 29-
- 90	Distributor box, upper, matrix lift lever hub	29-30	G-3253	Distributor box, upper, front plate, upper rail spring, back 29-
- 117	Distributor box, upper, lower rail separating block		G-3373	Distributor box, upper, bracket
	adjusting block screw, back 6-48 x 3/8"	29-30	G-3376	Distributor box, upper, front plate, upper rail 29-
- 117	Distributor box, upper, front plate screw 6-48 x 3/8"	29:30	G-3377	Distributor box, upper, front plate, upper rail, assembled 29-
	Distributor box, upper, back plate, lower rail screw 6-48 x 3/8"		G-3381	Distributor box, upper, back plate, upper rail
- 118	Distributor box, upper, lower rail separating block	20.00	6-3839	Distributor box, upper, front plate
	adjusting block screw, front 8-49 x 5/16"	29-30	G-3840	Distributor box, upper, back plate 29:
. 119	Distributor box, upper, front plate, lower rail screw 6-48 x 1/4"		G-2045	Distributor box, upper, front plate, lower rail 29:
	Distributor box, upper, back plate, lower rail screw 6-48 x 1/4°		G-3846	Distributor box, upper, back plate, lower rail 29:
	Distributor box, upper, front plate, upper rail screw 8-48 x 1/4"		6 3040	Distributor box, upper, lower rail separating block
119	Distributor box, upper, front plate, lower rail	80.00	0.3040	
	screw, long 6-48 x 1/4" .	20:30	C 2004	adjusting block 29: Distributor box, upper, front plate 29
. 121	Distributor box, upper, front plate, upper rail	40.90	C 300F	Distributor box, upper, front plate
	screw, center 8-48 x 5/32"	29 - 80	G-3690	Distributor box, upper, back plate
122		29:30	G-3896	Distributor box, upper, front plate, lower rail 29
122	Distributor box, upper, front plate screw 6-48 x 1/4* Distributor box, upper, front plate, upper rail	29.30	G-3897	Distributor box, upper, back plate, lower rail
123		29-30	G-4540	Distributor box, upper, front plate, upper rail spring, front 29-
150	screw, r.h. 6-48 x 5/32" . Distributor box, upper, back plate dowel, short 3/32" x 1/4"		G-4543	Distributor box, upper, front plate, upper rail, assembled 29:
159	Distributor box, upper, back plate dower, snort 3/32° x 1/4° Distributor box, upper, back plate, upper rail	29:30		Parts Not Illustrated
- 159	Distributor box, upper, back plate, upper rail			
	dowel 3/32" x 1/4"	29-30	G-3380	Distributor box, upper, front plate, assembled
- 162	Distributor box, upper, front plate, upper rail			(72-90) (from serial No. 54853)
	dowel 3/32" x .162"	29.30	G-3889	Distributor box, upper, front plate, assembled
- 163	Distributor box, upper, front plate, lower rail			(used on 72-90 only to serial No. 54698) 29-5
	dowel 3/32" x .190"	29.30	G-3890	Distributor box, upper, back plate, assembled
- 164	Distributor box, upper, back plate dowel, long 3/32" x 3/8"	29:30		(used on 72-90 only to serial No. 54698)
- 228	Distributor box, upper, back plate, lower rail		G-3898	Distributor box, upper, back plate, assembled
	dowel 3/32" x 9/32"	29:30		(used on 29 only to serial No. 51293)
- 244	Distributor box, upper, back plate, upper rail special screw	29.30	G-3899	Distributor box, upper, front plate, assembled
- 354	Distributor box, upper, back plate screw 6-48 x 5/18"	29 - 30		(used on 29 only to serial No. 51293) 29
- 354	Distributor box, upper, matrix lift lever hub		G-4066	Distributor box, upper, back plate, assembled
	screw 6-48 x 5/16"	29:30		(72-90) (from serial No. 53531)
				Distributor box, upper, front plate, assembled
- 438	Distributor box, upper, front plate, upper rail spring rivet 1/18" x 1/8"	29.30		




Distri	buting Mechanism	Models	29-30 Distributor Box, Upper	295
B- 96	Distributor box, upper, matrix bridge guiding rod			29.30
	screw 4-48 x 1/4"	29:30		$29 \cdot 30$
C- 93	Distributor box, upper, matrix lift cam lever adjusting			20.30
	screw nut 3/8"-18 x 1/2"	29 30		29.30
	Distributor box, upper, matrix lift cam pin 1/8" x 5/8"	20.30		29.30
D- 802	Distributor box chute matrix guide stop			29.30
	screw nut (72-90) 8-32 x 1/8"	29-30		29.30
D- 802	Distributor box, upper, font distinguisher			29.30
	nut (90 char.) 8-32 x 1/8°	20 30		29.30
	Distributor box chute dowel 3/32" x 5/16"	29:30		29.30
	Distributor box chute screw 8-32 x 7/16"	29.30		20.30
	Distributor box chute support screw 10-32 x 1/2"	29.30		26.30
D-2172	Distributor box chute matrix guide stop			29.30
	screw (72-90) 8-32 x 13/16"			28.30
	Distributor box, upper, bolt set screw 10-32 x 0/32"	29 30		29.30
E- 243	Distributor box, upper, matrix bridge support			29.30
	dowel 1/16" x .225"	29.30		29.30
	Distributor box, upper, bolt set screw shoe	29.30		29.30
	B Distributor box chute support dowel 3/16" x 5/8"	29.30		29.30
	5 Distributor box, upper, bar stop pin 3/32" x 1 5/32"	20 30		$29 \cdot 30$
	Distributor box, upper, matrix lift lever hinge pin	20:30		29.30
	Distributor box, upper, matrix lift cam roll	20.30		20.30
	Distributor box, upper, matrix lift cam roll stud	20 30		29-30
G- 103	Distributor box, upper, matrix lift cam roll stud			29 30
	pin .041" x .220"	20 30		29-30
G- 127	Distributor box, upper, matrix lift cam lever adjusting			29.30
	screw 3/8"-16 x 5/8"	20.30		29.30
	5 Distributor box, upper, matrix lift cam lever stop screw	20.30		29.30
G- 156	5 Distributor box, upper, matrix lift cam lever hub			29.30
	set screw 8-32 x 5/16"	29.30		29.30
G- 15	Distributor box, upper, matrix lift cam roll stud			29-30
	rivet .040" x .350"	29:30		29.30
	B Distributor box, upper, bar hinge pin 3/32" x 7/8"	29.30	G-3875 Distributor box, upper, matrix bridge guiding	
	Distributor box, upper, bar point rivet 1/18" x .438"	20:30		29.30
	P Distributor box, upper, matrix lift cam lever spring	29.30		29.30
	Distributor box, upper, font distinguisher	29.30		29:30
G- 825	Distributor box, upper, matrix lift shaft set		J- 800 Distributor box, upper, bolt handle stop screw	29.30
	screw 4-48 x 3/16"	29:30		




	buting Mechanism Mode			
88-134	Distributor box font distinguisher lever shoe dowel 1/8° x 3/		G-3885 Distributor box bridge control lever	29
	Distributor box bridge control lever shoe dowel 1/8" x 3/8"	29-30		
D- 145	Distributor box font distinguisher indicator bracket			29.3
	dowel 1/8" x 5/8"	29-30		
D- 145	Distributor box, upper, font distinguisher and bridge contro indicator bracket support dowel 1/8" x 5/8"	29:30		29.3
F- 64	Distributor box font distinguisher indicator bracket	29:30		20:30
F- 64	screw 1/4"-24 x 23/32"	29-30		29 30
	Distributor box font distinguisher lever shoc	29.30		29
r- 112	screw 14-24 x 3/8"	29 30		29:30
E 115	Distributor box bridge control lever shoe screw 14-24 x 3/8"	29:30		20.30
	Distributor box font distinguisher and bridge control	20.00		20.30
- 400	lever bracket dowel 3/18" x 5/8"	29.30		29:30
F. 689	Distributor box font distinguisher and bridge control		G-3942 Distributor box, upper, bridge control indicator,	20.00
- 000	lever bracket support screw 1/4"-24 x 3/4"	29-30		29:30
G- 163	Distributor box, upper, font distinguisher and bridge contro		G-3944 Distributor box, upper, bridge control indicator,	AD 01
	indicator, r.h. and l.h., pin 3/32" x .190"	29:30		29 30
G-1066	Distributor box, upper, font distinguisher and bridge contro	1	G-3946 Distributor box, upper, bridge control indicator,	-
	indicator spring	29-30		29:30
G-1345	Distributor box, upper, font distinguisher and bridge contro	1	G-3974 Distributor box, upper, font distinguisher and bridge control	
	indicator screw	20.30	indicator bracket	29:30
G-3854	Distributor box font distinguisher and bridge control		G-3975 Distributor box, upper, font distinguisher and bridge control	
	lever bracket	20.30	indicator bracket support	29:30
	Distributor box font distinguisher lever	29:30		
G-3859	Distributor box bridge control lever	29:30		29 30
G-3860	Distributor box font distinguisher and bridge control		G-3977 Distributor box, upper, font distinguisher and bridge control	
	lever fulcrum pin	29.30		29 30
G-3860	Distributor box matrix tray pin	29:30		
G-3861	Distributor box font distinguisher lever plunger	29.30		29 - 30
G-3861	Distributor box bridge control lever plunger			
	Distributor box font distinguisher lever plunger spring	29:30		29 - 30
	Distributor box bridge control lever plunger spring	29:30		
	Distributor box font distinguisher lever plunger knob	29:30		29.30
	Distributor box bridge control lever plunger knob	29:30		
	Distributor box font distinguisher lever shoe			29 - 30
	Distributor box bridge control lever shoe	29 30		
G-3865	Distributor box font distinguisher indicator bracket supporting roll	29 - 30		29:30
	Distributor box font distinguisher indicator bracket	29.30		29 30
G-3867	supporting roll pin 1/4" x 9/16"	29:30	1- 286 Distributor box bridge control lever plunger nut knob lock nut	
2-2071	Distributor box font distinguisher and bridge control	29.30	1- 286 Distributor box font distinguisher lever plunger knob	29 30
u-3071		29:30		
2-3971	lever fulcrum pin set screw 10-32 x 3/16"  Distributor box matrix tray pin set screw 10-32 x 3/16"	29:30		29 - 30
	Distributor box matrix tray pin set screw 10-32 x 3/16"  Distributor box font distinguisher indicator bracket	29.30	Parts Not Illustrated	
G-00/2	supporting roll pin set screw 5-40 x 3/16*	29 - 30	G-3883 Distributor box bridge control lever and bracket, assembled	99 - 90
2.3991	Distributor box font distinguisher lever, assembled	29:30		29.30
	Distributor box bridge control lever, assembled	29:30		29.30
	Distributor box font distinguisher lever	. 29	macanorea (so camacter)	20,00






G-3024 MODELS 29-30




Distri	buting	Mechanism		Models	29-30	Distributor Box, Lower 3	301
			trix lift cam pin 1/8" x 5				9 · 30
			shaft bearing dowel 3/	32" x 1/2" 29·30			9.30
D- 802			trix lift lever adjusting				9.30
		ew nut 8-32 x 5/16"		29.30	G-2795	5 Distributor box, lower, matrix lift lever	
		tor box, lower, ma		29.30			9.30
D-1535			lrix lift lever pivot				9.30
		screw 8-32 x 3/16"		29.30			9 - 30
E- 119			arating block, lower,				9 - 30
			tion of the state of	29.30			9 · 30
E- 231			irix pusher slide lever		G-3005		9.30
		n pin 1/8" x 3/8"		29.30			9.30
E- 947			rix lift lever fulcrum				9.30
	scr	ew nut 1/4"-32 x 3/	8"	29.30		8 Distributor box, lower, matrix pusher, back, assembled 28	
			per, extension, lower se				9.30
			rix lift lever spring hoo	k 29-30		O Distributor box, lower, matrix pusher slide lever29	
G- 164		tor box, lower, mat	rix pusher, front,				9.30
		wel 3/32" x 3/8"		29-30	G-3023	3 Distributor box, lower, cam shaft bearing 29	9.30
G- 164		tor box, lower, mat	rix pusher, back,		G-3063	3 Distributor front screw, upper, extension, lower	
		wel 3/32" x 3/8"		29.30			9.30
			rix lever spring stud			O Distributor box, lower, cam shaft	
			rix pusher slide spring				9.30
G- 739			rix pusher slide lever ca			5 Distributor box, lower, matrix pusher support screw nut	9.30
		screw 8-32 x 3/16"		29 - 30	G-3156	6 Distributor box, lower, matrix pusher support screw	
			rix lift spring stud, long			nut check nut	9.30
			shaft bearing screw 8-2			1 Distributor box, lower, matrix pusher, back 29	
			rix lift lever pivot	29-30		3 Distributor box, lower, matrix pusher slide	9.30
G-1974			rix lift lever fulcrum		G-3174	4 Distributor box, lower, matrix pusher, front, support	
		ew 1/4"-32 x 5/8"	a mana " Tana	29-80		rivet, long 29	9 · 30
			rix lift lever link screw		G-3174	4 Distributor box, lower, matrix pusher, back, support	
			rix pusher slide spring	29.30		rivet, long	
			rix pusher, front, suppo		G-3175	5 Distributor box, lower, matrix lift	
			rix pusher, back, suppor				9.30
			irix pusher, front, suppo			7 Distributor box, lower, matrix lift, assembled 29	
			rix pusher, back, suppo				9.30
			rix lift adjusting screw		G-3183	3 Distributor box, lower, matrix lift adjusting screw	
		or box, lower, mat		29.30			9.30
		or box, lower, mat		29:30	G-3210		9.30
			rix lift lever link cap	29 - 30	H- 177	7 Distributor box, lower, matrix pusher slide lever fulcrum	
			rix pusher slide pin	29 - 30			9.30
			rix pusher slide lever ca		M- 177	7 Distributor box, lower, matrix pusher slide pin	
			rix pusher slide roll rix pusher slide lever ca	. 29.30			9 - 30
					3- 247	7 Distributor box, lower, matrix pusher slide lever cam	
			rix slide lever fulcrum : rix lift screw			roll pin 1/16" x 3/8" 29  8 Distributor box, lower, matrix lift lever link	9 - 30
					J=1228		
	Dietribut	or box, lower, mat		29:30		screw nut 10-32 x 5/18"	



Distributing Mechanism	Models	29-30 Distributor Box, Lower	303
C- 471 Distributor box, lower, separating block ball	29:30	G-2615 Distributor box, lower, back plate upper rail, lower section,	29.30
D- 168 Distributor box, lower, matrix lift guide, front,		G-2676 Distributor box, lower, front plate upper rail, upper section	29.30
screw 4-48 x 1/4"	29.30	G-2676 Distributor box, lower, front plate upper rail, upper section G-2677 Distributor box, lower, back plate upper rail, upper section	29:30
D- 168 Distributor box, lower, matrix lift guide, back,		G-2677 Distributor box, lower, back place upper ran, upper section G-2694 Distributor box fastening screw flange	29-30
screw 4-45 x 1/4"		G-2792 Distributor box fastening screw mange	29-30
D- 177 Distributor box, lower, back plate upper rail, lower section	29-30	G-2799 Distributor box, lower, back plate upper rail, lower section	29:30
brace screw 4-48 x 3/16"		G-2800 Distributor box, lower, back plate upper rail, lower section	20.00
D- 177 Distributor box, lower, front plate upper rail, lower section	29-30	section, brace	29:30
brace screw 4-46 x 3/16"	29-30	G-2831 Distributor box hook	29.30
D- 657 Distributor box, lower, back plate dowel 3/32" x 1/4"	29:30	G-2891 Distributor box neek G-2891 Distributor box, lower, separating block pin 1/8" x 7/8"	29-30
D-1012 Distributor box, lower, front plate dowel 3/32" x 9/16"	29.30	G-2914 Distributor box, lower, separating block upper	29.30
D-1535 Distributor box, lower, handle set screw 8-32 x 3/16"		G-3001 Distributor box, lower, front plate lower rail	29-30
D-1535 Distributor box fastening screw flange set screw 6-32 x 3/16	5" 29-30	G-3001 Distributor box, lower, front plate lower rail	20.00
E- 98 Distributor box matrix tray screw (two	29:30	section, brace	29:30
magazine) 5/16"-24 x 7/6"	29.30	G-3003 Distributor box, lower, front plate lower rail, assembled	29.30
E- 119 Distributor box, lower, separating block, lower,	20:30	G-3013 Distributor box, lower, separating block, assembled	29 30
screw 6-46 x 1/4"	20.00	G-3014 Distributor box, lower, front plate	20.30
F- 860 Distributor box, lower, separating block ball spring	29:30	G-3014 Distributor box, lower, front plate upper rail, lower section	29.30
screw 1/4"-24 x 5/16"		G-3016 Distributor box, lower, back plate	29.30
G- 123 Distributor box, lower, front plate upper rail, upper section	29:30	G-3017 Distributor box, lower, back place	29:30
screw 6-48 x 5/82"		G-3018 Distributor box, lower, recating block	20.30
G- 123 Distributor box, lower, back plate upper rail, upper section	29:30	G-3164 Distributor box, lower, back plate lower rail	20.30
screw 6-48 x 5/32"	29:30	G-3178 Distributor box, lower, matrix lift guide, front	29:30
G- 123 Distributor box, lower, back plate screw 6-48 x 5/32"	39.30	G-3179 Distributor box, lower, matrix lift guide, back	29.30
G- 123 Distributor box, lower, front plate matrix guide	29:30	G-3186 Distributor box, lower, back plate lower rail, assembled	20:30
screw 6-48 x 5/32"	20.30	G-3209 Distributor box, lower, front plate matrix guide	29:30
G- 125 Distributor box, lower, locating block screw 6-46 x 1/2"	20.30	G-3855 Distributor box matrix tray	29:30
G- 159 Distributor box, lower, matrix lift guide, back, dowel 3/32" x 1/4"	29:30	G-3860 Distributor box matrix tray pin	29:30
	29.30	G-3871 Distributor box matrix tray pin set screw	29:30
G- 159 Distributor box, lower, matrix lift guide, front,	29-30	G-3917 Distributor box matrix tray (two magazine)	20.30
dowel 3/32" x 1/4"  G- 162 Distributor box, lower, back plate upper rail, upper section		G-4145 Distributor box hook	20:30
dowel 3/32" x .182"	29-30	H- 463 Distributor box, lower, separating block point	
dowel 3/32" x .162"		pin 3/32" x 3/4"	29-30
G- 162 Distributor box, lower, front plate upper rail, upper section dowel 3/32" x .162"	29-30	H-1255 Distributor box, lower, separating block ball spring	29.30
	29.30	1- 261 Distributor box, lower, front plate upper rail, lower section,	
G- 354 Distributor box, lower, separating block, upper, screw 6-48 x 5/16"	29-30	brace dowel 1/16" x 5/32"	.29 - 34
	29:30	1 - 261 Distributor box, lower, back plate upper rail, lower section,	
G- 354 Distributor box, lower, back plate screw 6-48 x 5/16"	29.30	brace dowel 1/16" x 5/32"	29:30
G- 698 Distributor box, lower, handle G-2578 Distributor box, lower, matrix separating block point	29:30	-,	
G-2578 Distributor box, lower, matrix separating block point G-2615 Distributor box, lower, front plate upper rail, lower section		Parts Not Illustrated	
G-2615 Distributor box, lower, front plate upper ran, lower section brace rivet	20.20	G-3012 Distributor box, lower, separating block (not assembled)	. 29-30
DIRCE HVEC	20.30		




Check Parts by Referring to Detail Pages.




BACK VIEW G-4350 MODEL 5F G-2381 MODEL 31 (30 EM) G-2863 MODEL 31 (42 EM)

Check Parts by Referring to Detail Pages.




Check Ports by Referring to Detail Pages.




BACK VIEW G-3801 MODEL 32 (30 EM) G-3802 MODEL 32 (42 EM)


Check Ports by Referring to Detail Pages.




Distribution	ng Mechanism	Models	5-3	31-3	2 Distrib	utor	3	09
	ibutor back screw shaft bracket screw 1/2"-12 x 1 3,	4" 5 31-32	G-	15	Distributor back screw bracket, r.h		5:31	-32
A- 17 Distr	ibutor beam screw, long 5, 8"-11 x 1 1/4"	32	G-		Distributor back screw bracket dowel 5/16" x 1 3/4"		5 31	1.32
	plate, small, rivet	5 31 32	G-	18	Distributor back screw bracket spring catch, lower		5 - 31	32
A- 824 Name		5.31.32	G-	50	Distributor back screw gear		31	1:32
	plate, trade mark, screw 8-32 x 1, 4"	5 31 32	G-		Distributor back screw gear pin 5, 32" x 1 5, 16"		31	1.32
	ibutor bracket support pad cover	31.32	G-	113	Distributor back screw bracket adjusting			
	plate, trade mark	5.31.32	1		screw 3/8*-16 x 13/16*		5:31	.32
6- 99 Distr	ibutor back screw bracket spring catch, lower,		G-	129	Distributor back screw shaft bracket spring catch, upp	er	5.31	1.32
	screw 8-32 x 3/8"	5:31:32	G-	130	Distributor back screw shaft bracket spring catch,			
BB-148 Distr	ibutor back screw gear guard screw 8-32 x 5/16"	5.31.32	1		upper, spring		5 31	32
	ibutor vertical adjusting screw nut 3/8"-16 x 1/2"	5 31 32	G-	131	Distributor back screw shaft bracket spring catch,			
C- 93 Distr	ibutor back screw bracket adjusting				upper, spring screw 1/4"-24 x 1/4"		5.31	1:32
	screw nut 3/8"-16 x 1/2"	5 - 31 - 32	G-	179	Distributor back screw gear time pin .120" x 9/16"		5 31	
	ibutor beam screw, long	32	G-	201	Distributor back screw shaft bracket, r.h.		5:31	-32
C- 799 Distr.	ibutor beam screw, r.h.	32	G-	204	Distributor bar, assembled		5.31	
D- 107 Distr.	ibutor bar screw washer	5.31.32	G-	205	Distributor back screw bracket, assembled		5:31	
E - 194 Distr.	ibutor vertical adjusting screw 3/8"-16 x 1 3/16"	31:32	G-	1566	Distributor back screw gear guard		31	.32
E- 304 Distr	ibutor back screw shaft bracket, r.h.,				Distributor bar screw 3/8"-16 x 2 1/4"		31	
	dowel 5-32" x 11/16"	5-31-32			Distributor side adjusting screw 3/8"-16 x 2 1/4"			. 32
E- 304 Distr	ibutor back screw shaft bracket, Lh.,		G-2	2029	Distributor back screw		31	
	dowel 5/32" x 11/16"	5-31-32	G-2	2030	Distributor back screw, assembled			
F- 463 Distr.	butor bar dowel 3/16" x 5/8"	5-31-32			Distributor side adjusting screw lug			- 32
F- 463 Distr.	ibutor bar, entrance section, dowel 3/16" x 5/8"	5-31-32	G-:	3268				32
	ibutor bar, entrance section, dowel 3/16" x 5/8"	31 - 32			Distributor back screw			32
F- 496 Distr.	butor bar, entrance section, screw 1/4"-24 x 5/16"	31 - 32			Distributor back screw, assembled			32
F- 592 Distr.	ibutor beam screw, l.h., washer 1/16" thick	31:32			Distributor back screw shaft			32
F - 593 Distr.	butor beam screw, i.h., washer 1/32" thick	31 - 32			Distributor back screw bracket, assembled			32
	butor beam screw, l.h., washer 1/64" thick	31 - 32			Distributor beam screw, r.h. 5/8"-11 x 1 5/16"		5-31	
G- 7 Distr	butor back screw shaft bracket, l.h.	5.31.32			Distributor beam screw, l.h. 5/8"-11 x 1 5/16"		5 31	
	butor bar screw 3 '8"-16 x 1 3/4"	32			Distributor beam screw, l.h., washer, variable		5.31	
	butor back screw bracket, l.h.	5.31.32			Distributor side adjusting screw nut		5.31	
	butor back screw shaft	5.31			Distributor side adjusting screw lug nut		5.31	



Distributing Mechanism	Madels	5-31-32	Distributor	311
A- 13 Distributor front screw bracket screw 1/2"-12 x 1 3/4"	5-31-32	G-1801 Distributor front screw, lower, au	tomatic spring hook5-:	31 - 32
BB-148 Distributor front screw gear guard screw 8-32 x 5/16"	5.31.32	G-1881 Distributor front screw, upper		
D- 657 Distributor front screw gear guard dowel 3/32" x 1/4"	5.31.32	G-1883 Distributor front screw, lower	. 54	
D-1012 Distributor front screw, lower, gear stop pin 3/32" x 9/16"	5 - 31 - 32	G-1947 Distributor front screw, upper, as		31
G- 48 Distributor front screw, upper, gear, small	5.31.32	G-3291 Distributor front screw, upper		32
G- 50 Distributor front screw, upper, gear, large	. 5.31.32	G-3292 Distributor front screw, upper, as		32
G- 114 Distributor clutch shaft screw	31.32	G-3293 Distributor front screw, lower		32
G- 178 Distributor front screw, upper, gear, small, rivet 1/8" x 7/	32" 5.31.32	G-3405 Distributor front screw, lower, au		32
G- 221 Distributor front screw, upper, gears, assembled		G-3566 Distributor front screw bracket, r		31 - 32
G- 228 Distributor front screw, upper, gear, small,		G-3566 Distributor front screw bracket, l.	h., guide key 5-1	31 - 32
time pin 3/32" x 9/32"	5 - 31 - 32	G-3567 Distributor front screw bracket, 1		31.32
G- 228 Distributor front screw, lower, gear, time pin 3/32" x 9/32		G-356B Distributor front screw bracket, r	h. 5-1	31 - 32
G- 532 Distributor front screw, lower, automatic		H- 56 Distributor front screw, upper, ge		
stop pin 3/32" x 15/32"	31 - 32	pin 5/32" x 15/16"		31 - 32
G- 702 Distributor front screw, lower, automatic pin 3/32" x 9/18	~ 5.31.32	H- 167 Distributor front screw, lower, au		
G- 702 Distributor front screw, upper, automatic pin 3/32" x 9/18				31 - 32
G-1524 Distributor front screw, lower, gear	5 - 31 - 32	H-1235 Distributor front screw, lower, au		
G-1525 Distributor front screw, lower, automatic	5.31.32	rivet, short 1/16" x 11/32"		31 - 32
G-1526 Distributor front screw, upper, automatic	5.31.32	I - 667 Distributor front screw bracket, r		31 - 32
G-1527 Distributor front screw, lower, automatic spring		1 - 667 Distributor front screw bracket, 1		31 - 32
G-1567 Distributor front screw gear guard			,	



Distri	buting Mechanism	Models	5-31-32	Distributor	313
B- 96	Distributor screw guard lever spring screw 4-48 x 1/4"	31	G-3998 Distributor screw guard operating link stud	d. lower	32
	Distributor belt hook	31.32	G-4118 Distributor screw guard lever		31
D- 979	Distributor screw guard lever plate screw 10-32 x 3/8"	31.32	G-4119 Distributor screw guard lever safety latch :	screw	31-32
D- 994	Distributor screw guard lever spring	31	G-4120 Distributor screw guard lever safety latch		31 - 32
D-3146	Distributor screw guard operating lever, lower,		G-4121 Distributor screw guard lever plate		31-32
	retaining washer screw 1/4"-24 x 1/2"	32	G-4122 Distributor screw guard lever, assembled		31
E- 219	Distributor screw guard lever stop screw		G-4126 Distributor screw guard lever		32
	lock screw 10-32 x 9/32"	31 - 32	G-4127 Distributor screw guard lever, assembled		32
E-3306	Distributor screw guard operating lever, lower,		G-4134 Distributor screw guard lever operating scr	rew	31:32
	retaining washer	32	G-4463 Distributor screw guard lever fulcrum scre	w	32
	Distributor screw guard lever stop screw 10-32 x 1/2"	31-32	G-4503 Distributor screw guard, auxiliary, operati	ng lever.	
	Distributor screw guard operating link stud washer	32	upper, collar	ALCOHOLD STREET	32
	Distributor screw guard lever operating screw 1/4"-24 x 7/6	" 31-32	H-1029 Distributor screw guard lever safety latch :	spring	31:32
	Distributor screw guard lever spring hook	. 31	H-3721 Distributor screw guard, operating link stu	d, upper	32
	Distributor screw guard spring hook	32	I - 114 Distributor screw guard lever plate dowel :	1/8" x 1/4"	31.32
G- 892	Distributor screw guard lever fulcrum screw	31-32	1 - 477 Distributor screw guard lever banking scre	W 1/4"-24 x 11/16"	31 - 32
G-2084	Distributor screw guard lever	31	1-2685 Distributor screw guard operating lever, lo	wer, pin	32
	Distributor belt, assembled	31:32	1-5631 Distributor screw guard operating link turn	nbuckle	
G-3398	Distributor screw guard lever operating		lock nut, r.h. 5/16"-24 x 1/2"		32
	screw nut 1/4"-24 x 3/8"	5	1-5811 Distributor screw guard operating link turn	nbuckle	
G-3810	Distributor screw guard lever, auxiliary, pad cover	5.31	lock nut, l.h. 5/167-24 x 1/27 (l.h. thres	d)	32
G-3833	Distributor screw guard operating link stud, lower	32	J- 463 Distributor screw guard operating lever, lo	wer.	
G-3834	Distributor screw guard operating link, short	32	pin nut 1/4"-24 x 3/16"		32
G-3836	Distributor screw guard operating link turnbuckle	32	J- 463 Distributor screw guard operating lever ad	justing	
	Distributor screw guard lever	32	screw nut 1/4"-24 x 3/16"		31 - 32
	Distributor screw guard, auxiliary, operating lever, lower	32	J-1228 Distributor screw guard lever, auxiliary, or	perating	
G-3994	Distributor screw guard, auxiliary, operating lever, upper	32	link screw nut 10-32 x 1/8"		31 - 32
G-3995	Distributor screw guard, auxiliary, operating lever, upper,		J-1228 Distributor screw guard lever adjusting scr	ew	
	fulcrum stud	32	lock nut 10-32 x 1/8"		31:32
	Distributor screw guard operating lever, auxiliary, link, los	ng 32			
G-3997	Distributor screw guard operating lever, auxiliary,				
	link, assembled	. 32			



Distributing Mechanism	Models 5-31-32 Distr	ibutor 3	315
3- 471 Distributor screw guard stop screw 8-32 x 7/8* 8-134 Distributor screw guard bracket dowel 1/8* x 3/8*	31 G-3811 Distributor screw guard bracket pad cover 4 G-386 Distributor screw guard bracket 5 G-386 Distributor screw guard bracket 5 G-389 Distributor screw guard bracket 5 G-389 Distributor screw guard bracket set screw 10-22 x 1 5 G-3991 Distributor screw guard bracket set screw 10-22 x 1 6 G-391 Distributor screw guard bracket set screw 10-22 x 1 7 G-481 Distributor screw guard screw hole cover 6 G-4861 Distributor screw guard screw 10-10 x 1 7 G-10 Distributor screw guard screw 10-10 x 1 7 Distributor 10-10 x 1	/187	31 · 32 32 32 32 32 32 32 32 32 31 31 31 31





Distributor


























































H 8-99

Distributing Mechanism	Aodels	31-32	Distributor 317
8- 99 Distributor screw guard lever operating lever, upper, screw 8-32 x 3/8"	31-32	G-4625 Distributor screw guard lever operatin G-4626 Distributor screw guard lever link side	support 31-32
B- 236 Distributor screw guard operating lever adjusting screw 1/4"-24 x 1 1/4"		G-4627 Distributor screw guard, auxiliary, ope G-4628 Distributor screw guard lever operatin	rating lever, lower 32
88-148 Distributor screw guard lever link side support screw 8-32 x 5/16".	- 1	G-4629 Distributor screw guard lever link top G-4630 Distributor screw guard lever link spri	support
D- 802 Distributor screw guard lever link top support screw nut 8-32 x 1/8"		G-4631 Distributor screw guard operating leve G-4632 Distributor screw guard lever link	r, lower 32
D-1012 Distributor screw guard lever operating lever, upper, shoe dowel 3/32" x 9/16"		G-4633 Distributor screw guard, auxiliary, ope G-4634 Distributor screw guard lever operatin	rating link 32
E-2592 Distributor screw guard lever adjusting screw 10-32 x 31/32" F-5529 Distributor screw guard lever link screw, upper	31 - 32	upper, assembled H-1029 Distributor screw guard lever safety la	31:32
G- 139 Distributor screw guard lever link spring hook G- 781 Distributor screw guard lever link screw, lower	32 31 32	<ul> <li>1 - 186 Distributor screw guard lever link side</li> </ul>	support
G-2790 Distributor screw guard lever link spring eye G-3800 Distributor screw guard, auxiliary, operating link screw	32	nut 3/8"-16 x 1/4" I - 665 Distributor screw guard lever operatin	g lever, upper,
G-4622 Distributor screw guard lever operating lever, upper, stud	32 31·32	shoe screw 8-32 x 5/8" I - 681 Distributor screw guard lever link top	support
G-4623 Distributor screw guard lever operating lever, lower G-4624 Distributor screw guard lever operating lever, upper	31 - 32	screw 8-32 x 11/16"	







J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, lower set, pin
J - 995 Distributor back screw gear, lower set, pin
J - 3614 Distributor back screw gear, lower set, pin
J - 3614 Distributor back screw gear, lower set, pin
J - 3614 Distributor back screw gear, lower set, pin
J - 3615 Distributor back screw gear, lower set, pin
J - 3615 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distributor back screw gear, upper set, pin
J - 995 Distr Parts Not Illustrated

26 G-3334 Distributor beam and cap, assembled 
 26
 G-3334
 Distributor beam and cap, assembled
 3

 G-3912
 Distributor beam and cap, assembled
 29

 29
 G-4795
 Distributor beam and cap, assembled
 29

 29-30
 G-4813
 Distributor beam and cap, assembled
 8

29

29 . 30


G-3445 Distributor bar, lower, assembled (90 character)

G-3597 Distributor bar, lower, assembled (72 character)
G-3600 Distributor bar, lower, assembled (72 character)


G-3911 Distributor beam side adjusting screw bracket screw 5/16"-24 x 7/8" G-3923 Distributor box, upper, matrix pusher stud, assembled G-3924 Distributor box, upper, matrix pusher block

G-3769 Distributor bar, main section and entrance section. cover plate

G-3909 Distributor beam side adjusting screw bracket .



Distrib	outing	Mechanist	m	Models	29-30		Distributor	323
A- 112	Dietribu	or screw from	t, gear guard, r.h., upper set,		G-3276	Distributor screw idler gear, intermediate	, assembled	29-30
	SCI	ew 8-32 x 3/8"		29:30	G-3277	Distributor screw idler gear, lower, assem	bled	29-30
A- 112	Distribu	or screw, fron	t, gear guard, lower, screw 8-	32 x 3/8"29·30	G-3278	Distributor screw idler gear, upper, assen	ibled	29:30
A- 112	Distribu	tor screw, back	c, gear guard, lower set,		G-3341	Distributor front screw, upper, upper set		30
	SCI	ew 8-32 x 3/8"		29:30	G-3342	Distributor front screw, upper, upper set,	assembled	. 30
D-1012	Distribu	for front screw	, lower, gear stop pin 3/32" x	9/18" 29:30	G-3343	Distributor front screw, upper, lower set Distributor front screw, upper, lower set,	assembled	30
D-1535	Distribu	or screw auto	matic set screw 8-32 x 3/18"	29-30	6-3344	Distributor front screw, upper, lower set, Distributor front screw, lower, upper set	assembled	30
D-1890	Distribu	for screw idler	gear, intermediate, stud was	her 29·30	G-3349	Distributor front screw, lower, upper set		
D-1890	Distribu	ter front screw	intermediate gear stud wash	1er, 29·30		Distributor front screw, lower, automatic		30
	up	per set	and the state of the state of	29:30	G 3564	Distributor screw idler gear, lower, upper	and intermediate	
D-1890	Distribu	tor screw idler	gear, lower, stud washer gear, upper, stud washer	29 30	0-3304	stud 3/8"-32	and intermediate,	29 - 30
D-1890	Distribu	for screw idler	gear, lower, upper and inter	mediate	G-3564	Distributor front screw intermediate gear	stud.	
E- 229	Distribu	d nut 3/8"-32 x	gear, lower, upper and inter-	29-30		upper set 3/8"-32		29:30
F. 520			intermediate gear stud nut,		G-3635	Distributor front screw, upper, gear, small	l. lower set.	
2- 555		per set 3/8"-32		29-30		pin (oversize) .182" x 15/16"		29 - 30
G- 228	Dietribu	or front screw	, lower, gear pin 3/32" x 9/32"		G-3635	Distributor front screw, upper, gear, small	ll, upper set,	
G- 532	Distribu	for front screw	, lower, automatic			pin (oversize) .162" x 15/18"		29:30
	stc	p pin 3/32" x 1	6/32"	29 - 30	G-3637	Distributor front screw, upper, gear, larg-	e, lower set,	
G- 702	Distribu	front screw	, lower, automatic pin 3/32" x	K 9/16" 29:30		pin (oversize) .130" x 1 5/18"		29 - 30
G- 702	Distribu	tor front screw	v, upper, automatic pin 3/32" >	x 9/16" 29·30	G-3637	Distributor front screw, upper, gear, larg-	e, upper set,	
G-1525	Distribu	tor front screw	, lower, automatic, upper set	29 - 30		pin (oversize) .130" x 1 5/16"	4.17 9.1	29 - 30
G-1525	Distribu	tor front screw	, lower, automatic, lower set	29 30	G-3999	Distributor screw idler gear, lower, upper	and intermediate,	
G-1526	Distribu	tor front screw	, upper, automatic, upper set	29 - 30		stud nut lock washer	and a comment	29.30
G-1526	Distribu	tor front screw	v, upper, automatic, lower set	29:30	G-3999	Distributor front screw intermediate gear nut lock washer	stud, upper set,	29:30
G-1527	Distribu	tor front screw	, lower, automatic spring	29	C 4043	Distributor front screw, lower, upper set		20.30
G-1801	Distribu	tor front screw	r, lower, automatic, upper set	29.30	6-4043	Distributor front screw, lower, upper set		29
	sp	ing hook			G-4044	Distributor front screw, upper, upper set	perembled	20
G-1801	Distribu		v, lower, automatic, lower set,	29:30	6-4096	Distributor screw, back, gear guard, lowe	r set	30
	Distribus	ing nook	, upper, lower set	20.00	G-4087	Distributor screw, front, gear guard, r.h.,	upper set	29:30
6-3028	Distribu	tor front screw	, lower, lower set	20	G-4375	Distributor screw, back, gear guard, lowe		20
			, upper, gear, small, upper se		G-4397	Distributor screw, front, gear guard, r.h.,	upper set	29
G-3037	Dietribo	tor front screw	, upper, gear, small, lower se		H- 56	Distributor front screw, upper, gear, sma	II, upper set,	
G-3038	Distribu	tor front screw	v, upper, gear, large, upper se	t 29:30		pin 5/32" x 15/18"		29:30
G-3038	Distribu	tor front screw	, upper, gear, large, lower set	t 29.30	H- 56	Distributor front screw, upper, gear, small	II, lower set,	
G-3043	Distribu	tor front screw	, lower, gear, upper set	29:30		pin 5/32" x 15/16"		29:30
G-3043	Distribu	tor front screw	r, lower, gear, lower set	29.30	H-1235	Distributor front screw, lower, automatic	, upper set,	
G-3131	Distribu	tor front screw	r, upper, lower set, assembled	20		spring hook rivet, short 1/16" x 11/3	2"	29:30
G-3162	Distribu	tor screw, back	k, gear guard, lower set,		H-1235	Distributor front screw, lower, automatic	, lower set,	
		wel 1/18" x .395		29.30		spring hook rivet, short 1/16" x 11/3	lower set	29.30
G-3203	Distribu	tor screw, fron	it, gear guard, r.h., upper set	29.30	J- 136	Distributor front screw, lower, automatic	, lower set,	29:30
G-3204	Distribu	tor screw, fron	it, gear guard, lower	29·30 29·30	1 120	spring hook rivet, long 1/16" x 1/2" Distributor front screw, lower, automatic	upper set	89.30
G-3205	Distribu	tor screw, back	k, gear guard, lower set	29.30	J- 136	spring hook rivet, long 1/16" x 1/2"	tabber sett	29:30
6-3237	Distribu	tor screw idler	gear, upper, bushing v intermediate gear, upper set		1- 247	Distributor screw gear time pin 1/16" x 3/	8"	20.30
0-3274	Distribu	tor scrow idlor	gear, intermediate, bushing	29-30	1. 995	Distributor front screw, upper, gear, larg	e. lower set.	2.00
6 3274	Distribu	tor serew idler	gear, lower, bushing	29.30	. 333	pin 1/8" x 1 5/16"	-,	29 - 30
			v intermediate gear,	20.00	J- 995	Distributor front screw, upper, gear, larg	e, upper set,	
0.3213	Distribu	ner set assemb	pled	29:30		pin 1/8" x 1 5/16"		29 - 30
	up	per set, assemb	bled	29:30		pin 1/8" x 1 5/16"		29



Distributing Mechanism	Models	29-30	Distributor	325
B- 217 Distributor screw guard operating link lever spring eye	screw 30	G-4084 Distributor screw guard oper	ating link, assembled	30
B- 614 Distributor screw guard connecting link stud washer	29-30	G-435B Distributor screw guard open	ating link spring	29.30
8- 614 Distributor screw guard operating link stud washer	29.30	G-4359 Distributor screw guard open	ating link, long	29:30
C- 535 Distributor screw guard operating lever, lower, spring collar screw 10-32 x 3/6"	20	G-4372 Distributor screw guard oper G-4401 Distributor screw guard oper	ating link, assembled	29:30
D- 331 Distributor screw guard operating lever, lower, back.		G-4426 Distributor screw guard open	eting link oping	29.30
bracket dowel 1/6" x 9/16"	80	G-4440 Distributor screw guard leve	ading mix, lower	29.30
D- 802 Distributor screw guard operating link lever spring eve	30	G-4514 Distributor screw guard leve	r, auxiliary	29:30
screw nut	30	G-4519 Distributor screw guard leve	operating screw	
D-5445 Distributor screw guard lever, auxiliary, operating		G-4520 Distributor screw guard leve	r, auxiliary, operating piece, fron	it 30
piece screw	30	G-4521 Distributor screw guard neve	r, auxiliary, operating piece, back	1 30
E- 84 Distributor screw guard operating lever, lower, front, pi		G-4522 Distributor screw guard oper	ating link collar	
E- 523 Distributor screw guard operating lever, lower, front, pr	n 30	G-4522 Distributor screw guard oper	ating link, upper	29.30
link connecting stud stop washer	30	G-4524 Distributor screw guard oper	ating link, assembled	
E-3752 Distributor screw guard operating lever link spring	30	G-4601 Distributor screw guard oper	ating link spring	29
F- 64 Distributor screw guard operating lever, lower, back.	30	G-4602 Distributor screw guard oper	ating link spring eye	30
bracket screw 1/4"-24 x 23/32"		G-4603 Distributor screw guard oper	ating link lever spring eye	
		G-4604 Distributor screw guard oper	ating link lever spring	30
G- 126 Distributor screw guard lever operating screw	- 29	I - 477 Distributor screw guard leve		
G- 139 Distributor screw guard operating lever link spring hool		1-5605 Distributor screw guard oper		
G- 892 Distributor screw guard lever fulcrum screw	29	1-5606 Distributor screw guard oper		
G- 955 Distributor screw guard operating link, lower, stud	29-30	1-5614 Distributor screw guard open		
G-2790 Distributor screw guard operating link spring eye	29 - 30	I-5617 Distributor screw guard oper		
G-3833 Distributor screw guard operating lever, lower, front,		1-5622 Distributor screw guard oper		30
link connecting stud	. 30	I -5623 Distributor screw guard oper		
G-3833 Distributor screw guard operating link stud	29 - 30	fulcrum stud		
G-3833 Distributor screw guard operating lever, lower, back,		1-5628 Distributor screw guard oper		30
link connecting stud	. 30	1-5631 Distributor screw guard oper		
G-3834 Distributor screw guard operating link, short			L 5/16"-24 x 1/2"	. 30
G-3835 Distributor screw guard operating link, long	30	1-5631 Distributor screw guard oper		
G-3836 Distributor screw guard operating link turnbuckle	30		. 5/16"-24 x 1/2"	30
G-3836 Distributor screw guard operating lever, lower,		1-5642 Distributor screw guard open		
link turnbuckle		link, assembled		30
G-3837 Distributor screw guard operating link, assembled	30	I-5811 Distributor screw guard oper	ating lever, lower, link	

G-4083 Distributor screw guard operating link, long 30 J-1228 Distributor screw guard operating link stud nut 10-32 x 8/16\* 30

Please Give Model and Seriel Number When Ordering

link connecting stud nut 30 1-5958 Distributor screw guard operating link collar dowel G-3963 Distributor screw guard lever 29 J- 223 Distributor screw guard operating link collar screw

turnbuckle lock nut, l.h. 5/16"-24 x 1/2" l.h. thds.

G-3869 Distributor screw guard operating lever, lower, back,




































D-168



Distrit	outing Mechanism	Models	29-30	Distributor	327
B- 209 C- 42	Distributor box chute matrix guide collar set screw 1/4"-24 x 5/16" Distributor screw bearing, r.h., lower set, screw 3/8"-18 x ? Distributor screw, front, bearing, r.h., upper set,	29·30 1/6" 29·30	G-1370 G-3034 G-3035	Distributor box chute matrix guide detent spring Distributor screw bearing, r.h., lower set, oil tube Distributor screw, front, bearing, l.h., upper set Distributor screw hearing, l.h., lower set, front Distributor box chute matrix guide detent	29 30 29 30 29 29 30 29 30
D- 168 D- 572	screw 3/8"-18 x 7/8" Distributor box chute matrix deflector screw 4-48 x 1/4" Distributor screw, front, bearing, l.h., lower set,	29:30	G-3091 G-3092 G-3322	Distributor box chute matrix guide detent screw 8-32 x 1" Distributor box chute matrix guide collar Distributor box chute matrix deflector	29·30 29·30 29·30
	dowel 3/16" x 13/16" Distributor screw, front, bearing, r.h., upper set, dowel 3/16" x 13/18"	29-30	G-3351 G-3566	Distributor screw, front, bearing, l.h., upper set Distributor screw bearing, r.h., guide key, lower set Distributor screw, front, bearing, r.h., guide key, upper set	20·30 20·30 20·30
D- 572	Distributor screw bearing, r.h., lower set, dowel 3/16" x 13. Distributor screw, front, bearing, l.h., upper set, dowel 3/16" x 13/16"	29:30	G-3569 G-3570	Distributor screw, front, bearing, r.h., upper set Distributor screw bearing, r.h., upper set Distributor screw, front, bearing, r.h., upper set	29-30
	Distributor screw, front, bearing, l.h., screw, upper set 5/16°-18 x 11/16° Distributor screw, front, bearing, l.h., screw, lower	29:30		(electromatic safety) Distributor screw, front, bearing, l.h., upper set (electromatic safety)	29-30
G- 240	Distributor screw, front, bearing, l.h., upper set, dowel Distributor screw, front, bearing, l.h., lower set, dowel	29·30 29·30	G-4650	Distributor screw, bearing, r.h., lower set (electromatic safety Distributor screw, bearing, l.h., lower set, front (electromatic safety)	29:30
G-1107	Distributor screw, front, bearing, l.h., key, upper set Distributor screw, front, bearing, l.h., key, lower set	29.30	G-4683	Distributor box safety switch bracket (electromatic safety)	29:30



Distributing Mechanism	Models	29-30 Distributor	329
B- 614 Distributor screw guard connecting link stud washer	29.30	G-3833 Distributor screw guard connecting link stud	29:30
C- 42 Distributor screw guard, lower, bracket, r.h.,		G-3838 Distributor screw guard, lower, assembled	30
screw 3/8"-16 x 7/8"	29	G-3851 Distributor screw guard, lower, stop screw 10-32 x 15/16"	29:30
C- 476 Distributor belt hook	29 30	G-3893 Distributor screw guard, lower	29
D- 145 Distributor screw guard bracket dowel 1/8" x 5,8"	29 30	G-3901 Distributor screw guard, lower, shaft	29
D- 401 Distributor screw guard, upper, dowel 1/8" x 7/16"	29 30	G-3902 Distributor screw guard, upper, assembled	29
D- 401 Distributor screw guard, lower, dowel 1/8" x 7/16"	29:30	G-3903 Distributor screw guard, lower, assembled	29
E- 25 Distributor screw guard, upper, shaft collar set		G-3936 Distributor screw guard, upper, shaft	29
screw 8-32 x 1/4"	29	G-3948 Distributor screw guard, upper, l.h., end piece	29-30
E- 25 Distributor screw guard, lower, shaft collar set		G-3949 Distributor screw guard, upper	30
screw 8-32 x 1/4"	29	G-3950 Distributor screw guard, upper	29
E- 370 Distributor screw guard, upper, l.h., end piece bracket		G-3951 Distributor screw guard, upper, l.h., end piece bracket	29
screw 3/8"=16 x 3/4"	30	G-3952 Distributor screw guard, upper, l.h., end piece bracket	
E- 370 Distributor screw guard bracket screw 3/8"-16 x 3/4"	29:30	screw washer	29
E- 371 Distributor screw guard, upper, l.h., end piece bracket		G-3955 Distributor screw guard, lower, bracket, r.h.	20
screw 3, 8"=10 x 1/2"	29	G-3962 Distributor screw guard, lower, arm, r.h.	. 29
E-2592 Distributor screw guard lever adjusting screw 10-32 x 31/32	1" 29	G-3964 Distributor screw guard, lower, arm, r.h., spring	20
G- 118 Distributor screw guard, upper, l.h., end piece		G-4362 Distributor screw guard, lower, arm, r.h.	29
screw 6-48 x 5/16"	29.30	G-4373 Distributor screw guard, lower, assembled	29
G- 939 Distributor screw guard, lower, arm, r.h., spring eye	20	G-4394 Distributor screw guard, upper, arm, center	29 30
G-2465 Distributor belt, assembled	29-30	G-4439 Distributor screw guard, lower, bracket, intermediate	30
G-2556 Distributor screw guard, upper, spring	30	G-4516 Distributor screw guard, lower, assembled	30
G-2790 Distributor screw guard, upper, spring eye	30	G-4665 Distributor screw guard bracket, center	29:30
G-3047 Distributor screw guard, upper, l.h., end piece bracket	30	G-4800 Distributor screw guard, upper	20
G-3048 Distributor screw guard bracket, r.h.	20	G-4801 Distributor screw guard, upper, assembled	20
G-3398 Distributor screw guard, lower and upper, connecting		G-4802 Distributor screw guard, lower	20
link turnbuckle lock nut 1/4"-24 x 3/8"	29 30	G-4803 Distributor screw guard, lower, assembled	29
G-3820 Distributor screw guard, lower	30	G-4804 Distributor screw guard, bracket, l.h.	29.30
G-3821 Distributor screw guard, lower, arm, center	30	G-4805 Distributor screw guard, upper	30
G-3824 Distributor screw guard, lower, arm	30	G-4806 Distributor screw guard, upper, assembled	30
G-3824 Distributor screw guard, upper, arm	29.30	G-4807 Distributor screw guard, lower	30
G-3824 Distributor screw guard, lower, arm, l.h.	29	G-4808 Distributor screw guard, lower, assembled	. 30
G-3825 Distributor screw guard, lower, bracket	30	H- 387 Distributor screw guard, lower, arm pin 3/16" x 7/8"	29.30
G-3825 Distributor screw guard, upper, bracket	29.30	H- 387 Distributor serew guard, upper, shaft collar pin 3/16" x 7/8"	29
G-3825 Distributor screw guard, lower, bracket, l.h. and center	29	H- 387 Distributor screw guard, upper, arm pin 3/16" x 7/8"	29.30
G-3826 Distributor screw guard, lower, shaft	30	H- 387 Distributor screw guard, lower, shaft collar pin 3/16" x 7/8"	29
G-3826 Distributor screw guard, upper, shaft	30	<ul> <li>1 - 567 Distributor screw guard, lower, stop screw 10-32 x 7/8"</li> </ul>	29
G-3827 Distributor screw guard, lower, shaft collar	29	I-1027 Distributor screw guard, upper, spring	30
G-3827 Distributor screw guard, upper, shaft collar	29	J- 223 Distributor screw guard, lower, screw 10-32 x 5/16"	29:30

30 J- 223 Distributor screw guard, upper, screw 10-32 x 5, 16"

29-30 J-1228 Distributor screw guard lever adjusting screw lock nut 10-32 x 5/16"

29:30 J-1228 Distributor screw guard, lower, stop screw nut 10:32 x 5/16"

29-30 J-1228 Distributor screw guard connecting link stud nut 10-32 x 5/16" 29-30

29:30

20:30

G-3829 Distributor screw guard, upper, connecting link

G-3830 Distributor screw guard, lower, connecting link

link turnbuckle G-3832 Distributor screw guard connecting link, assembled

G-3831 Distributor screw guard, lower and upper, connecting




Distributing	Machanism	


## Models 5-29-30-31-32

## Distributor Clutch 331


A- 13 Distributor clutch bracket screw 1/2"-12 x 1 3/4"	5 · 29 · 30 · 31 · 32		ating spring	29-	30
A- 132 Distributor clutch starting lever flange set		G- 429 Distributor clutch lever scre	w	. 5.29	30 - 31 - 32
screw 1/4"-24 x 7/16"		G-1538 Distributor clutch lever		. 5	31 - 32
B- 236 Distributor clutch lever adjusting screw 1/4"-24 x	1 1/4" 20	G-1540 Distributor clutch lever hing	e pin		31-32
BB-138 Distributor clutch flange spring washer		G-1938 Distributor clutch bracket be	earing cap, small	20	30
screw 8-32 x 1/2"	5 - 29 - 30 - 31 - 32	G-2259 Distributor clutch starting le	ver flange	5.29	30-31-35
D- 142 Distributor clutch lever adjusting screw bracket		G-2260 Distributor clutch bracket			31 - 32
SCTeW 1/4"-24 x 5/8"	29:30	G-2790 Distributor clutch actuating	spring eve	29:	30
G- 32 Distributor clutch flange spring	5-29-30-31-32	G-3133 Distributor clutch bracket be	earing cap, large	20	
G- 33 Distributor clutch flange spring washer	5 - 29 - 30 - 31 - 32	G-3333 Distributor clutch bracket be	earing cap, large		30
G- 58 Distributor clutch lever actuating spring .	5 31-32	G-3362 Distributor clutch lever .		29-	30
G- 111 Distributor clutch lever hinge pin set		G-3363 Distributor clutch lever hing	e pin		30
screw 3/8"-18 x 7/16"	5 31-32	G-3558 Distributor clutch lever hing	e pin	29	
G- 240 Distributor clutch bracket dowal 3/16" x 3/4"	5 31 32	G-3629 Distributor clutch lever actu	ating spring stud	20-1	30
G- 304 Distributor clutch bracket bearing cap, large.		G-4085 Distributor clutch lever adju			30
screw 1/4"-24 x 1/2"	29-30	J-1086 Distributor clutch lever hing			
G- 304 Distributor clutch bracket bearing cap, small,		screw 10-32 x 7/16"		29 -	30
screw 1/4"-24 x 1/2"	29.30				




A- 132 Distributor clutch flange collar set		G-1934 Distributor clutch shaft collar, l.h., pin 5/32" x .836" 29-30
screw 1/4"-24 x 7/16"	5 29 30 31 32	G-2001 Distributor clutch flange, assembled 5-29-30-31-32
C- 147 Distributor clutch flange key pin 3/32" x 11/16"	5 - 29 - 30 - 31 - 32	G-2199 Distributor clutch spring collar 5-29-30-31-33
C- 231 Distributor clutch pulley washer screw 8-32 x 5/16"	5 - 29 - 30 - 31 - 32	G-2379 Distributor belt, assembled
C- 476 Distributor belt hook	5 - 29 - 30 - 31 - 32	G-2380 Distributor clutch pulley 5-29-30-31-32
E- 424 Distributor clutch flange spring adjusting knob		G-2465 Distributor belt, assembled . 29-30
screw 1/4"+24 x 13/64"	29.30	G-2748 Distributor clutch pulley washer 29-30
F- 97 Distributor clutch flange collar screw 8-32 x 3/8"	5-29-30-31-32	G-2802 Distributor clutch spring hook 5-29-30-31-3:
G- 34 Distributor clutch flange key	5-29-30-31-32	G-2949 Distributor clutch shaft collar 5-29-30-31-3
G- 36 Distributor clutch shaft gear	5 31.32	G-3078 Distributor clutch shaft washer 5 31-3:
G- 114 Distributor clutch shaft screw	5 31 32	G-3079 Distributor clutch shaft 5 31-32
G- 274 Distributor clutch spring collar screw 8-32 x 3/8"	5 - 29 - 30 - 31 - 32	G-3081 Distributor clutch shaft, assembled 5 31-32
G- 282 Distributor clutch shaft washer screw 10-28 x 3/8"	5 31-32	G-3357 Distributor clutch shaft 29-30
G- 354 Distributor clutch stop, l.h., screw 8-48 x 5/18*	5-29-30-31-32	G-3358 Distributor clutch shaft, assembled 29-30
G- 394 Distributor clutch pulley washer	5 31.32	G-3574 Distributor clutch pulley screw 5-29-30-31-3:
G- 702 Distributor clutch shaft collar pin 3/32" x 9/16"	5 31-32	G-3592 Distributor clutch balancing spring 5-29-30-31-33
G- 702 Distributor clutch shaft collar, r.h., pin 3/32" x 9/16"	29:30	G-3593 Distributor clutch pulley washer flange 5 31-3:
G- 955 Distributor clutch pulley washer flange		G-4062 Distributor clutch pulley washer flange 29-30
banking screw	5-29-30-31-32	G-4488 Distributor clutch flange spring adjusting knob 29-30
G-1061 Distributor clutch flauge collar	5 - 29 - 30 - 31 - 32	G-4489 Distributor clutch flange spring adjusting knob shoe 29-30
G-1547 Distributor clutch stop, r.h.	5 - 29 - 30 - 31 - 32	G-4490 Distributor clutch flange spring adjusting bushing 29-30
G-1548 Distributor clutch stop, l.h.	5 - 29 - 30	G-4491 Distributor clutch flange spring 29-30
G-1549 Distributor clutch friction collar stop	0 80 00	G-4492 Distributor clutch shaft 29-30
screw 10-92 x 7/18"	29-30-31-32	G-4496 Distributor clutch shaft, assembled 29-30
G-1549 Distributor clutch pulley washer flange stop	20.00.01.02	H- 56 Distributor clutch shaft gear pin 5/32" x 15/16" 5 31-32
screw 10-32 x 7/16*	5 31-32	I-1027 Distributor clutch spring 5-29-30-31-32
G-1604 Distributor clutch shaft collar, l.h.	29.30	J- 794 Distributor clutch stop, r.h., screw 4-48 x 3/8" 5-29-30-31-32
G-1636 Distributor clutch shaft collar, r.h.		
G-1933 Distributor clutch shaft collar, r.h., pin 5/32" x .710"	29:30	J-1784 Distributor clutch spring screw 5-29-30-31-32
3-1933 Distributor cruteri snart conar, r.n., pm 8/82- x .710-	39.30	



Distril	buting Mechanism	Models	5-31-32	Channel Entrance 335
8- 471	Channel entrance frame hinge bracket adjusting		1-5877 Channel entrance frame h	inge bracket screw washer 5-31-32
	screw 8-32 x 7/8"	31.32	1-5897 Channel entrance frame hi	inge bracket, l.h. 5-31-32
	Channel entrance handle screw 8-32 x 5/16"	5.31.32	1-5925 Channel entrance frame h	inge bracket adjusting screw
D- 802	Channel entrance frame hinge bracket adjusting		bracket screw	
	screw lock nut 8-32 x 5/16"		1-5931 Channel entrance frame h	inge bracket screw 1/4"-24 x 15/32" 5:31:32
	Channel entrance partition locking bar screw 8-32 x 13/16	5.31.32	1-6149 Channel entrance frame h	inge bracket, r.h. 32
	Channel entrance frame hinge bracket adjusting screw	5	1-6161 Channel entrance partition	locking strip
	Channel entrance adjusting screw	5.31.32	1-6162 Channel entrance partition	plate . 5
	Channel entrance hinge pin set screw 8-32 x 5/16"	5-31-32	1-6163 Channel entrance frame	
	Channel entrance frame hinge pin set screw	5	I-6167 Channel entrance, assembl	ed 31
1 - 628	Channel entrance partition locking rod, 22 31/32" long	5-31-32	1-6168 Channel entrance, assembl	ed 32
	Channel entrance partition locking bar	5.31.32	I-6730 Matrix guard	5.31.32
1-1322	Channel entrance adjusting screw 1/4"-24 x 1 1/8"	5.31.32	1-6735 Channel entrance, assembl	ed . 32
I-1636	Channel entrance handle	5-31-32	1-6736 Channel entrance, assembl	ed 5-31
1-3270	Channel entrance partition locking strip	31.32	1-8020 Channel entrance bracket,	r.h., assembled 31-32
1-3273	Matrix guard	31 - 32		l.h., assembled 31-32
1-3274	Channel entrance partition plate	31.32	J- 463 Channel entrance adjustin	g screw nut 1/4"-24 x 3/8" 5:31-32
1-3275	Channel entrance frame	31.32		
1-3277	Channel entrance, assembled	31	Parts N	fot Illustrated
1-3278	Channel entrance, assembled	32	1-5864 Channel entrance bracket.	r.h. 31·32
1-3335		5-31-32	1-5865 Channel entrance bracket.	I.h. 31-32
1-5824	Channel entrance frame hinge bracket, r.h.	5.31	1-5932 Channel entrance bracket.	r.h., assembled 31-32
1-5869	Channel entrance frame hinge pin	5.31	1-5935 Channel entrance bracket.	I.h., assembled
1-5869	Channel entrance frame hinge pin, l.h.	32	1-7339 Channel entrance bracket.	r.h
1-5970	Channel entrance frame hinge pin, r.h.		1-7340 Channel entrance bracket,	



Distributing Mechanism N	odels	29-30	Channel	Entrance	337
8-213 Channel entrance frame throwout lever lock stud, lower	30	1-7580 Char	anel entrance frame throwout lever link		
- 297 Channel entrance frame throwout lever lock			operating lever, front, clevis stud		30
support nut 5/18"-18 x 1/4"	30	1-7581 Char	anel entrance frame throwout lever link		
- 840 Channel entrance frame throwout lever link			operating lever, front, clevis		. 30
operating lever, front, clevis screw	30	1-7582 Chan	anel entrance frame throwout lever link		
- 991 Channel entrance frame throwout lever link,			operating lever, front, link, r.h.		30
front, clevis stud screw	30	1-7583 Chan	anel entrance frame throwout lever link		
-1401 Distributor screw guard safety stop screw 8-32 x 9/18"	29 - 30				30
- 168 Distributor screw guard safety stop dowel 1/8" x 1/2"	29 - 30	1-7623 Chan	anel entrance frame throwout lever link le	ver	30
<ul> <li>584 Channel entrance frame throwout lever, r.h.,</li> </ul>			anel entrance, upper, throwout lever, l.h., a		29.30
adjusting screw 1/4"-24 x 19/32"	29.30	1-7827 Chan	anel entrance, upper, throwout lever link, !	l.h.	29.30
-2438 Distributor screw guard lever operating screw lock washer	29:30		anel entrance frame throwout lever link st		29 - 30
- 139 Channel entrance frame throwout lever link spring hook	29.30	1-7838 Chan	mel entrance frame throwout lever, r.h., st	and	29 - 30
- 183 Channel entrance frame throwout lever link spring	29	1-7839 Chan	anel entrance frame throwout lever, r.h.		29
- 397 Channel entrance frame shoe dowel 1/8" x 11/32"	29 - 30	1-7840 Chan	anel entrance frame throwout lever, r.h.		30
<ul> <li>781 Channel entrance, upper, throwout lever link, l.h., stud, lower</li> </ul>	29 - 30	1-7841 Chan	anel entrance frame throwout lever, r.h., as	ssembled	29
-2318 Channel entrance frame throwout lever screw 1/4"-24 x 1/2"	29 - 30	1-7842 Chan	anel entrance frame throwout lever, r.h., as	ssembled	30
-3398 Channel entrance frame throwout lever, r.h.,		1-7844 Chan	anel entrance frame throwout lever link		29
adjusting screw nut 1/4"-24 x 1/8"	29:30	1-7845 Chan	inel entrance frame throwout lever link, a	ssembled	29
-3398 Channel entrance, upper, throwout lever, l.h.,		1-7848 Chan	anel entrance frame throwout lever link		30
adjusting screw nut 1/4"-24 x 1/8"	29:30	1-7849 Chan	anel entrance frame throwout lever link, as	ssembled	30
-3398 Distributor screw guard lever operating		1-7851 Chan	inel entrance, upper, throwout lever, l.h., l	ink	29 - 30
screw nut 1/4"-24 x 1/8"	29:30	1-8039 Chan			29
-4601 Distributor screw guard operating link spring	29	1-8045 Chan	anel entrance frame throwout lever link su	pport	30
-4635 Distributor screw guard safety stop	20 - 30	1-8046 Chan	anel entrance frame throwout lever link su	pport stud	. 30
- 177 Channel entrance frame throwout lever link			inel entrance frame throwout lever link		30
stud set screw 8-32 x 1/4"	20	1-8053 Chan	anel entrance frame throwout lever link, as	ssembled	20
- 177 Channel entrance frame throwout lever link		1-8054 Chan	anel entrance frame throwout lever link, as	ssembled	30
stud, upper set screw 8-32 x 1/4"	30	J- 463 Chan	anel entrance frame throwout lever link		
- 570 Channel entrance throwout lever link stud	29.30		support stud nut 1/4"-24 x 3/16"		30
-7424 Channel entrance, upper, throwout lever, l.h.	29:30	J-1218 Chan	mel entrance frame throwout lever stud pi	in .	
-7425 Channel entrance, upper, throwout lever, l.h.	29.30	J-5498 Chan	nel entrance frame throwout lever link		
-7461 Channel entrance frame throwout lever link stud, lower	29		operating lever, front, clevis stud screw le	ock washer	. 30




Distributing Mechanism	Madels	5-31-3	2 CF	nannel	Entrance	339
B- 217 Channel entrance buffer screw 8-32	× 1/4" 5-31-32	1-1645	Channel entrance spring			32
B- 236 Distributor clutch lever adjusting so	rew 1/4"-24 x 1 1/4" 5-31-32	1-2066	Channel entrance frame extension			31.32
B- 237 Distributor clutch lever adjusting sc	rew nut 1/4"-24 x 1/2" 5-31-32	1-2689	Channel entrance buffer			5-31-32
88-148 Distributor clutch lever adjusting so	rew bracket		Channel entrance partition crimped (I			31.32
screw 8-32 x 5/16"	5.31.32	1-3272	Channel entrance partition lug (Nos. 3	10-33 and	61-92)	31-32
D- 131 Channel entrance bracket, r.h., scre-		1-3294	Channel entrance locating block			5-31-32
D- 131 Channel entrance bracket, l.h., screv	V 3/8"-16 x 1 1/8" 31-32	1-5248	Channel entrance spring screw			5.31.32
D- 396 Distributor clutch lever adjusting so	rew bracket	r-5986	Channel entrance partition lug, assemi	bled (No	8 15-16)	31.32
dowel .068" x 1/4"	5-31-32	1-6161	Channel entrance partition locking str	in		5.31.32
D- 532 Channel entrance spring stud		1-6162	Channel entrance partition plate			5.31.32
D- 714 Channel entrance latch pin 3/32" x 1	/2" . 5-31-32	1-6164	Channel entrance partition crimped (2	Voc 1-14	10-90 34-60)	. 31.32
D-1377 Channel entrance latch screw	5:31:32	1-6165	Channel entrance partition lug (Nos. 3	0.33.61.9	2)	31 - 32
F- 235 Channel entrance spring hook	5.31.32	1-6166	Channel entrance partition plate screv	v	-/	31:32
F-2438 Distributor screw guard lever opera	ting screw lock washer 5:31:32	1-6176	Channel entrance partition lug, assemi	bled (No	0 15 16 17 10	
G- 11B Channel entrance frame extension s	crew 6-48 x 5/16" 31-32	1-6731	Channel entrance partition crimped (1	Vos 1-14	10-20 34-60)	31:32
G-1173 Channel entrance locating block scr.	ew 8-32 x 1/2" 5:31:32	1-6732	Channel entrance partition lug (Nos. 3	0-99 61-0	2)	5.31.32
G-1541 Distributor clutch lever adjusting sc	rew bracket 5-31		Channel entrance partition lug, assemi		.,	0.01.02
G-3398 Channel entrance frame throwout le	ver link stud, lower, nut as	0104	(Nos. 15, 16, 17, 18)			5.31.32
G-3398 Distributor screw guard lever opera	ting screw nut 5:31:32	1-7135	Channel entrance partition (fender) as			0.01.04
I-1013 Channel entrance latch	31-32	1-1100	(Nos. 1-14, 19-29, 34-60)			5-31-32


31.32

1-1014 Channel entrance latch spring


I-1015 Channel entrance latch stop I-1173 Channel entrance spring



Distri	buting mechanism	Mout	01 32	Channel Entrance, Auxiliary 5	т.
	Channel entrance, auxiliary, support screw 8-32 x 3/8"	32		Channel entrance, auxiliary, partition, assembled, Nos. 16 and 34	3.
	Distributor clutch lever adjusting screw 1/4"-24 x 1 1/4"	32		Channel entrance, auxiliary, partition, assembled, No. 17	3
	Distributor clutch lever adjusting screw nut 1/4"-24 x 1/2"	32	1-3750	Channel entrance, auxiliary, partition, assembled, No. 18	3
BB-148	Distributor clutch lever adjusting screw bracket			Channel entrance, auxiliary, partition, assembled, No. 21	3
	screw 8-32 x 5/16"	32	1-3752	Channel entrance, auxiliary, partition, assembled, No. 22	3
	Channel entrance, auxiliary, bracket screw 3/8"-16 x 3/4"	32		Channel entrance, auxiliary, partition, assembled, No. 23	3
	Channel entrance, auxiliary, partition plate screw 8-32 x 3/18"	32		Channel entrance, auxiliary, partition, assembled, Nos. 24 and 25	3
D- 396	Distributor clutch lever adjusting screw bracket		1-3755	Channel entrance, auxiliary, partition, assembled, No. 26	3
	dowel .066" x 1/4"	32	1-3756	Channel entrance, auxiliary, partition, assembled, No. 27	3
	Channel entrance, auxiliary, supporting screw 1/4"-24 x 1"	32	1-3757	Channel entrance, auxiliary, partition, assembled, No. 29	3
	Channel entrance, auxiliary, hinge support screw 1/4"-24 x 3/4"	32		Channel entrance, auxiliary, partition, assembled, No. 31	3
F-1991	Channel entrance, auxiliary, hinge pin adjusting bearing		1-3759	Channel entrance, auxiliary, partition, assembled, No. 33	3
	gib screw 8-32 x 3/4"	32	1-3760	Channel entrance, auxiliary, partition, No. 35	3
F-2344	Channel entrance, auxiliary, hinge support adjusting		1-3761	Channel entrance, auxiliary, partition plate,	
	screw nut 10-32 x 3/32"	32		center section, hinge	3
	Channel entrance adjusting screw 1/4"-24 x 1 3/4"	32	1-3763	Channel entrance, auxiliary, partition plate,	
	Distributor clutch lever adjusting screw bracket	. 32		center section, assembled	33
G-35B7	Distributor clutch lever adjusting screw bracket and pi			Channel entrance, auxiliary, partition locking strip, upper	3
	chute support (72-90)	32		Channel entrance, auxiliary, assembled	3:
G-4071	Distributor clutch lever adjusting screw bracket pi chute suppo	rt 32	1-3873	Channel entrance, auxiliary, partition locking strip,	
	Channel entrance, auxiliary, hinge pin set screw 8-32 x 5/16"	32		lower, assembled	3:
1 - 567	Channel entrance, auxiliary, hinge support adjusting		1-3874	Channel entrance, auxiliary, partition locking strip,	
	screw 10-32 x 7/8"	32		lower, latch washer	3:
1 - 681	Channel entrance, auxiliary, partition locking bar			Channel entrance, auxiliary, partition locking strip, lower, latch	3:
	screw 8-32 x 11/16"	32	1-3876	Channel entrance, auxiliary, partition locking strip,	
1 - 788	Channel entrance, auxiliary, partition plate, center section,	1		lower, latch stud	3:
	hinge rivet	32	1-6252	Matrix guard, auxiliary	3:
1-1120	Channel entrance, auxiliary, bracket dowel 1/4" x 5/8"	. 32	1-6594	Channel entrance, auxiliary, hinge support, r.h.	3
	Channel entrance, auxiliary, hinge pin	. 32	1-6595	Channel entrance, auxiliary, hinge support screw	3
	Channel entrance, auxiliary, frame	32		Channel entrance, auxiliary, hinge pin	3
	Channel entrance, auxiliary, partition plate	32		Channel entrance, auxiliary, hinge support, l.h.	3:
	Channel entrance, auxiliary, partition locking rod	32		Channel entrance, auxiliary, frame	33
	Channel entrance, auxiliary, partition locking bar	.32		Channel entrance, auxiliary, assembled	3:
	Matrix guard, auxiliary	32		Channel entrance, auxiliary, adjusting screw nut 1/4"-24 x 3/8"	31
	Channel entrance, auxiliary, support	32	J- 463	Channel entrance, auxiliary, support adjusting	
	Channel entrance, auxiliary, partition, assembled, Nos. 1 to 11	32		screw nut 1/4"+24 x 3/8"	31
	Channel entrance, auxiliary, partition, assembled, No. 12	32	J- 9B3	Distributor clutch lever adjusting screw bracket and pi	
1-3745	Channel entrance, auxiliary, partition, assembled,			chute support screw 5-40 x 7/8"	31
	Nos. 13, 20, 28 and 30	. 32		Parts Not Illustrated	
	Channel entrance, auxiliary, partition, assembled, No. 14	32			
1-3747	Channel entrance, auxiliary, partition, assembled,			Channel entrance, auxiliary, bracket, r.h., assembled	32
	Nos. 15, 19 and 32	32	1-6604	Channel entrance, auxiliary, bracket, l.h., assembled	32



Distri	buting Mechanism	Models	29-30	Channel Entrance, Upper	343
	Channel entrance, upper, partition plate screw 8-32 x 3/		1-5705	Channel entrance, upper, 72 character, partition	
	Channel entrance, upper, partition locking bar	. 29.30		No. 30, assembled	29 - 30
1 - 681	Channel entrance, upper, partition locking bar		1-5706	Channel entrance, upper, 72 character, partition	
	screw 8-32 x 11/16"	29.30		with protecting leaf No. 31, assembled	29.30
	Channel entrance, upper, partition plate, lower	29.30	1-5707	Channel entrance, upper, 72 character, partition	
	Channel entrance, upper, partition crimped	29.30		with protecting leaf Nos. 43 and 48, assembled	29-30
	Channel entrance, upper, partition lug	29:30	1-5708	Channel entrance, upper, 72 character, partition	
	Channel entrance, upper, partition plate, upper	29.30		with protecting leaf No. 54, assembled	29-30
	Channel entrance, upper, assembled	29.30	1-5709	Channel entrance, upper, 72 character, partition	
	Channel entrance, upper, hinge pin			Nos. 55 and 61, assembled	29.30
	Channel entrance, upper, 72 character, partition plate, l	ower 29.30	I-5710	Channel entrance, upper, 72 character, partition	
I -5689	Channel entrance, upper, 72 character, partition			with protecting leaf Nos. 59 and 63, assembled	29-30
	Nos. 1, 2, 5, 22, 46 and 47, assembled	29.30	1-5711	Channel entrance, upper, 72 character, partition	
1-5690	Channel entrance, upper, 72 character, partition			No. 67, assembled	29:30
	Nos. 3, 6, 8, 10, 12 and 26, assembled	29.30	1-5712	Channel entrance, upper, 72 character, partition	
1-5691	Channel entrance, upper, 72 character, partition			No. 71, assembled	29:30
	No. 4, assembled	29.30		Channel entrance, upper, 72 character, partition No. 74	29 - 30
1-5692	Channel entrance, upper, 72 character, partition			Channel entrance, upper, 72 character, partition plate, upper	29 30
	Nos. 7, 13, 66 and 73, assembled	29.30	I-5715	Channel entrance, upper, 72 character, partition	
1-5693	Channel entrance, upper, 72 character, partition			Nos. 23, 50 and 82, assembled	29.30
		29.30	1-5754	Channel entrance, upper, 72 character, partition	
1-5694	Channel entrance, upper, 72 character, partition			No. 65, assembled	29 30
	with protecting leaf Nos. 11 and 17, assembled	29:30	1-5755	Channel entrance, upper, 72 character, partition	
1-5695	Channel entrance, upper, 72 character, partition			with protecting leaf Nos. 32 and 57, assembled	20.30
	Nos. 14, 25 and 70, assembled	29.30	1-5756	Channel entrance, upper, 72 character, partition	
1-5696	Channel entrance, upper, 72 character, partition			Nos. 44 and 69, assembled	29:30
	with protecting leaf Nos. 15, 33 to 42, 49 and 60, ass	embled 29:30	1-5757	Channel entrance, upper, 72 character, partition	
1-5697	Channel entrance, upper, 72 character, partition			with protecting leaf No. 64, assembled	29:30
	with protecting leaf No. 18, assembled	29.30	1-5758	Channel entrance, upper, 72 character, partition	
1-5698	Channel entrance, upper, 72 character, partition			No. 72, assembled	29.30
	Nos. 18, 51, 52, 58 and 68, assembled	29:30		Channel entrance, upper, 72 character, assembled	29.30
1~5699	Channel entrance, upper, 72 character, partition		1-6192	Channel entrance matrix guard, upper	29:30
	Nos. 19 and 27, assembled	29.30		Channel entrance, upper, 72 character, matrix guard	29.30
1-5700	Channel entrance, upper, 72 character, partition		I-7137	Channel entrance, upper, partition, fender,	
	Nos. 20, 53 and 58, assembled	29.30		Nos. 1 to 14, 16, 18 to 29, 34 to 60, assembled	29:30
1-5701	Channel entrance, upper, 72 character, partition		1-8008	Channel entrance, upper, partition, fender,	
	No. 21, assembled	29.30		Nos. 1 to 14, 18, 18 to 29, 34 to 60, assembled	29:30
1-5702	Channel entrance, upper, 72 character, partition			Channel entrance, upper, partition lug	29.30
	No. 24, assembled	29-30		Channel entrance, upper, partition plate, lower	29.30
1-5703	Channel entrance, upper, 72 character, partition		I-8011	Channel entrance, upper, assembled	29-30
	No. 28, assembled	29 - 30			
1-5704	Channel entrance, upper, 72 character, partition				
	No. 29, assembled	29-30			



dels	29-30	Channel Entrance,	Upper	345
9-30	1-6235	Channel entrance, upper, hinge pin adjusting bearing	ng gib,	
30		upper, r.h.		29 30
9.30	1-6236	Channel entrance, upper, hinge pin adjusting bearing	ng gib,	
9.30		lower, r.h.		29:30
	1-6236	Channel entrance, upper, hinge pin adjusting bearing	ng gib,	
9.30		upper, l.h.		20:30
9.30	1-6238	Channel entrance adjusting screw, l.h. 1/4"-24 x 2 1/	8"	29-30
9.30	1-6238	Channel entrance adjusting screw 1/4"-24 x 2 1/8"		29:30
	1-6243	Channel entrance, upper, frame		29.30
3.30	1-6244	Channel entrance, upper, assembled (so character)		29:30
	1-6246	Channel entrance, upper, assembled (72 character)		20.30
9:30	1-7402	Channel entrance, upper, guide roll bracket		20:30
9.30	1-7473	Channel entrance frame shoe		29.30
9:30	1-7610	Channel entrance, upper, guide roll stud		29:30
3.30	1-7786	Channel entrance, upper, hinge pin, r.h.		29:30
30	1-7789	Channel entrance, upper, banking screw, r.h., plate		29:30
3.30	1-7791	Channel entrance, upper, hinge pin, l.h.		29:30
9:30	1-7823	Channel entrance, upper, banking shoe		29:30
1.30	1-7824	Channel entrance, upper, frame		20.30

20:30

29:30

20:30

29:30

1-7825 Channel entrance, upper, assembled (72 character)

J- 463 Channel entrance, upper, guide roll bracket adjusting

J- 463 Channel entrance adjusting screw nut 1/4"-24 x 3/8"

29-30 J-1535 Channel entrance, upper, banking shoe screw 10-32 x 1/2"

bearing 29-30 screw no bearing gib, 29-30 J-463 Channel entra 29-30 J-1535 Channel entra Please Give Model and Seriol Number When Ordering

29-30

Mad

Distributing Mechanism


1-5490 Channel entrance, upper, hinge pin

lower, l.h.

1-6234 Channel entrance frame hinge pin adjustable bearing

1-6235 Channel entrance, upper, hinge pin adjusting bearing gib,

B- 236 Channel entrance adjusting screw, r.h. 1/4"-24 x 1 1/4" D-3044 Channel entrance frame shoe screw 8-32 x 11/32" E-1150 Channel entrance, upper, balance spring E-2720 Channel entrance, upper, guide roll screw nut 5/16"-18 x 1/8 F- 65 Channel entrance, upper, guide roll bracket screw 1/4"-24 x .715" F- 235 Channel entrance spring hook F- 235 Channel entrance, upper, balance spring hook F-1991 Channel entrance frame hinge pin adjusting bearing gib screw 8-32 x 3/4" F-3969 Channel entrance, upper, guide roll bracket adjusting serew 1/4"-24 x 3/4" G- 156 Channel entrance hinge pin set screw 8-32 x 5/18" G- 910 Channel entrance adjusting screw, l.h. 1/4-24 x 13/4" G-2929 Channel entrance, upper, guide roll H- 177 Channel entrance frame hinge pin set screw 8-32 x 1/4" 1- 628 Channel entrance, upper, partition locking rod 1-3013 Channel entrance frame hinge pin 1-5456 Channel entrance, upper, frame 1-5461 Channel entrance, upper, frame stop stud



Distributing Mechanism	Models	29-30 Channel Entrance, Lower	347
A- 672 Name plate, small, channel entrance rivet	29-30	1-6235 Channel entrance, lower, hinge pin adjusting bearing	
A- 824 Name plate, small, channel entrance	29 - 30	gib, lower, l.h.	29 - 30
8- 217 Channel entrance buffer screw 8-32 x 1/4"	29.30	1-6236 Channel entrance, lower, hinge pin adjusting bearing	
88-148 Channel entrance handle screw 8-32 x 5/16"	29:30	gib, lower, r.h.	29.30
BB-211 Channel entrance, lower, balance spring stud	29-30	1-6236 Channel entrance, lower, hinge pin adjusting bearing	
D- 218 Channel entrance, lower, banking shoe stud support	1		29:30
bracket dowel	29-30	1-6237 Channel entrance buffer	29.30
D- 977 Channel entrance, lower, latch bracket dowel	30	1-6241 Channel entrance, lower, frame	29:30
D-3044 Channel entrance frame shoe screw	29-30	1-6242 Channel entrance, lower, assembled	29.30
E- 184 Channel entrance, lower, latch operating pin	29.30	I-6313 Channel entrance buffer stop	29:30
E-2720 Channel entrance, lower, balance spring hook cap lock nut	29:30	1-7403 Channel entrance, lower, latch stop stud	29.30
F- 689 Channel entrance, lower, hinge pin, r.h., support screw	29:30	1-7414 Channel entrance, lower, banking shoe spring	29:30
G- 156 Channel entrance hinge pin set screw 8-32 x 5/16"	29:30	1-7416 Channel entrance, lower, latch	29.30
G- 910 Channel entrance adjusting screw 1/4"-24 x 13/4"	29.30	1-7423 Channel entrance, lower, hinge pin, r.h., support	29:30
G-1053 Channel entrance, lower, latch adjusting screw nut	29.30	1-7457 Channel entrance adjusting screw banking button	29.30
G-2790 Channel entrance, lower, banking shoe spring eye	29 30	1-7471 Channel entrance, lower, latch stud	29:30
G-3398 Channel entrance, lower, banking shoe stud nut	29.30	1-7473 Channel entrance frame shoe	29:30
1 - 403 Channel entrance buffer stop screw	29:30	1-7488 Channel entrance, lower, banking shoe stud support bracket :	29:30
I - 788 Channel entrance, lower, plate, upper, center section,	1	- 1-7612 Channel entrance, lower, balance spring	29:30
hinge rivet	29:30	1-7630 Channel entrance, lower, latch bracket	30
1-3062 Channel entrance handle	29.30	1-7738 Channel entrance, lower, balance spring hook stud, l.h.	29:30
1-3724 Channel entrance, lower, balance spring	29:30	1-7739 Channel entrance, lower, balance spring hook stud, r.h.	29:30
I -3892 Channel entrance buffer	29:30	1-7741 Channel entrance, lower, balance spring adjusting hook	29:30
I -4217 Channel entrance, lower, 72 character, matrix guard	29 30	1-7788 Channel entrance, lower, hinge pin, r.h.	29:30
I-5444 Channel entrance, lower, frame	29:30	1-7819 Channel entrance, lower, frame	29
1-5445 Channel entrance, lower, partition plate, lower	29:30	1-7820 Channel entrance, lower, frame	30
1-5453 Channel entrance, lower, balance spring hook, r.h.	29 30	I -7821 Channel entrance, lower, assembled	29
1-5454 Channel entrance, lower, balance spring hook cap	29:30	1-7822 Channel entrance, lower, assembled	30
1-5455 Channel entrance, lower, assembled	29:30	1-7834 Channel entrance banking shoe spring stud	29.30
1-5490 Channel entrance, lower, hinge pin	29:30	I-7837 Channel entrance, lower, banking shoe	29:30
1-5490 Channel entrance, lower, hinge pin, l.h.	29:30	J- 405 Channel entrance, lower, latch adjusting screw	29:30
1-5621 Channel entrance, lower, balance spring hook, l.h.	29:30	J- 463 Channel entrance, lower, latch stud nut	29:30
1-5842 Channel entrance, lower, banking shoe stud support			29.30

bracket screw

gib, upper, r.h.


1-6235 Channel entrance, lower, hinge pin adjusting bearing

29:30 J- 463 Channel entrance, lower, balance spring adjusting hook nut 29:30


J-6085 Channel entrance, lower, latch adjusting screw banking stud 30

29:30

29:30 J- 463 Channel entrance adjusting screw nut 1/4"-24 x 3/8"




Distributir	g Mechanism	Models	29-30	Channel	Entrance,	Lower	349
D- 159 Chan	nel entrance, lower, partition plate screw 6-32 x 3/16"	29.30	1-3134	Channel entrance, lower, partition p	late, upper.		
1- 628 Chan	nel entrance, lower, partition locking rod	29.30		center section, locking spring	washer		29:30
I- 680 Chan	nel entrance, lower, partition locking bar .	29:30	1-5445	Channel entrance, lower, partition p			29:30
1- 681 Chan	nel entrance, lower, partition locking bar		1-5449	Channel entrance, lower, partition p	late, upper		29.30
	screw 6-32 x 11/16"	29.30	1-5451	Channel entrance, lower, partition p	late, upper,		
1-2682 Char	nel entrance, lower, partition plate, upper,			center section, locking spring	I I as all and		29.30
	center section, hinge rivet	29-30	1-5452	Channel entrance, lower, partition p	late, upper,		
1-3127 Chan	nel entrance, lower, partition plate, upper,			lower section, assembled			29.30
	center section, hinge	29-30	1-7121	Channel entrance, lower, partition p	late, upper,		
1-3129 Chan	nel entrance, lower, partition plate, center			lower section, assembled			29 - 30
	section, stiffening strip	29:30	1-7122	Channel entrance, lower, partition le			29:30
1-3131 Chan	nel entrance, lower, partition plate, upper, .		1-7123	Channel entrance, lower, partition le	ocking rod stri	p. lower	29:30
	center section, assembled	29.30				,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
1-3133 Chan	nel entrance, lower, partition plate, upper,						
	center section, locking spring stud	.29.30					




Channel Entrance, Lower 35	Channel	Entrance,	Lower	35
----------------------------	---------	-----------	-------	----

Distrib	uting	Mechanism	Models	27-30		
	a	entrance bracket dowel 5/16" x 7/8"	29 - 30	1-5736	Channel entrance, lower, 72 character, partition,	
			5/16" 29:30			29 - 30
				1-5737	Channel entrance, lower, 72 character, partition,	29:30
					with protecting leaf, No. 31, assembled	
			29	1-5738	Channel entrance, lower, 72 character, partition, with protecting leaf, Nos. 43 and 48, assembled	20.30
			7/8" 30		Channel entrance, lower, 72 character, partition,	
				1-5739	with protecting leaf, No. 54, assembled	29:30
			29:30		Channel entrance, lower, 72 character, partition,	
D- 164	Distribu	itor clutch lever adjusting screw bracket	. 29	1-5740	Nos. 55 and 81, assembled	29 - 30
	sc	rew 1/4"-24 x 15/16"		1 5741	Channel entrance lower, 72 character, partition,	
D- 407	Channe	l entrance bracket, l.h., screw, upper 3/8"-16 x 3/4"	30		with protecting leaf. Nos. 50 and 63, assembled	29.30
E- 100	Channe	l entrance bracket, r.h. and l.h.,	29-30	1-5742	Channel entrance, lower, 72 character, partition,	
	BC	rew, upper 3/5"-16 x 3/4" itor clutch lever adjusting screw 1/4"-24 x 1 3/4"	29			29.30
G- 910	Distribu	ator clutch lever adjusting screw bracket	29	1-5743	Channel entrance, lower, 72 character, partition,	
G-3448	Distrib	ator clutch lever adjusting screw bracket				29.30
1 - 667	Distrib	owel 3/16" x 7/8"	29	1-5744	Channel entrance, lower, 72 character, partition, No. 74	20.30
	Channa	l entrance, lower, partition lug, crimped, No. 1	29 - 30	1-5748	Channel entrance, lower, 72 character, partition,	29-30
1 5446	Channe	l entrance, lower, partition lug	29:30		Nos. 23, 50 and 22, assembled	29.30
1 5440	Channe	l entrance, lower, partition, crimped	29.30	1-5749	Channel entrance, lower, 72 character, partition,	29 - 30
1 -5446	Channe	l entrance, lower, 72 character, partition,			with protecting leaf, Nos. 32 and 57, assembled	29.00
			29 - 30	1-5750	Channel entrance, lower, 72 character, partition,	29:30
1 5720	Channe	l entrance, lower, 72 character, partition,			Nos. 44 and 60, assembled	20.00
			29:30	1-5751	Channel entrance, lower, 72 character, partition,	29-30
1-6721	Channe	l entrance, lower, 72 character, partition,			with protecting leaf, No. 84, assembled	80 00
			29:30	1-5752	Channel entrance, lower, 72 character, partition,	29-30
1-5722	Channe	d entrance, lower, 72 character, partition,			No. 65, assembled Channel entrance, lower, 72 character, partition,	
			29.30	1-5753	No. 72, assembled	29:30
1-5723	Channe	el entrance, lower, 72 character, partition,			Channel entrance bracket, l.h., screw, upper 3/8" x 18-1 1/8"	29:30
			29:30	1-5861	Channel entrance bracket, r.h., screw, upper 3/8" x 18-1 1/8"	29:30
1-5724				1-5861	Channel entrance, lower, partition (fender)	
			29 - 30	1-7139	Nos. 2 to 14, 18, 18 to 29, 34 to 30, assembled	29 30
1-5725			29:30	1	Channel entrance, lower, partition (fender) No. 1, assembled	20:30
	v	ith protecting leaf, Nos. 11 and 17, assembled	59.30	1-/141		
1-5726	Channe	el entrance, lower, 72 character, partition,	29.30		Parts Not Illustrated	
	N	los. 14, 25 and 70, assembled	29.30	1.5521	Channel entrance bracket, r.h., to serial No. 53427	29:30
1-5727	Channe	el entrance, lower, 72 character, partition, with protecting leaf, Nos. 15, 33 to 42, 49 and 60, asser	mblad sa.sa			29:30
	V	rith protecting lear, Nos. 15, 33 to 42, 49 and 60, asses	mored an ac	1.6227	Channel entrance bracket, r.h., from serial No. 53428 to	
1-5728	Channe	el entrance, lower, 72 character, partition,	29-30			29:30
	, V	rith protecting leaf, No. 18, assembled	20.00	1-6240	Channel entrance bracket, r.h., assembled, to serial No. 57099	29:30
1-5729	Chann	el entrance, lower, 72 character, partition,	29.30	1-6329	Channel entrance bracket, l.h., from serial No. 53428 to	
	1	ics. 18, 51, 52, 58 and 68, assembled el entrance, lower, 72 character, partition,	20 00			29:30
1-5730	Chann	er entrance, lower, 12 character, partition,	20.30	1-6339	Channel entrance bracket, l.h., assembled, to serial No. 57099	29 - 30
	en	vos. 19 and 27, assembled el entrance, lower, 72 character, partition,	20 00	1-7790		
1-5731	Chann	el entrance, lower, 12 character, partition,	29:30			29:30
	Chann	vos. 20, 53 and 58, assembled el entrance, lower, 72 character, partition,		1-7793	Channel entrance bracket, l.h., assembled, from serial	29:30
1-5732	Chann	Vo. 21, assembled	29 - 30			29:30
	Chann			1-803	Channel entrance bracket, r.h., from serial No. 61942	29.30
1-5733	Chann	Vo. 24, assembled	29.30			89.30
1 5724	Chann	el entrance, lower, 72 character, partition,		1-805	Channel entrance bracket, l.h., assembled, from serial	29:30
			29:30		No. 61942	20.30
1-6725	Chann	el entrance, lower, 72 character, partition,		1-805	Channel entrance bracket, r.h., assembled, from serial	29.30
1-5/30	Chami	No. 29, assembled	29.30	1	No. 61942	29.00



				-			
	Channel entrance, auxiliary, adjusting screw 1/4"-24 x 1 1/4" 30	1-5468	Channel entrance, auxiliary, upper, partition, No. 12, assembled	30			
	Channel entrance partition plate screw 8-32 x 3/18" 30	1-5469	Channel entrance, auxiliary, upper, partition,				
	Channel entrance, auxiliary, upper, spring 30		Nos. 13, 20, 28-30, assembled	. 30			
F- 235	Channel entrance, auxiliary, upper, spring hook . 30	1~5470	Channel entrance, auxiliary, upper, partition, No. 14, assembled	30			
G-2318	Channel entrance, auxiliary, frame throwout lever	I-5471	Channel entrance, auxiliary, upper, partition,				
	SCTeW 1/4"-24 x 1/2"		Nos. 15, 19, 32, assembled	30			
H- 144	Channel entrance, auxiliary, hinge pin set screw 8-32 x 5/16" 30	1-5473	Channel entrance, auxiliary, upper, partition,				
	Channel entrance, auxiliary, hinge pin set screw 8-32 x 1/4" . 30		Nos. 18, 34, assembled .	30			
I - 681	Channel entrance, auxiliary, partition locking bar	1-5474	Channel entrance, auxiliary, upper, partition, No. 17, assembled	30			
	Screw 8-32 x 11/16"	1-5475	Channel entrance, auxiliary, upper, partition, No. 18, assembled	30			
I - 788	Channel entrance, auxiliary, upper, partition plate,	1-5476	Channel entrance, auxiliary, upper, partition, No. 21, assembled	30			
	center section, hinge rivet 30	1-5477	Channel entrance, auxiliary, upper, partition, No. 22, assembled	30			
1-2931	Channel entrance, auxiliary, upper, spring . 30	1-5478	Channel entrance, auxiliary, upper, partition, No. 23, assembled	30			
1-3422	Channel entrance, auxiliary, upper, partition locking rod 30	1-5479	Channel entrance, auxiliary, upper, partition,				
1-3423	Channel entrance, auxiliary, upper, partition locking bar 30		Nos. 24, 25, assembled	30			
1-3424	Matrix guard, auxiliary	1-5480	Channel entrance, auxiliary, upper, partition, No. 28, assembled	30			
I -3761	Channel entrance, auxiliary, upper, partition plate,	I-5481	Channel entrance, auxiliary, upper, partition, No. 27, assembled	30			
	center section, hinge 30	1-5482	Channel entrance, auxiliary, upper, partition, No. 29, assembled	30			
1-3763	Channel entrance, auxiliary, upper, partition plate,	1-5483	Channel entrance, auxiliary, upper, partition, No. 31, assembled	30			
	center section, assembled . 30	1-5484	Channel entrance, auxiliary, upper, partition, No. 33, assembled	30			
1-3873	Channel entrance, auxillary, upper, partition locking	1-5485	Channel entrance, auxiliary, upper, partition, No. 35	30			
	strip, lower, assembled 30	1-5486	Channel entrance, auxiliary, upper, partition locking strip, upper	30			
1-3874	Channel entrance, auxiliary, upper, partition locking	1-5487	Channel entrance, auxiliary, upper, assembled	30			
	strip, lower, latch washer	1-5490	Channel entrance, auxiliary, upper, hinge pin	30			
1-3875	Channel entrance, auxiliary, upper, partition locking	1-6251	Channel entrance, auxiliary, upper, frame	90			
	strip, lower, latch	1-6252	Matrix guard, auxiliary	30			
1-3876	Channel entrance, auxiliary, upper, partition locking	1-6253	Channel entrance, auxiliary, upper, assembled	30			
	strip, lower, latch stud	1-6311		30			
1-5463	Channel entrance, auxiliary, upper, frame . 30	1-6408	Channel entrance, auxiliary, upper, balance spring stud	30			
1-5464	Channel entrance, auxiliary, upper, partition plate, lower 30	1-7644	Channel entrance, auxiliary, upper, frame	30			
1-5467	Channel entrance, auxiliary, upper, partition,	1-7831	Channel entrance, auxiliary, upper, rame	30			
	Nos. 1 to 11, assembled 30	J- 463	Channel entrance, auxiliary, adjusting screw nut 1/4*-24 x 3/8*	30			
				90			
	Please Give Madel and Serial Number When Ordering						



Distributi	ng Mechanism	Mode	1 30	Channel Entrance, Auxiliary, Lower 3	55
	nel entrance, auxiliary, buffer screw 8-32 x 1/4"	30		Channel entrance, auxiliary, lower, frame	
3- 236 Dista	ibutor clutch lever adjusting screw 1/4"-24 x 1 1/4"	30		Channel entrance, auxiliary, lower, partition plate, lower	30
	ibutor clutch lever adjusting screw nut 1/4"-24 x 1/2"	30	I-3517	Channel entrance, auxiliary, lower, partition plate,	
	nel entrance, auxiliary, lower, balance spring stud	30		upper, upper section	30
0- 142 Disti	ibutor clutch lever adjusting screw bracket		1-3520	Channel entrance, auxiliary, lower, partition plate,	
	screw 1/4"-24 x 5/8"	30		upper, center section, assembled	- 31
0- 159 Char	inel entrance, auxiliary, lower, partition locking,			Channel entrance, auxiliary, lower, matrix guard	
	lower, screw 8-32 x 3/18"	30		Channel entrance, auxiliary, lower, frame supporting arm shoe	
E- 100 Dist	ibutor clutch lever adjusting screw bracket		1-3549	Channel entrance, auxiliary, lower, assembled	.30
	screw 3/8"=16 x 3/4"	. 30	1-3614	Channel entrance, auxiliary, lower, partition locking	
F- 463 Dist	ibutor clutch lever adjusting screw bracket			rod strip, lower	- 30
	dowel 3/18" x 5/8"	30	1-3615	Channel entrance, auxiliary, lower, partition locking	
F- 904 Char	nel entrance, auxiliary, lower, frame supporting			rod strip, upper	- 30
	arm shoe screw 1/4"-24 x 9/16"		1-3617	Channel entrance, auxiliary, lower, partition plate,	
	mel entrance adjusting screw 1/4"-24 x 1 3/4"	- 30		upper, lower section, assembled	- 34
	ibutor clutch lever adjusting screw bracket ibutor clutch lever adjusting screw bracket	30		Channel entrance, auxiliary, lower, balance spring Channel entrance, auxiliary, lower, balance spring hook	30
		30			3
	mel entrance, auxiliary, hinge pin set screw 8-32 x 5/16" mel entrance, auxiliary, hinge pin set screw 8-32 x 1/4"	30		Channel entrance, auxiliary, hinge pin Channel entrance, auxiliary, lower, partition plate,	- 3
		30	1-6038	upper, lower section, hinge	
	mel entrance, auxiliary, buffer stop screw 8-32 x 15/16" mel entrance, auxiliary, lower, partition plate support	30			31
- 681 Chai		30	1-6237	Channel entrance, auxiliary, buffer Channel entrance, auxiliary, adjusting screw 1/4"-24 x 2 1/8"	31
	screw 8-32 x 11/16" anel entrance, auxiliary, lower, partition locking bar	30		Channel entrance, auxiliary, lower, frame	31
- 681 Chai	screw 8-32 x 11/16"	30		Channel entrance, auxiliary, lower, matrix guard	
ant Dist	butor clutch lever adjusting screw bracket	30		Channel entrance, auxiliary, lower, matrix guard .  Channel entrance, auxiliary, lower, assembled	36
- 831 Disti	dowel 3/16" x 11/18"	20		Channel entrance, auxiliary, lower, assembled Channel entrance, auxiliary, buffer stop	
0000 Cha	anel entrance, auxiliary, lower, partition plate,	30		Channel entrance, auxiliary, lower, partition plate support	31
-2682 Cniu	upper, lower section, hinge rivet	. 30		Channel entrance, auxiliary, adjusting screw 1/4"-24 x 2 3/8"	
2000 (1)	apper, lower section, ninge rivet anel entrance, auxiliary, lower, partition plate,	30		Channel entrance, auxiliary, lower, frame	
-2682 Cna	upper, center section, hinge rivet			Channel entrance, auxiliary, lower, balance spring	01
2107 Char	anel entrance, auxiliary, lower, partition plate,	30	1-7740	adjusting hook stud	- 94
-312/ Cha	upper, center section, hinge	30	1 7741	Channel entrance, auxiliary, lower, balance spring	01
2120 Char	anel entrance, auxiliary, lower, partition plate,	30	1-//41	adjusting hook	. 31
-3126 CHR	upper, lower section, stiffening strip rivet	. 30	1 7770	Channel entrance, auxiliary, lower, balance spring	
2122 Char	and entrance, auxiliary, lower, partition plate,	- 00		Channel entrance, auxiliary, hinge pin	31
-3132 CHAI	upper, lower section, locking spring	30		Channel entrance, auxiliary, lower, guide roll	31
2122 Char	onel entrance, auxiliary, lower, partition plate,	30		Channel entrance, auxiliary, lower, guide roll stud	31
-3133 Chai	upper, lower section, locking spring stud	30		Channel entrance, auxiliary, lower, guide ron stud	34
2124 Cho	anel entrance, auxiliary, lower, partition plate,	80		Channel entrance, auxiliary, lower, balance spring	- 01
-3134 Chia	upper, lower section, locking spring washer	30	J - 403	adjusting hook nut 1/4"-24 x 3/8"	31
1 -2422 Char	inel entrance, auxiliary, lower, partition locking rod	30	1- 463	Channel entrance, auxiliary, adjusting screw nut 1/4"-24 x 3/8"	30
	inel entrance, auxiliary, lower, partition locking for	. 30	- 403	Chainer chance, administ, adjusting screw fluct/4 -wt x 5/6	30


Distrib	buting	Mechanism		Mo	del 30	Channel	Entrance,	Auxiliary,	Lower	357
A- 730	Channel	l entrance, auxiliary	, frame bracket dowel 5/1	6" x 7/8"	0 1-354	2 Channel entrance, au	xiliary, lower	partition, No. 2	, assemble	d 30
8- 99	Channel	entrance, auxiliary	, support screw 8-32 x 3/8	*		3 Channel entrance, au				
88-148	Channel	l entrance, auxiliary	, handle screw 8-32 x 5/18			4 Channel entrance, au				
			, support detent spring			5 Channel entrance, au				
D- 404	Channel	l entrance, auxiliary	, support detent knob pin	1/16" x 3/8" :		6 Channel entrance, au				
D- 407	Channel	l entrance, auxiliary	, frame bracket screw 3/8	"-16 x 3/4"		7 Channel entrance, au				
D-1535	Channe	l entrance, auxiliary	, support pin set screw 8-	32 x 3/16" 1		<ol> <li>Channel entrance, au</li> </ol>				
F- 236	Channel	l entrance, auxiliary	, support bracket screw 1	/4"-24 x 5/8" ;		2 Channel entrance, au				
F-1991			, hinge pin adjusting bea			3 Channel entrance, au				
				21 x 000 11 3		4 Channel entrance, au				
G- 910		l entrance, auxiliary				8 Channel entrance, au				30
						9 Channel entrance, au				
			, hinge pin set screw 8-32		0					
			, support pin 1/4" x 2 1/4"			9 Channel entrance, au				
			, support bracket dowel a			7 Channel entrance, au				
			, handle			5 Channel entrance, au				
1-3526		l entrance, auxiliary				6 Channel entrance, au				
	N	os. 1 to 11, assemble		11 110	0 1-638	9 Channel entrance, au				. 30
1-3527	Channe	l entrance, auxiliary	, lower, partition, No. 12,	assembled :	0 J- 46	3 Channel entrance, au				
1-3529		l entrance, auxiliary				screw nut 1/4"-	24 x 3/8"			30
			ssembled			7 Channel entrance, au	xiliary, frame	bracket dowel a	/18" x 7/8"	30
			, lower, partition, No. 14,	assembled	10					
1-3532		l entrance, auxiliary				Pi	arts Not Illust	rated		
			mbled	dancer l	10					
1-3535		l entrance, auxiliary				2 Channel entrance, au				
			led			3 Channel entrance, au				. 30
			, lower, partition, No. 17,			1 Channel entrance, au				
1-3537	Channe	l entrance, auxiliary	, lower, partition, No. 18,	assembled	0			2002 2 320 00		30
1-3538	Channe	l entrance, auxiliary	, lower, partition, No. 21,			7 Channel entrance, au				
1-3539	Channe	l entrance, auxiliary	, lower, partition, No. 22,	assembled	10			at a b assemble		
1-3540	Channe	l entrance, auxiliary	, lower, partition, No. 23,	assembled		<ul> <li>Channel entrance, au</li> </ul>				
1-3541		l entrance, auxiliar				1 Channel entrance, au	xmary, brack	et, i.n., assemble	a	30
	N	os. 24 and 25, assemb	led	- 10 00 0	10 [					

Distribu	ting Mechanism	Models	5-29-30-3	1-32	Matrix	Tray	359
A- 112 M	atrix trav screw 8-32 x 3/8"	. 5	1-2840	Matrix tray, assembled			30
B- 217 M	atrix tray, auxiliary, screw 8-32 x 1/4"	30		Matrix tray bracket, l.h., screw 1/4"-24 x 1			31-32
	atrix tray screw 8-32 x 1/4"			Matrix tray bracket, r.h., screw 1/4"-24 x			31-32
	atrix tray, auxiliary, bracket screw 1/4"-24 x 5/8"			Matrix tray, r.h.			30
	atrix tray bracket, r.h. and l.h., dowel 1/8" x 1/2"		11-32 1-5425	Matrix tray bracket, r.h.			31-32
	atrix tray bracket, r.h., dowel 1/8" x 1 1/8"	29:30	1-5427	Matrix tray support			31 - 32
	atrix tray bracket, r.h., dowel 1/8" x 13/32"		1.99 1-5428	Matrix tray, center			31 - 32
	atrix tray bracket, l.h., dowel 1/8" x 13/32"	29 - 30 - 3	1.92   1.5420	Matrix tray, r.h.			31-32
	atrix tray bracket, r.h., screw 1/4"-24 x 1/2"	29-30	1 5420	Matrix tray, l.h.			31.32
	atrix tray bracket, fill, screw 1/4 at 1/2 atrix tray, auxiliary, bracket screw 1/4°-24 x 7/16°		1 5431	Matrix tray, assembled			31 - 32
	atrix tray, auxiliary, bracket screw 1/4"-24 x 7/16"	29:30	1-5431	Matrix tray, assembled			
			1-5816	Matrix tray support		25	
	atrix tray bracket, r.h., screw 1/4"-24 x 7/18"		1-5817	Matrix tray, r.h.		21	
	atrix tray rivet		1-5818	Matrix tray, assembled		21	
1-1471 M	atrix tray	. 5	1-5898	Matrix tray bracket, l.h.			31 - 32
	atrix tray, auxiliary, bracket dowel 3/16" x 9/18"		32 1-6292	Matrix tray, auxiliary, bracket			30
	atrix tray, auxiliary, center and l.h.		1-6410	Matrix tray bracket, l.h.		20	-30
1-2673 M	atrix tray, center	29:30	1-6411	Matrix tray, auxiliary, support			30
	atrix tray support		1-6412	Matrix tray, auxiliary, r.h.			30
1-2675 M	atrix tray spring	29:30:3	1-6413	Matrix tray, auxiliary, assembled			30
1-2675 M	atrix tray, auxiliary, spring	30	1-6506	Matrix tray, auxiliary, bracket, r.h.			32
1-2676 M	atrix tray spring rivet	29-30-3		Matrix tray, auxiliary, bracket			32
	otnin tron anniliana maina sinat			Motolar trans comilions - combled			0.0

29 - 30


| 1-2676 Matrix tray, auxiliary, spring rivet | 30 | 1-2677 Matrix tray, auxiliary, spring rivet | 29-30-3: | 1-2677 Matrix tray auxiliary, rivet | 30 | 1-2677 Matrix tray, auxiliary, rivet | 30 | 1-2679 Matrix tray bracket, r.h. | 29-30

1-2839 Matrix tray, l.b.




Assembled D-3302 MODELS 5F-29-30-31-32

Check Parts by Referring to Detail Pages.



ASSEMBLED

D-6030 Models 30 and 32 from Serial No. 54066 D-6569 Models 30 and 32 from Serial No. 61470




Distributing Mechanism	Models 5-2	19-30-31-32 Pi Stacke	r and	Tube	363
A- 112 Pi stacker rail screw 8-32 x 3/8"	5-29-30-31-32	D-4597 Pi stacker chute plate, long			30 3:
C- 476 Pi stacker driving belt hook	5-29-30-31-32	D-4598 Pi stacker chute plate, short			30 3
C-1984 Keyboard, auxiliary, driving belt, assembled	30 32	D-4600 Pi stacker friction block			30 3
D- 85 Pi stacker chute plate screw, long 4-48 x 3/18"		D-4943 Pi stacker chute cover screw 6-48 x 3/16"		5 - 29 -	30-31-3
D- 142 Pi stacker screw 1/4"-24 x 5/8"	5 - 29 - 30 - 31 - 32	D-5218 Pi stacker driving belt, assembled		29	
D- 177 Pi stacker friction block spring screw 4-48 x 3/16"	5-29-30-31-32	D-6019 Pi stacker driving shaft gear			30 33
D-1271 Pi stacker star shaft bushing	5-29-30-31-32	D-6020 Pi stacker driving shaft bearing, Lh.			30 33
D-1273 Pi stacker friction block	5 - 29 - 30 - 31 - 32	D-6021 Pi stacker driving shaft bearing, r.h.			30 33
D-1274 Pi stacker friction block spring	5-29-30-31-32	D-6022 Pi stacker star driving shaft bushing			30 33
D-1280 Pi stacker star pulley	5 - 29 - 30 - 31 - 32	D-6023 Pi stacker driving shaft			30 3:
D-1282 Pi stacker driving pulley	5-29-30-31-32	D-6024 Pi stacker star driving shaft			30 3
D-1535 Pi stacker star pulley screw 8-32 x 3/18"	5-29-30-31-32	D-6025 Pi stacker star driving shaft collar			30 33
D-1535 Pi stacker driving pulley screw 8-32 x 3/18"	5 - 29 - 30 - 31 - 32	D-6027 Pi stacker star driving shaft, assembled			30 3
D-1574 Pi stacker belt guide screw 10-32 x 1/2"		D-6546 Pi stacker chute matrix guide, assembled			30 3
D-2182 Pi stacker star driving shaft head pin 3/32" x 15/32"	5 - 29 - 30 - 31 - 32	D-6547 Pi stacker chute matrix guide stop			30 33
D-2503 Pi stacker universal joint	5-29-30-31-32	D-6549 Pi stacker driving shaft			30 3
D-2504 Pi stacker star shaft	5-20-30-31-32	D-6557 Pi stacker driving belt, assembled			30 3:
D-2505 Pi stacker star driving shaft head	5-29-30-31-32	D-6565 Pi stacker chute and support, assembled			30 3
D-2512 Pi stacker star driving shaft, assembled		D-6567 Pi stacker belt guide			30 3
D-2973 Pi stacker driving belt, assembled	30 32	E - 356 Pi stacker chute plate screw, short 4-48 x 3.	32"	5 - 29	30-31-3
D-3294 Pi stacker rail D-3296 Pi stacker chute cover, assembled	5-29-30-31-32	E- 356 Pi stacker chute plate screw, short 4-48 x 3, H- 71 Pi stacker driving shaft gear pin			30 3:
D-3296 Pi stacker chute cover, assembled	5-29-30-31-32	I - 299 Pi stacker chute matrix guide pin 1/16" x 1		5-20	30-31-3
D-3297 Pi stacker chute plate, long	5-29-30-31-32	· · · · · · · · · · · · · · · · · · ·			
D-3298 Pi stacker chute plate, short	5-29-30-31-32	Parts Not Illustrated			
D-3299 Pi stacker chute matrix guide	5-29 30-31-32				
D-3300 Pi stacker chute matrix guide spring D-3301 Pi stacker star	5-29-30-31-32	D-3293 Pi stacker bracket to serial No. 57099 on Mc			
D-3301 Pi stacker star	5-20-30-31-32	to serial No. 57222 on Model 32		5 - 29 -	30-31-33
D-4480 Pi stacker driving belt, assembled	31	D-3302 Pi stacker, assembled		5 - 29 -	30-31-33

30 32 D-4593 Pi stacker bracket from serial No. 57100 on Model 30,

from serial No. 57223 on Model 32 ...... 30 32

D-4594 'Pi stacker rail

D-4596 Pi stacker chute cover, assembled .




	Models	29-30-32
_		

Distributing Mechanism

Models 29-30-3	2


P:	Stacker	and	Tubo	36

A- 115	Pi stacker and assembler entrance, upper, finger shift		D-6540 Pi stacker idle pulley support	30.32
	bracket support dowel 3/8" x 7/8"	29	D-6541 Pi stacker detent support	30.32
A- 731	Pi stacker detent pin 5/18" x 1 1/4"	30 - 3		30.32
8- 99	Pi stacker idle pulley retaining washer screw 8-32 x 3/8"	30.3		30.32
8- 584	Pi stacker detent cotter pin	30	D-6545 Pi stacker idle pulley, assembled	30 - 32
	Pi stacker detent support screw, l.h. 8-32 x 5/16"	30.3	32 D-6548 Pi stacker detent	30-32
C- 147	Pi stacker detent pin dowel 3/32" x 11/16"	30.3	32 D-6558 Pi stacker detent pin bracket	30 - 32
	Pi stacker detent pin bracket screw 3/8"-16 x 5/8"	30.3		30-32
	Pi stacker detent pin bracket dowel 1/6" x 7/16"	30.3		20-32
	Pi stacker and assembler entrance, upper, finger key		F- 97 Pi stacker detent support screw, r.h. 8-32 x 5/8"	30 - 32
	shift bracket support	29	F- 357 Pi stacker detent spring	30.32
D-4942	Pi stacker and assembler entrance, upper, finger shift		F-3115 Pi stacker detent support screw, r.h. 8-32 x 1 1/8"	30 - 31
D-4342	bracket support screw 1/2"-12 x 7/8"	29	F-4797 Pi stacker idle pulley stud pin 1/8" x 3/4"	30-32
D E210	Pi stacker bracket extension		G- 33 Pi stacker idle pulley retaining washer	30-31
		30.8		
	Pi stacker and auxiliary keyboard driving belt	30.9		30 - 32
D-6427	Pi stacker and assembler entrance, upper, shift bracket		G- 240 Pi stacker bracket dowel 3/18" x 3/4"	20.32
	screw, upper, front	29	I-4821 Pi stacker idle pulley support screw 10-22 x 5/8"	30 - 32
D-6428	Pi stacker and assembler entrance, upper, shift bracket screw, lower	29	Parts Not Illustrated	
	Pi stacker and assembler entrance, upper, shift bracket	29	D-6579 Pi stacker and support arm, assembled	30-32
	Pi stacker and assembler entrance, upper, shift Pi stacker and assembler entrance, upper, shift	20	D-6579 11 stacker and support arm, assembled	30.32
D-6430				
	bracket, assembled	29		




		30 32	D-6528 Pi stacker and keyboard, auxiliary, supporting bracket, r.h. 30	
B- 222		30	D-6550 Pi stacker support arm shaft	32
C- 209		30 32	D-6566 Pi stacker support arm bracket	32
D- 84	Pi stacker support detent spring	30 32	D-6568 Pi stacker support and drive bracket	32
D- 131	Pi stacker support and driving bracket screw 3/8"-18 x 1 1/6":	30	D-6572 Pi stacker support arm 30	32
D- 404	Pi stacker support detent knob pin 1/16" x 3/8"	32	D-6637 Pi stacker and keyboard, auxiliary, supporting bracket, r.h. so	04
D-1402	Pi stacker chute support screw 8-32 x 7/16"	30 32	E- 9 Pi stacker support pivoting bracket screw 1/4"-42 x 7/8" 30	32
D-1606	Pi stacker support screw	32	E- 38 Pi stacker support arm bracket screw 3/8"-16 x 7/8" 30	32
D-3253	Pi stacker support	32		
D-4468	Pi stacker support and control lever rod	02	E- 190 Pi stacker support and driving bracket dowel 1/4" x 1 1/2" 30	32
	guide bracket (72-90)		F- 6B9 Pi stacker support arm adjusting screw 1/4"-24 x 3/4" . 30	32
D 4460	Pi stacker support and control lever rod guide bracket	31	G- 33 Pi stacker idle pulley retaining washer 30	32
D-4469			G- 119 Pi stacker support and drive bracket cover	
	screw 1/2"-12 x 1" (72-90)	31	Screw 6-46 x 1/4" 30	32
D-4686	Pi stacker support screw	10	H-4108 Pi stacker support arm adjusting screw nut 1/4"-24 x 3/16" 30	32
D-4701	Pi stacker support	10	I- 905 Pi stacker support arm shaft pin	32
D-4880	Pi stacker support lock screw knob	0	1-3552 Pi stacker support detent	32
D-4881	Pi stacker support lock screw, assembled .	10	1-3553 Pi stacker support detent knob	32
D-5214	Pi stacker support pivoting bracket	32	I -3554 Pi stacker support detent, assembled	32
D-5215	Pi stacker support pivoting bracket screw 1/4"-24 x 3/4"	32		32
D-6017	Pi stacker and keyboard, auxiliary, supporting bracket, r.h. a	0 32	Parts Not Illustrated	
D-6018	Pi stacker support and drive bracket	0 32	D 4016 Di steeken sunnent	
D-6026	Pi stacker support and drive bracket cover	0 32	D-4916 Pi stacker support, assembled . 30	
D 6527	Pi stacker and keyboard, auxiliary, supporting	0 32	D-5614 Pi stacker support, assembled	32
0-0327	breaket and keyboard, auxiliary, supporting			
	bracket, r.h., adjustable plate	0 32		

Please Give Model and Serial Number When Ordering



istributing Mechanism	Models 5-29-30-31-32	Pi Stacker and Tube	36

8- 74	Sorts box supporting frame hinge bracket			I-3553 Sorts box detent knob	0 3
	screw, upper 3/8"-18 x 5/8"	30	32	1-5843 Sorts box supporting frame screw	
B- 201	Sorts box supporting frame hinge pin set			J-3198 Sorts box 5-29-3	0.31.3
	screw 1/4"-24 x 5/16"	30	32	J-3303 Sorts box supporting frame .	3
B- 210	Assembler entrance, upper, finger key lever stop			J-3306 Sorts box supporting frame hinge pin	0 3
	screw 1/4"-20 x 1"	30		J-3550 Sorts box bracket, assembled 5-29-3	0.31.3
	! Sorts box supporting frame slide stop screw	30	32	J-3551 Sorts box supporting frame, assembled	3
		29-30-31	.32	J-4532 Sorts box supporting frame spring washer 3	0 3
D-465	Assembler entrance, upper, finger key lever			J-4717 Sorts box supporting frame hinge bracket 3	0 3
	fulcrum pin	30		J-4890 Sorts box supporting frame	0
E- 2	Assembler entrance, upper, finger key lever			J-4891 Sorts box supporting frame, assembled 3	0
	fulcrum pin set screw 8-32 x 1/4"	30		J-6019 Sorts box supporting frame 3	0 3
E- 75	Sorts box supporting frame slide bracket collar pin	30	32	J-6033 Sorts box bracket, assembled 3	0 3
E- 7	Sorts box supporting frame slide bracket stop			J-6227 Sorts box supporting slide bracket stop collar 3	0 3
	collar pin	30	32	J-6230 Sorts box supporting frame slide bracket detent	
F- 86	Sorts box supporting frame slide bracket stop			latch, assembled 3	0 3
	collar set screw 1/4"-24 x 5/16"	30	32	J-6233 Sorts box supporting slide needle bearing 3	0 8
F-5591	Assembler entrance, upper, finger key lever stop			J-6235 Sorts box supporting slide ball bearing 3	0 3
	screw lock nut 1/4"-20 x 3/8"	30		J-6237 Sorts box supporting frame slide, assembled 3	0 3
G-2790	Assembler entrance, upper, finger key lever spring eye	30		J-6238 Sorts box supporting frame, assembled 3	0 3
		29-30-31	-32	J-6288 Sorts box supporting frame 3	0 3
H-229	Sorts box supporting frame hinge bracket			J-6289 Sorts box supporting frame, assembled 3	0 3
	screw, lower 1/4"-24 x 5/8"	30	32	Parts Not Illustrated	
H-391	Sorts box supporting frame slide bracket collar	30	32	Farts Not Hustrated	
1-1073	Sorts box supporting frame hinge bracket			J-6231 Sorts box supporting slide bracket, assembled 3	0 3:
	dowel 1/4" x 3/4"	30	32		



Distributing Mechanism	Models 5-29-30-31-32	Pi Ste

Distributing Mechanism	Models	5-2	9-30-31-32	Pi	Stacker	and	Tube	371
B- 217 Pi chute screw 8-32 x 1/4"	5-29-30-	31-32	J-3367 Pi chute lower stiffening piec				30	,
B- 217 Pi chute lower stiffening piece screw 8-32 x 1/4"			J-3371 Pi chute intermediate plate, le	ng			29.30	,
BB-14B Pi chute supporting bracket screw 8-32 x 5/16"	. 30		J-3372 Pi chute intermediate plate, sl	ort			29:30	
BB-220 Pi chute adjusting screw 10-28 x 7/8"	. 29		J-3375 Pi chute, assembled				30	,
BB-221 Pi chute adjusting screw nut 10-28 x 5/16"			J-4B34 Pi chute, assembled					32
D- 779 Pi chute supporting bracket screw washer	30		J-5488 Pi chute, assembled				29	
D-3169 Pi chute support		32	J-5725 Pi chute supporting bracket				30	
F- 233 Pi chute locating pin 1/8" x 11/84"	29 - 30		J-5729 Pi chute, assembled				30	
G- 956 Pi stacker tube fulcrum screw nut 5-40 x 1/4"	29-30	32	J-6085 Pi chute screw, lower				29.30	
G-4071 Distributor clutch lever adjusting screw bracket and			J-6106 Pi chute back plate				. 29 - 30	
pi chute support		32	J-6169 Pi chute front plate, assemble	1			29-30	
I - 204 Pi stacker tube fulcrum screw 5-40 x 1/84"	29:30	32	J-6172 Pi chute, assembled				30	
J- 983 Distributor clutch lever adjusting screw bracket and								
pi chute support screw 5-40 x 7/8"		32	J-6252 Pi chute, assembled					
J-1B69 Pi chute, assembled	.5	31 - 32						




Distributing	Mechanism	Models 5-29

## 9-30-31-32

Pi Stacker and Tube 373

	Pi stacker tube bracket screw 8-32 x 3/8" 29-30	D-3281	Pi stacker tube section clamp . 5-29-30-31-32
A- 112	Pi stacker tube clip, center, bracket screw 8-32 x 3/8° 29	D~3283	Pi stacker tube clip, lower
	Pi stacker tube clip, intermediate, screw 8-32 x 3/8" 3:	D-3404	Pi stacker tube clip, intermediate 30
	Pi stacker tube clip, upper, screw 8-32 x 1/4" 5 31-3:	D-4376	Pi stacker tube clip, lower 32
B- 217	Pi stacker tube clip, intermediate, screw 8-32 x 1/4" 5 3:	D-4575	Pi stacker tube clip, intermediate 5 31
B- 217	Pi stacker tube clip, lower, screw 8-32 x 1/4" 5-29-30-31-3:	D-5175	5 Pi stacker tube clip, upper 5 31-32
B- 217	Pi stacker tube clip, center, screw 8-32 x 1/4" 29	D-5179	Pi stacker tube clip, upper clamp 5 31-32
B- 217	Pi stacker tube section, upper, screw 8-32 x 1/4" 31	D-5179	Pi stacker tube support clip clamp (72-90) (72) 29
D- 159	Pi stacker tube clip screw 8-32 x 3/18" 30 3:	D-5213	Pi stacker tube clip, intermediate 32
D- 534	Pi stacker tube clip, intermediate, screw 10-32 x 7/16" 30	D-5508	Pi stacker tube section clamp screw nut 5-40 x 1/16" 5-29-30-31-32
	Pi stacker tube clip, center 29	D-5585	Pi stacker tube clip 32
	Pi stacker tube clip, center, bracket 29	D-5585	Pi stacker tube clip, intermediate 30
	Pi stacker tube entrance 5 31	D-5586	Pi stacker tube clip 30 32
	Pi stacker tube extension 5-29 31		Pi stacker tube support (72-90) (72)
	Pi stacker tube extension (72-90)	D-5700	Pi stacker tube clip, upper 32
D-2230	Pi stacker tube clip, intermediate and upper 3:	D-6218	Pi stacker tube support stud 29-30
D-2714	Pi stacker tube entrance (72-90) 31	D-6426	Pi stacker tube entrance 29-30
D-2714	Pi stacker tube entrance 29-30	D-6551	Pi stacker tube bracket 30 32
	Pi stacker tube section clamp screw 5-40 x 3/8" 5-29-30-31-3:	E- 267	Pi stacker tube clip, intermediate, screw 6-48 x 3/16" 30
D-2749	Pi stacker tube section clamp screw nut 5-40 x 7/32" 5-29-30-31-3;		Pi stacker tube clip, upper, clamp screw 6-48 x 5/8" 5 31-32
	Pi stacker tube clip, lower 5-29 31	G- 118	Pi stacker tube support clip clamp
D-2815	Pi stacker tube support 20	0- 110	screw (72-90) (72) 6-46 x 5/8" 29
D-2816	Pi stacker tube support screw 1/2"-12 x 3/8" 29	1- 223	Pi tube bracket screw 10-32 x 5/16" 30 32
D-3279	Pi stacker tube extension 30 3:		
3219	a commence two execution 30 3:	321	Pi stacker tube support screw (72-90) (72) 29




A4 - J-I-	5-29-30-31-32	

Distributing Mechanism

Pi	Stacker	and	Tube	375

Distributing //techanism	Modela	J-2	J-30-31-32	II JIUCKEI	unu	· ube	313
D-2743 Pi stacker tube section, lower	. 3	11	D-5837 Pi stacker tube section, lower				31
D-2745 Pi stacker tube section, upper		32	D-5838 Pi stacker tube section, upper			3	0
D-2752 Pi stacker tube section, lower		32	D-5839 Pi stacker tube section, lower,	upper section		3	0
D-2752 Pi stacker tube section, lower, upper, center	30		D-5839 Pi stacker tube section, lower :				0
D-2754 Pi stacker tube section, upper		1	D-5841 Pi stacker tube section, lower			29	
D-2757 Pi stacker tube section, lower	29	- 1	D-5841 Pi stacker tube section, center			. 29	
D-2757 Pi stacker tube section, center	29	- 1	D-5843 Pi stacker tube section, upper			5.29	31
D-2757 Pi stacker tube section, upper center, lower center		- 1	D-5845 Pi stacker tube section, lower				32
and lower		32	D-5846 Pi stacker tube section, upper				32
D-2759 Pi stacker tube section, upper			D-5849 Pi stacker tube section, center				32
D-2761 Pi stacker tube, assembled	29		D-5850 Pi stacker tube section, lower :				0
D-2965 Pi stacker tube section, upper	29 3	1	D-5851 Pi stacker tube section, lower :				32
D-3170 Pi stacker tube section, lower	30	32					
D-3170 Pi stacker tube section, upper, center		32					0
D-3170 Pi stacker tube section, lower, center		32					81
D-3171 Pi stacker tube, assembled		92					32
D-3280 Pi stacker tube section, upper		3/2	D-6305 Pi stacker tube, assembled				
D-3285 Pi stacker tube, assembled		32	D-6306 Pi tube section, upper				
D-4584 Pi stacker tube, assembled			D-6453 Pi stacker tube section, upper			29	U
D-5150 Pi stacker tube, assembled		.	D-6454 Pi stacker tube, assembled			29	
D-5437 Pi stacker tube, assembled	20	32	D-6495 Pi stacker tube, assembled				32
D-5587 Pi stacker tube, assembled	30	32	D-6552 Pi stacker tube section, lower			. 3	
D-5701 Pi stacker tube, assembled		32	D-6553 Pi stacker tube section, lower			. 3	
D-5702 Pi stacker tube section, upper center D-5702 Pi stacker tube, assembled		32	D-6554 Pi stacker tube, assembled			3	
D-5746 Pi stacker tube, assembled D-5746 Pi stacker tube section, lower center	30	32	D-6555 Pi stacker tube section, upper D-6555 Pi stacker tube, assembled				32
							32
D-5750 Pi stacker tube section, lower center		32	D-6574 Pi stacker tube section, upper	and center		. 3	




					Electromatic Safety	511
		unit capacitor screw 8-32 x 3/8" .	29.30		Control unit terminal strip marker, short	29:30
		unit box cover screw cotter pin			Control unit receptacle, female (4), small	29 - 30
		unit box cover screw washer .196" x 5/16" x 1/16"	29-30		Control unit receptacle, female (10), large	
D-5725 C	Control	unit capacitor lock washer	29.30		Control unit box cover screw 10-32 x 7/16"	
E-2335 C	Control	unit support bracket screw washer 1/4" x 1/16" x 1/			Control unit resistor (1 megohm) (1/2 watt)	
E-4161 C	Control	unit selenium rectifier screw	29:30		Control unit resistor (270,000 ohms) (1/2 watt)	
		unit fuse holder support lock washer 6 x .065° x .044	29 30	F-8460	Control unit chassis and bracket	. 20-30
E-4605 C		unit selenium rectifier screw		F-8657	Control unit harness and transformer knife disconnect	29:30
	loc	k washer 6 x .066" x .044"	29:30	F-8690	Resistor (1000 ohms) (10 watts)	29-30
E-4605 C	Control	unit resistor terminal strip screw		F-8692	Control unit fuse receptacle and cover, assembled	29-30
	loc	k washer 6 x .055" x .044"	29:30	F-8693	Control unit transformer, assembled	29:30
		unit terminal strip screw lock washer 6 x .055" x .04	4" 29-30	F-8706	Control unit, assembled	29:30
E-4605 C		unit tube, thyratron, socket screw		F-8710	Wiring harness knife disconnect tubular insulator .	29-30
	lac	k washer 8 x .055" x .044"	29:30	F-8745	Control unit selenium rectifier	.29:30
		unit support bracket screw 14-24 x 3/8"		F-8754	Control unit selenium rectifier, assembled	29:30
		unit short terminal strip support screw 8-32 x 3/4"	29.30	G- 119	Control unit tube, thyratron, socket screw 6-48 x 1/4"	20:30
		unit support bracket, r.h.			Control unit resistor terminal strip screw 6-46 x 5/32"	
F-2161 C	Control	unit support bracket, l.h.	29.30	G-2772	Control unit terminal strip support screw 6-46 x 1/2"	20.30
F-2445 C	control	unit transformer washer 10 x 5/64" x 3/64"	29:30	1-2800	Control unit tube, thyratron, socket screw	
F-2478 C	control	unit fuse holder support screw 6-32 x 1/2"	29:30		nut 6-48 x 5/64" x 1/4"	29:30
		unit relay screw 6-32 x 1/2"		1-2800	Control unit terminal strip support screw	
		unit fuse holder support nut 6-32 x 5/18" x 3/32" .			nut 6-48 x 5/64" x 1/4" Control unit transformer screw 10-32 x 5/16"	29:30
F-4828 C	ontrol	unit transformer nut 10-32 x 1/8" x 3/8"	20.30	J- 223	Control unit transformer screw 10-32 x 5/16"	20:30
F-8355 C	control	unit tube, thyratron	29:30			
		unit capacitor stud			Parts Not Illustrated	
F-8378 C	control	unit capacitor	29:30	A- 998	Wire marker	20:30
F-8379 C	control	anit tube, thyratron, fastener	29:30	C-2078	Control unit main power supply cable, assembled	20:30
F-8380 C	control	unit tube, thyratron, socket	. 29:30		Control unit chassis jumper wire, assembled (506)	
F-8381 C	control	unit selenium rectifier .	29:30	F-8698	Control unit chassis jumper wire, assembled (512)	29:30
F-8382 C	ontrol :	unit resistor (150 ohms) (5 watt)	. 29:30		Control unit chassis jumper wire, assembled (513)	
F-8383 C	control	unit resistor terminal strip	29-30		Control unit chassis jumper wire, assembled (516)	
F-8384 C	control	unit relay	29:30		Control unit chassis jumper wire, assembled (514)	
F-8385 C	ontrol 1	unit terminal strip, long	29.30		Control unit chassis jumper wire, assembled (518)	
F-8386 C	ontrol :	anit terminal marker strip, long	29:30	F-8703	Control unit chassis jumper wire, assembled (519)	20:30
F-8388 C	control	anit chassis clinch nut	. 29-30	F-8704	Control unit chassis jumper wire, assembled (520)	20.20
F-8389 C	ontrol t	unit chassis, assembled .	29 - 30	F-8705	Control unit chassis jumper wire, assembled (517)	29-30
F-8396 C	ontrol a	anit box	29-30	F-8733	Control unit chassis jumper wire, assembled (511)	29:30
F-8398 C	ontrol :	unit terminal strip, short	29:30	F-8734	Control unit chassis jumper wire, assembled (515)	20.20



Distributing Mechanism	Models	29-30	Electramatic	Safety	379
A- 112 Matrix safety solenoid fastening screw 8-32 x 3/8"	29 30	F-8631	Control unit fuse, 2 amp		29-30
A- 885 Distributor matrix safety pilot light pad cover	. 29 30	F-8657	Wiring harness knife disconnect .		29.30
D- 534 Amplifier chassis screw 10-32 x 7/18"	29 30	F-8659	Matrix safety solenoid cover screw 8-32 x 3/8"		29.30
D-5640 Distributor matrix safety pilot light box receptacle			Distributor matrix safety pilot light		
screw 8-48 x 5/32"	29 30		Wiring harness receptacle nut 4-48 x 3/18"		29.30
D-6908 Pi stacker bracket extension, assembled	29:30		Spaceband lever keyrod spring eye		29 - 30
E- 219 Auxiliary, matrix safety, stop disk set screw 10-32 x 9/32"	30		Matrix safety solenoid extension adjustment nut		29.30
E- 219 Matrix safety, stop disk set screw 10-32 x 9/32"	30		Matrix safety bracket screw 5/18"-18 x 1/2"		30
E-1200 Auxiliary, matrix safety solenoid extension screw	30		Matrix safety disk pawl fulcrum screw		
E-1200 Matrix safety solenoid extension screw 10-32 x 3/18" x .44	75" 29 30		Auxiliary, matrix safety stop disk pawl spring sto		
E-1991 Wiring harness, fuse, terminal strip support screw 8-32 x	3/4" 29:30		Distributor matrix safety pilot light box bracket		
E-3816 Wiring harness, fuse, terminal strip washer	29:30		Distributor matrix safety pilot light box		
F-1383 Auxiliary, matrix safety bracket dowel .250" x 1 9/16"	30		Distributor matrix safety pilot light box receptac		29:30
F-2343 Distributor matrix safety pilot light box bracket			Matrix safety solenoid extension		
screw 10-32 x 1/2"	20	1-8271	Matrix safety stop disk pawl		30
F-2445 Amplifier chassis washer	29:30	1-8272	Matrix safety stop disk		30
F-4586 Matrix safety stop disk pawl spring 9/32" x 31/32"	29.30		Matrix safety solenoid bracket		
F-4586 Auxiliary, matrix safety stop disk pawl spring 9/32" x 31,	32" 30		Matrix safety bracket		
F-5545 Distributor matrix safety pilot light box cover	20.30		Distributor matrix safety pilot light box bracket		
F-8168 Wiring harness fuse wire terminal, blue	29:30		Channel entrance energizing switch cam follower		
F-8192 Distributor matrix safety wiring harness terminal, red	. 29	1-8655	Channel entrance energizing switch cam follower	screw	30
F-8192 Wiring harness, control unit, power section, wire termina	il, red 20:30		Energizing switch cam		30
F-8406 Control unit, female, plug, small		J- 794	Wiring harness receptacle screw 4-48 x 3/8"		29:30
F-8407 Control unit, female, plug, small, cable clamp		J-5498	Wiring harness receptacle screw washer .		29.30
F-8408 Control unit, male 10 angle 90°, plug	29:30		Th. 1 M. 1 M. 1 M. 1 M. 1		
F-8409 Control unit, male angle 90°, cable clamp	29:30		Parts Not Illustrated		
F-8412 Control unit, main and auxiliary, energizing switch	. 30	A- 998	Wire marker (801-609 incl.) (820-821)		30
F-8412 Control unit distributor shifter switch	29:30		Wiring harness, control unit, power section, asser		29.30
F-8429 Matrix safety main elevating shaft switch	29:30	F-8695	Wiring harness, control unit, amplifier, assemble	d	29:30
F-8430 Matrix safety main latch solenoid	29:30	F-8707	Distributor matrix safety wiring harness, assemb	led	. 29
F-8430 Matrix safety, auxiliary, latch solenoid	. 30	F-8730	Control unit harness, assembled		. 30
F-8601 Distributor matrix safety pilot light socket	. 29.30	G-4862	Distributor matrix safety cable		. 29
F-8619 Matrix safety solenoid cover	29.30	G-4865	Distributor matrix safety pilot light box, assembly	ed	29.30
F-8621 Matrix safety solenoid cover base, assembled	29:30	1-8267	Distributor matrix safety pilot light wire, assemb	led	. 29.30

D-6726 ASSEMBLY



Assembling Mechanism	Model 29	Assembler Entrance, Upper, Hand Shift 381
D-6166 Assembler entrance, upper, shift connecting link .	29 D-672	Assembler entrance, upper, shift connecting link,
D-6232 Assembler entrance, upper, connecting lever stop screw		upper, assembly (72-90)
D-6233 Assembler entrance, upper, connecting lever link pawl	stud 29 D-6728	Assembler entrance, upper, lever stud
D-6703 Assembler entrance, upper, connecting lever latch bloc	k 29 D-6725	Assembler entrance, upper, lever link
D-6704 Assembler entrance, upper, connecting lever latch		Assembler entrance, upper, shift connecting link turnbuckle . 29
spring plunger		Assembler entrance, upper, connecting lever latch washer 29
D-6705 Assembler entrance, upper, connecting lever latch spring		Assembler entrance, upper, connecting lever latch
D-6706 Assembler entrance, upper, connecting lever link latch	pawl 29	spring retainer
D-6707 Assembler entrance, upper, connecting lever link latch	1-563	Assembler entrance, upper, shift connecting link turnbuckle
pawl assembly		lock nut 5/16"-24 x 1/2" 29
D-6708 Assembler entrance, upper, roll lever locking screw de		Assembler entrance, upper, shift connecting link turnbuckle
D-6709 Assembler entrance, upper, connecting lever latch		lock nut, l.h.t. 5/16"-24 x 1/2"
block, assembly		Assembler entrance, upper, connecting lever latch spring
D-6712 Assembler entrance, upper, lever	29	plunger stud lock nut 10-32 x 5/16"
D-6724 Assembler entrance, upper, shift connecting link, upper	T (72-90) 29	
D-6725 Assembler entrance, upper, shift connecting link.		Parts Not Illustrated
upper, extension (72-60)	29 A-1006	Distributor bracket support
D-6726 Assembler entrance, upper, shift connecting link, upper		Assembler entrance, upper, shift connecting link rivet 29
	e Model and Serial Number	





Assembling Mechanism	Mode	1 29	Assembler Entrance, Upper, Hand Shift 383
D-6701 Assembler entrance, upper, shift bracket (72-90)	29	E- 539	Assembler entrance, upper, counterbalance weight rod lock
D-6713 Assembler entrance, upper, counterbalance weight .	29		nut 3/8"-32 x 1/8"
D-6714 Assembler entrance, upper, counterbalance weight rod	29	G-2891	Assembler entrance, upper, counterbalance weight lever,
D-6715 Assembler entrance, upper, counterbalance weight lever,			rod dowel
back (72-90)	. 29	G-3836	Assembler entrance, upper, counterbalance weight
D-6717 Assembler entrance, upper, counterbalance weight lever,			link turnbuckle . 29
back, screw	29	I-5631	Assembler entrance, upper, counterbalance weight
D-6730 Assembler entrance, upper, counterbalance weight link, long	29		link turnbuckle lock nut . 29
D-6731 Assembler entrance, upper, counterbalance weight link, short	29	I-5811	Assembler entrance, upper, counterbalance weight
D-6733 Assembler entrance, upper, counterbalance weight			link turnbuckle lock nut. l.h. 29
link, assembly	29		
D-6901 Assembler entrance, upper, shift bracket			Parts Not Illustrated
D 6902 Assembles entrance upper connecting layer step breaket	00	D 6702	Accomplicy entreprise common shift buselest concerbby (55 co.)



F-2462

Assemb	ling Mechanism	Model 30	Assembler Entrance, Upper, Hand Shift 385
C- 116 A	ssembler entrance, auxiliary, upper, operating handle dowel (D-7021 assembly)	D-6876	Assembler entrance, upper, counterbalance weight lever, back, screw
D-6217 A	ssembler entrance, auxiliary, upper, operating handle	D-6879	Assembler entrance, auxiliary, upper, counterbalance weight 30
	shaft bearing		Assembler entrance, auxiliary, upper, operator lever shaft
	ssembler entrance, upper, counterbalance weight	30	(90)-(72-90)(D-7021 assembly) . 30
	ssembler entrance, auxiliary, upper, counterbalance rod	30 D-7004	Assembler entrance, main, upper, operator lever shaft 30
	ssembler entrance, auxiliary, upper, operating lever link scre		Assembler entrance, main, auxiliary, upper, operator
D-6716 A	ssembler entrance, upper, operating shaft lever, front, screw		handle pointer 30
	ssembler entrance, upper, operating lever screw	30 E- 539	Assembler entrance, main, upper, counterbalance weight
D-6716 A	ssembler entrance, auxiliary, upper, operating lever link scre		lever, back, nut
D-6716 A	ssembler entrance, upper, counterbalance connecting		Assembler entrance, upper, counterbalance weight lever,
	link screw	. 30	back, screw washer 30
	ssembler entrance, upper, operating lever shaft		Assembler entrance, main, upper, operating handle set screw 30
	ssembler entrance, upper, counterbalance weight link (long)		Assembler entrance, auxiliary, upper, counterbalance weight
D-6731 A	ssembler entrance, upper, counterbalance weight link (short)	30	rod dowel 30
	ssembler entrance, upper, counterbalance weight link assemb	ly 30 G-3836	Assembler entrance, upper, counterbalance weight link
D-6851 A	ssembler entrance, auxiliary, main, upper, counterbalance		turnbuckle (D-6733 assembly) 30
	weight lever (back) (D-7055 assembly)	30 H- 56	Assembler entrance, upper, operator lever shaft, main, dowel so
D-6852 A	ssembler entrance, auxiliary, upper, counterbalance weight		Assembler entrance, upper, counterbalance connecting link
	lever (back) (D-7056 assembly)	30	turnbuckle, lower, lock nut
D-6856 A	ssembler entrance, auxiliary, upper, operating lever link		
	(length 7.5")	. 30	Parts Not Illustrated

D-7021 Assembler entrance, auxiliary, upper, operating handle assembly 30

back, assembled

30 D-7022 Assembler entrance, main, upper, operating handle assembly . . 30

30 D-7055 Assembler entrance, upper, counterbalance weight lever.

30 D-7056 Assembler entrance, auxiliary, upper, counterbalance weight


D-6860 Assembler entrance, auxiliary, upper, operating lever shaft

(90) = (72-90)

bracket (90)-(72+90)

D-6862 Assembler entrance, auxiliary, upper, operating handle


D-6861 Assembler entrance, main, upper, operating handle




Assem	bling Mechanism	Mode	1 30	Assembler Entrance, Upper, Hand Shift 38	87
B- 836	Assembler entrance, upper, connecting lever stop bracket scre-	w 30	D-6893	Assembler entrance, auxiliary, upper, shift connecting link	
	Assembler entrance, auxiliary, upper, connecting lever stop	30			
D-6716	Assembler entrance, auxiliary, upper, shift connecting		D-6894		30
	lever screw	30	D-6894	Assembler entrance, auxiliary, upper, connecting lever	
	Assembler entrance, main, upper, shift connecting link screw	30			30
D-6716	Assembler entrance, auxiliary, upper, shift connecting			Assembler entrance, upper, shift connecting link, assembly	30
	link screw .		D-6928	Assembler entrance, auxiliary, upper, shift connecting	
	Assembler entrance, main, upper, connecting lever screw	30			30
D-6716	Assembler entrance, upper, shift connecting link,			Assembler entrance, main, upper, connecting lever stop bracket	30
	assembly, screw	30		Assembler entrance, upper, connecting lever guard plate	30
D-6716	Assembler entrance, auxiliary, upper, shift connecting link,		F- 584	Assembler entrance, upper, connecting lever adjusting screw	
	assembly, screw	30			30
D-6850	Assembler entrance, auxiliary, upper, connecting lever		F- 584	Assembler entrance, auxiliary, upper, connecting lever	
	(D-7053 assembly)	30			30
D-6853	Assembler entrance, auxiliary, upper, shift lever	. 30		Assembler entrance, upper, connecting lever adjusting screw nut	30
D-6854	Assembler entrance, upper, shift connecting link, lower		G-3836	Assembler entrance, main, auxiliary, upper, shift connecting	
	(D-6926 assembly)	30		link turnbuckle	30
D-6858	Assembler entrance, auxiliary, upper, shift connecting link,		1-5811	Assembler entrance, auxiliary, upper, shift connecting link	
	lower (D-6928 assembly)	30		turnbuckle, upper, lock nut .	30
D-6865	Assembler entrance, upper, connecting lever pin	30	1-5831	Assembler entrance, upper, shift connecting link turnbuckle,	
D-6866	Assembler entrance, upper, connecting lever screw	. 30		lower, lock nut	30
	Assembler entrance, upper, shift connecting link			No. 1 AV 1 AV 1 AV	
	(D-6926 assembly)	. 30		Parts Not Illustrated	
D-6877	Assembler entrance, auxiliary, upper, shift connecting link		D-2985	Assembler entrance, auxiliary, upper, shift connecting link rivet	30
	(D-8928 assembly)	30		Assembler entrance, upper, shift connecting link rivet	
D-6893	Assembler entrance, upper, shift connecting link			Assembler entrance, main, upper, connecting lever, assembly	30
2-3000	(D.com assembly)	. 30		Assembler entrance, auxiliary, upper, connecting lever, assembly	30



Assembling Mechanism	Models	29-30	Assembler Entrance, Upper, Hand Shift	389
D- 145 Keyboard spaceband rod slide lever link dowel	29 - 30		Keyboard spaceband rod slide lever operating lever screw	. 29
D- 154 Keyboard spaceband rod lever slide link spring	29		Keyboard spaceband rod lever slide link, upper, nut	29
D- 802 Keyboard spaceband rod lever slide link nut	29:30	G-3085	Keyboard spaceband rod lever slide link housing bushing	
D-4666 Keyboard spaceband rod lever slide link housing bushing	29		set screw	29
D-4667 Keyboard spaceband rod lever slide link spring washer	29		Keyboard spaceband rod slide lever operating lever screw	29:30
D-4669 Keyboard spaceband rod lever slide link spring collar	29		Keyboard spaceband rod lever slide link screw	29 - 30
D-4670 Keyboard spaceband rod lever slide link spring collar pin	29		Keyboard spaceband rod slide lever operating lever	29:30
D-4671 Keyboard spaceband rod lever slide link spring housing	29		Keyboard spaceband rod slide lever link	29:30
D-6217 Assembler entrance, upper, fulcrum shaft, needle, bearing	, r.h. 29		Keyboard spaceband rod lever slide link (front)	29 30
D-6719 Assembler entrance, upper, operating handle	29		Keyboard spaceband rod lever slide link (back)	29:30
D-6874 Assembler entrance, upper, operating lever	30	1-8564	Automatic matrix guard lever, r.h., extension, front	29
D-6897 Assembler entrance, upper, operating lever shaft	29		Magazine elevating shaft crank shaft bracket	29
E-3479 Keyboard spaceband rod lever slide link, upper,		1-8580	Magazine elevating shaft worm gear housing tie rod bracket	29
nut lock washer	29	1-8583	Automatic matrix guard lever, r.h.	20



Assen	nbling	Mechanism	Models	29-30	Assembler	Entrance,	Upper,	Hand	Shift	391
BB-493	Keyboa	rd rod frame lever shaft collar	29-30	H-5705	Keyboard rod frame	lever shaft, s	hort (72-90			.29-30
		rd rod frame link lever stud nut		H-6101	Keyboard rod, long,	frame link le	ver bracke	l, l.h.		29.30
D- 802	Keyboa	rd rod lever slide link stud nut	29:30	H-6106	Keyboard rod, long,	frame operat	ing link, le	ogth 2 7/8	,	29.30
D-1344	Keyboa	rd rod frame operating lever screw	30	H-6186	Keyboard rod frame	link lever (L	-8477 assen	abled onl	v)	29 - 30
D-1344	Keyboa	rd rod, long, frame operating link screw	29-30		Keyboard rod, long,					29:30
D-1344	Keyboa	rd rod frame operating lever, back, screw	29:30	H-6433	Keyboard rod frame	operating lev	er, back (	0)		29.30
E-3816	Keyboa	rd rod frame link lever stud lock washer	29.30		Keyboard rod frame					20.30
		rd rod lever slide link stud lock washer	29.30		Keyboard rod frame					29:30
F- 689	Keyboa	rd rod, long, frame link lever bracket screw	29:30	H-6475	Keyboard rod frame	link, r.h. (72-	90)			29 30
F- 689	Keyboa	rd rod, long, frame link lever bracket, l.h., screw	29.30		Keyboard rod frame					29:30
G- 781	Keyboa	rd rod frame lever shaft screw	29:30		Keyboard rod frame			72-90)		29:30
G- 781	Keyboa	rd rod frame lever shaft, assembled, reed rack scr	ew 29·30	H-6478	Keyboard rod frame	lever shaft. 1	ength 12 3/	3"		29:30
		rd rod frame lever shaft pin 1/8" x 11/16"			Keyboard rod frame					29:30
H- 144	Keyboa	rd rod frame lever collar set screw 8-32 x 5/18"	29 - 30	H-6502	Keyboard rod frame	operating lev	er .			. 30
H-2843	Keyboa	rd rod lever slide link lever (D-6479 assembled on	ly) 29:30		Keyboard rod frame			rew		30
		rd rod frame link lever stud			Keyboard rod, long,					29.30
H-2848	Keyboa	rd rod lever slide link stud	29:30							
H-4459	Keyboa	rd rod lever slide, r.h., stud	29:30		1	Parts Not Illus	trated			
H-5704	Keyboa	rd rod frame lever shaft connecting bracket (72-90		H-6480	Keyboard rod, long,	frame, assemi	oled (90) .			20.30



Assembling Mechanism	Models	29-30	Assembler	Entrance,	Upper,	Hand	Shift	393
D- 154 Keyboard spaceband rod lever slide link spring	29	I-5660	Magazine elevating	crank drive	shaft clutch	shift lev	er	
D-4666 Keyboard spaceband rod lever slide link housing bushing	29		link (lower se	ection) .				30
D-4667 Keyboard spaceband rod lever slide link spring washer	29	1-5660	Magazine elevating	crank drive s	haft clutch	shifting	lever	
D-4669 Keyboard spaceband rod lever slide link spring collar	29		link (interme	diate section)				. 30
D-4670 Keyboard spaceband rod lever slide link spring collar pin	29	1-5661	Magazine elevating					
D-4671 Keyboard spaceband rod lever slide link spring housing	29		link (interme	diate section)	pin		alle recei	. 30
D-6217 Magazine, auxiliary, elevating shaft crankshaft bracket,		I-5661	Magazine elevating					
needle bearing	30		link (lower se	ection) pin				30
E- 539 Magazine, elevating crank drive shaft clutch shifting lever		1-7589	Magazine elevating	crank drive s	haft clutch	shifting	lever	
link (intermediate section) lock nut	30		link (lower se	ection)				30
E- 539 Magazine elevating crank drive shaft clutch shift lever		1-7590	Magazine elevating	crank drive s	haft clutch	shift lev	er	
link (lower section) lock nut	30		link-(upper se	ection)				30
E-3479 Keyboard spaceband rod lever slide link (upper)		1-8384	Magazine elevating		haft clutch	shift lev	er	
nut lock washer	. 29		link (lower se	ection)				- 30
G- 744 Keyboard spaceband rod lever slide link (upper) nut	29		Pivoting, front, guid					30
G-3085 Keyboard spaceband rod lever slide link housing bushing		1-8709	Magazine elevating					
set screw 4-48 x 5/32"	29		link, assemble	ed				- 30
H- 602 Pivoting front guide holder balance spring lever fulcrum		I-8721	Magazine elevating	crank drive s	haft clutch	shifting	lever	
screw 3/8"-16 x 2 1/4" x 3/4"	. 30		link (upper se	ection)				30
H-6438 Keyboard spaceband rod lever slide link (front)	. 20			Parts Not Illu	-11-3			
H-6439 Keyboard spaceband rod lever slide link (back)								
H-6440 Keyboard spaceband rod lever slide link, assembled (90)	29	I-8696	Magazine elevating	shaft crank s	haft bracke	t .		30



D-979











C-39







1-250 1-730














Assembling Mechanism	Model	30	Assembler Entrance, Upper, Hand Shift 395
C- 39 Magazine, auxiliary, elevating drive shaft, vertical, washer nu C- 535 Magazine, auxiliary, elevating drive shaft, gear housing cover screw D- 979 Magazine, auxiliary, elevating drive shaft, vertical,	30	I-5117	Magazine, auxiliary, elevating drive shaft, horizontal, ball bearing 30 Magazine, auxiliary, elevating drive shaft, vertical 30 Magazine, auxiliary, elevating drive shaft, vertical, gear key 30
ball bearing cap screw  D- 979 Magazine, auxiliary, elevating drive shaft, horizontal, gear ball bearing cap, front, screw			Magazine, auxiliary, elevating drive shaft, horizontal, gear ball bearing, cap, front 30 Magazine, auxiliary, elevating drive shaft, horizontal, gear
D- 979 Magazine, auxiliary, elevating drive shaft, horizontal, gear ball bearing cap, rear, screw E- 69 Magazine, auxiliary, elevating drive shaft, vertical, universal	30	I-5121	ball bearing, cap, rear 30 Magazine, auxiliary, elevating drive shaft, vertical, ball bearing, cap 30
joint pin  E- 738 Magazine, auxiliary, elevating drive shaft, gear housing screw	30	I -6388 I -7600	Magazine, auxiliary, elevating drive shaft, vertical, washer 30 Magazine, auxiliary, elevating drive shaft, horizontal,
F-5436 Magazine, auxiliary, elevating drive shaft, vertical ball bearin I-4924 Magazine, auxiliary, elevating drive shaft, horizontal, coupling, rear, pin		I -8268	coupling, rear 30 Magazine, auxiliary, elevating drive shaft, gear housing 30 Parts Not Illustrated
i-5061 Magazine, auxiliary, elevating drive shaft, gear housing cover 1-5098 Magazine, auxiliary, elevating drive shaft, vertical, gear 1-5099 Magazine, auxiliary, elevating drive shaft, horizontal, gear	. 30	I -8694	Magazine, auxiliary, elevating drive shaft, housing, assembled so









Part No. A B-85. %x16 B-210. %x20	в %	e %	D % 1%	
<b>BB-175</b> %x16	11/6	$1\frac{1}{2}$	13%	
F-31¼x20 F-370¼x20	1/o 1/4	1/a 1/4	1/4 1/4	
I-740314x24	11	11	1/4	
	11		% %	

Table 3



Dia. &		Dia. & Thread	
B-236¼x24	B 11/4	G-7398x32 G-910/4x24	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
D-998x32 D-3048x32 D-21728x32	1¼ 1¼	G-9328x32 G-1402½x24 G-16116x48	1 2 1/4 2 1/
D-2471. 16x18 D-3042. 10x32 D-4381. 8x32	141001400	G-2023%x16 G-28775x40 G-399010x32	21/4 11/4
D-56418x32 D-61946x48	%	H-11244x48 H-360710x32	1 <sup>1</sup> /a
E-25. 8x32 E-27. ½x24 E-194. ½x16 E-219. 10x32 E-424. ½x24 E-503. ½x18 E-3674. ½x24	14	I-5. %x16 I-567. 10x32 I-681. 8x32 I-1322. ½x24 I-1821. ½x24 I-1873. %x18 I-2536. %x18	1% % 13 1% 1% 1%
F-14.	1% 1%	I-2795. \$\frac{2}{3}\text{x32}\$ I-5301. \$\frac{1}{3}\text{x24}\$ I-5536. \$\frac{1}{3}\text{x12}\$ I-5581. \$\frac{2}{3}\text{x18}\$ I-5582. \$\frac{2}{3}\text{x18}\$ I-5683. \$\frac{1}{3}\text{x49}\$	1%
G-113. %x16 G-127. %x16 G-1568x32 G-4156x48 G-4166x48	13 1/4 .325	I-6238. 4x24 J-182. 4x48 J-6444. \$\frac{x}{2} \text{x}18 J-6550. 5x40	2½ 1½

Table 4



Part No. A D-17524x48	в .200	c .122
E-5278x32	1/4	1/4
G-126.	% % % 1/2	****
I-477\%x24 I-1028\%x16	11 11	Ĥ
<b>J-804</b> 8x32	10	%

Table 5



J-1086....10x32

Table 6



Part No.

F-267.....6x48 F-2478....6x32

F-3115....8x32 F-3230....10x24

F-3260....6x32 F-5847...10x32

G-117.....6x48 G-118.....6x48

G-119.....6x48

G-121.....6x48

G-125.....6x48

G-142....6x48 G-1998....6x48

H-1138.....5x40

I-1981....6x48

I-3599....5x40

I-4057...6x32 I-6146...10x32 I-6830...5x40

J-223....10x32

J-375.....8x32

J-453.....8x32

J-794.....4x48

T-1922 10+22

J-5148....5x40 J-5497....4x48

J-5501....10x32

I-705....10x32 1 kg

Dia. & Part No. 14x24 ----8x32 ...8x32 B-96.....4x48 B-217.....8x32 BB-148.....8x32 ŵ D-34.....8x32 D-85.....4x48 145 D-120.....4x48 D-159.....8x32 D-326 ....8x32 D-341....14x21 D-526.....4x48 D-534....10x32 D-713....4x48 D-868....10x32 D-1401....8x32 D-1402....8x32 D-4103....10x32 D-4383....8x32 D-4411....8x32 D-4455....8x32 D-4456....4x48 D-5588....4x48 D-5589....8x32 D-5590....8x32 D-6063....4x48 E-192.....4x48 \* E-2062....4x48 F-97.....8x32 F-112....14x24

2555



Part No. A-864	Dia. & Thread A 4x 18	в %	e de	D Tr
B-99 B-264 B-828	8x32	% †	1/4 1/4 1/4	A 20 20 21
BB-138		1/4	%	ŵ
C-231		1/4	1/4	Ve.
D-168 D-177 D-3067 D-3126 D-3144 D-4373 D-4495 D-1732 D-1742 D-4777 D-4816 D-818 D-8595	.4x48 .8x32 .8x32 .8x32 .4x48 .4x48 .4x48 .4x48 .4x48 .4x48 .3x48 .3x48 .3x48 .5x40 .4x48	公司大会会会上各个公司	107 107 108 1100 1100 1100 1100 1100 110	270 253 253 253 190 190
E-119 E-145	6x48 .14x24	1/4 1/2	Å	žį.
F-1266 F-6952	.¼x32 .¼x24	18 5%	1/2	%
G-122 G-123 G-354 G-1635 G-2763 G-3154 G-5197	.6x48 .6x48 .6x48 .4x48 .6x48	私意在表表的	.177 % % 6.5 .065	11 14 14 14 12 19 161

Table 7-Continued Dia. & Thread Part No. H-207. H-353. H-978. .....8x32 .....8x32 .....8x32 H-4438. .....8x32 I-665......8x32 I-6014.....10x32 Table 8 - c-Dia. & Thread Part No. A-555....%x16 1% B-74.....%x16 % C-150....\%x24 C-535....10x32 C-536....8x32 C-842....\%x16 D-31.....34x16 D-101.....4x48 D-131....34x16 D-141.....\4x24 ....½x24 ...%x16 D-567

Table	8-0	Contin	ued	
Dia. & Thread Part No. A D-684.	B 1/2 1/2 1/2 1/2 1/2 1/2 1/2 1/2 1/2 1/2	C 1/2 12 1/2 1/2 1/2 1/2 1/2 1/2 1/2 1/2	D 111 125 135 135 1437	1000000000000000000000000000000000000
	% % 1	% % % % %	\$100 mm 100 mm 1	NAME AND ADDRESS OF
F-64 ½ x24 F-236 ½ x24 F-1991 8x32	17	1/2 1/2 1/4	% 12	Ż
G-131 ½x24 G-282 10x28 G-2772 6x48 G-2795 10x32	1/4 9/4 1/6 1/6	1% 1% 1%	% % %	4000
H-602. %x16 H-1585. 8x32 H-2290. %x24 H-3800. 8x32	21/4 1 1/4 1/4	94 3/6 3/6 5/6	% 13 11	克克
I-568. 10x32 I-1276. 10x32 I-4763. ½x24 I-4821. 10x32 I-5166. 8x332 I-5221. ½x16 I-5656. ½x16 I-5656. ½x16 I-6256. ½x18 I-647. 10x32 I-547. 10x32 I-547. 10x32 I-547. 10x32 I-547. 10x32 I-5674. ½x18	2 %	% % % % % % % % % % % % % % % % % % %	\$1,248 \$2,248 \$1,000 \$1	**************
J-2477. 10x32 J-3809. 4x48 J-4716. ½x24 J-5518. ½x24 J-5563. 5x40 J-6223. 8x32	% % 33 1% 1%	% 115/2 1/2 1/2 1/2	.185 .187 .167	2012/04/2012

Table 9



\*

120

"放我以要玩

% .075 %


Dia. & Thread A B

B-61510x32 B-7994x48 B-83610x32	100 1100 1100 1100	% 1%	1150 1150	ÿ.	E-28008x32 E-3819½x24	1/4 1/6	1/4	1/4 5/4
C-42%x16 C-142%x16	7/4 9/4	% %	**	Å.	F-65	.715 15 15	1/4	40
D-86. 8x32 D-846. 6x48 D-971. 8x32 D-978. 10x32 D-979. 10x32 D-1231. 10x32 D-2432. 3xx16	0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.0	***************************************	V4. 17.4 17.4 17.5 17.5 17.5 17.5 17.5 17.5 17.5 17.5	\$ 100 KK	F-1806. 3x40 F-2771. ½x24 F-2791. ½x24 F-5705. ½x24 F-6155. 4x48 F-6783. 10x32 F-6828. ½x24	STATISTICS	*****	***********
D-2934 8x32 D-3044 8x32 D-3559 10x32 D-3667 2x64 D-4686 4x12 D-4793 10x32 D-5255 4x48 D-5445 8x32 D-6427 4x12	17 189 454 174 374 374	17/2 11/2 11/2 11/2 11/2 11/2 11/2 11/2	218 24 323 34 34 34 34 34 34 34 34 34 34 34 34 34	**************************************	G-274 8x32 G-304 4x24 G-308 4x24 G-809 4x18 G-1173 8x32 G-1213 8x32 G-1283 5x40 G-3283 5x40 G-3285 5x40	%	%专口工工	14 11 11 14 14 14 15 15 16 16 16 16 16 16 16 16 16 16 16 16 16
D-6428½x12 D-658210x32 E-9½x24 E-3564x48	ŵ				H-518	% % U	% %	12.00
E-377. 8x32 E-922. 154x18 E-1024. 14x24 E-1126. 8x32 E-1522. 15x24 E-1589. 8x32	% 1% 1% 1%	% ************************************	**********	*****	I-403 8x32 I-627 6x48 I-1682 10x32 I-2031 10x32 I-3207 ½x24	14 1/4 1/4 1/4 1/4	% % %	14 PARTS

Dia. & Thread A

Part No.

Table 10



J-1404....1/4×24

Table 11



Table 12





ï	bread						
Part No.	A :	n	C	D			G
D-52711	0x32 -	Dr.	A	.310	1/4	1/4	3/6
	4x24	Œ	5%	.374	.192	1/2	.162
D-6282	4x21 3	%	%	.374	16	1/6	20
G-3976	%x16	Per	ŵ.	.500	Te.	%	%

Dia. & Thread						
Part No. A.	В	c	D	10	F	G
I-799410x32	13	10	.312	35	1/2	À
J-6253 1/4×24	2%	%	35	vir.	1/2	3/4

Table 13



Part No.

Dia. &

Cv49

.8x32 370 .182

8x32

....8x32

364

 $\frac{1}{197}$ 

11 222 18 .225

% .162 % .162

.230

381

607

G-3998....10x32

G-4036....8x32

H-139.....8x32

H-140....8x32

H-1341.....8x32

H-2361....8x32

H-1765 ....8x32

H-2870. ...8x32

H-2871. ..10x32 .310

H-3224 ...8x32

H-3721 .10x32

H-3827 ...8x32

H-4446. ....8x32 37 8

I-233. I-374.

I-2079. 10x32

I-4488 10x32

I-5154

T-5499 .8x32

I-5623

I-5905 14x24 2.483 100

I-5910. 16x24 2.109

I-6216

J-465 10x28

T-4919

J-5383.

J-5722

J-5767 ....8x32

Part No. B-19..... 1/2 x12 B-636.....8x32 % .312 .286 D-354.....8x32 .130 D-532.....8x32 245 .197 ů D-840....\%x24 20 D-1377.....8x35 .160 D-1386....8x32 D-1898....8x32 .292 .292 245 .130 D-2299....8x32 245 .097 D-2739. ....8x32 .067 D-2780 .200 .200 .070 D-2941 ...8x32 .055 D-3326 .245 .130 307 D-4263 ...4x48 .067 D-4502 .8x32D-4664 .130 D-5013 .093 D-5124 .506 509 405 297 D-5988. D-6658. .8x32 .282 .245 .197 .282 .8x32 .096 18 F-1466. .10x32 3/4 .161 G-197... .8x32 G-318.....1/4x24 .310 1.255 G-781. 4x24 374 374 .410 G-1588 ...8x32 120 G-3800...10x32 G-3833...10x32 248 .130

Dia. &

.248 .130 .120 .248 .192 .315 .245 401 .245 255 ins .250 .090 .245 .197 % % .307 .067 4444 .130 .090 .197 066 169 135 .194 130 .252 .230 248 1.885 200 .130 .278 442 % 11 13 437 341 .686 1.765 .686 1.609 .266 11 151 .248 .130 .343 .248 .192 .120 .105 .248 .130 .245 .245 .270 317

Table 14



.028

Part No.

Dia. & Thread

218 .370 .218 .370 .248 .250 .312 .034 .251 1.130 B-843....10x32 B-856....14x24 D-1064.....4x48 \$ \$2 320 D-1301...4x48 D-1606...%x16 12 1/2 1/2 1.250 1.56 126 .067 .126 .067 1.165 2.614 120 120 D-1867....5x40 D-3816....10x32 D-4719. ..4x48 ,050 D-4936 437 .435 .373 .435 . 14x24 .293 .050 AxIS 17 .136 D-5231 .5x40 312 312 .199 .067 15 .082 D-5320 .10x32 D-5492 ....8x32 .065 の古古古古古 D-6151.... 1/4 x 24 124 D-6191....8x32 .249 D-6290....6x32 E-103.....6x48 E-4065....10x32 249 F-5529....10x32 .377 .310 .375 .247 .749 1.252

Dia. &

B-805.....8x32

Part No. A

G-3995....<sub>1</sub>Ex18 G-4036....8x32 343 ,523 交交 南京 G-4119....8x32 H-2490....%x11 15% .374 H-2847.....8x32 10 10 271 1/1 .249 .249 .244 .310 .500 .251 .220 力力力力 H-2848....8x32 3 271 H-2884....10x32 H-4079....1/4 x 24 I-2695.....5x40 .122 .034 I-3584. ....8x32 .248 .249 .498 .120 .314 1.130 10x32 I-4486. % .432 I-5165 186 .375 .250 .436 14 .249 .280 .374 .373 I-5626 6x48 I-5923 I-5963 I-6320 I-6321 .8x32 I-6326. ....8x32 I-6399....10x32 I-7610...4x18 I-7829...4x18 19 495 J-1784....6x48 .187 .068 福福寺 % -536 J-6380..., x18 .373 .310 .253 % .089 J-5381....4x24 áã .130 J-6382... 1/4 x 24

Table 15




	Dia. & Thread						
D-215	A 8x32	B 1/4	C 1/4	.245	.317	9/ <sub>0</sub>	G Ve
D-232	8x32	3%	74	.188	311	78 9%	3%
D-548	8x32	sh.	1/1	2,8	.067	1/1	3/a

Table 16



Table 17



	Dia. &	_					
Part No. D-185	A .8x32	B 25 25	c tr	.098	E 1 <sup>t</sup> c	y vir	G tr
E-187 E-1265	1/4x24 .4x48	*	1/2	.124	1/6	%	1/4 1/4
G-99 G-429 G-787	.8x32 %x16 10x32	Ž.	Ż	.092 .121	% %	Ż	400
I-1930	-5x32	ŵ	ŵ	1/4	*	76	1/4

Table 18



Dia. Thre	A ad					
Part No. A	В	C	D	30	y	G
D-9914x4	8 🔥	44	.080	20,	- A	J.
D-47706x4		7	A	32	X	5%
D-62428x3	12 🐔	36	.123	11	14	14
E-403	8 11	11	3/4	21	1/4	3.
E-1737%x1	6 11	10	34	11	*	ŵ.
G-114%x1	6 %	2/6	.245	2	1/6	1/4
G-27898x8	2 1	3/4	.110	5%	1/4	⅓a ⅓6
H-47954x4	8 %	ŵ	12	15	12	10
I-276714x2	2 .183	.183	12	3/6	%	.129





Table 23




Part No.	Α	В	Part No.	Α	В
A-120	250	- Ar	G-229	.09375	11
			G-246	.1875	15
D-323	. 1/4	11	G-357		.151
D-403	0625	81	G-397	.125	4.1
			G-632	.09375	3.5
E-231		% .225	G-3162	.0625	.395
E-243 E-466	· 10	.225	G-3226	.15625	1/4
E-466	063	.942			
E-1079	. 16	.942	H-192	.09375	放
			H-567	.21875	1/0
F-723		14			
F-5854	1875	12	I-114		3/4
			I-299		1
	09375	16	I-1079	3/4 .	13/4
	09375	1/4 1/2 1/62			
G-162		.162	J-479	.09375	.56
	09375	.190	J-763		13%
G-164	09375	% **	J-3756	.0625	11
G-228	09375	str.	1		

Table 24







.1107 .0881

.1693

.2084 1237

.1978

.1693

.2292

.1216

D-107. 41
D-336. 173
D-376. 173
D-940. ¼
D-1525. ¼
D-1857. 173
D-1880. 31
D-3815. 41
D-3815. 41
D-3227. 505
D-5914. 505
D-6190. 11

E-525 255 3 E-2746 25 7 E-306 11 1/2 F-592 630 14 F-593 630 14 F-594 630 14 F-7125 4 1/2 F-3264 630 15 F-3264 630 15 F-3264 630 15

Table 27



Part No. A A-116	B 1/2	C %	Part No. A G-956. 5x40	В	c
B-237	% %	16	G-10534x48 G-3398½x24 G-36472x18	立及主	C 1/4
BB-22110x28 BB-247%x11 BB-270%x20	1/4	11/6 11/6 11/6	H-74210x32 H-40368x32	4 2222	**
C-93%x16 C-297%x18	1/4 1/4	1/2 1/2	H-4075%x20 H-4108%x24 I-186%x16		
D-8028x32 D-5298%x16 D-55085x40	lh. %	拉	I-25151x8 I-28006x48 I-30676x18	200	1/2
E-165. %x16 E-430. ½x12 E-539. %x32 E-947. ¼x32 E-3720. ½x18 E-2739. ½x24 E-3265. 8x32	N	%15%%%% %15%%%%%	I-3089. ½x12 I-4495. ½x32 I-4528. ½x32 I-5040. ½x11 l.h. I-5207. ½x24 I-5508. ½x16 I-5631. ½x24 I-5811. ½x24	24人成功以及在我在我	SALES SALES AND SALES SA
F-234410x32 F-23998x32 F-55994x20 F-74154x24	I.h.	74 THE P.	I-6148	夏花	1/2
G-744 <sub>1</sub> 5x18	14	10	<b>J-463</b> ¼x24	ŵ	%

Table 28



Part No. Diamete	er	
G-33. 173 G-107510 G-394. 1½ G-1134. ½ G-1135. ¾ G-1168. 1½ G-2748. 1½ G-3078196 G-3952. ½	3/3/2/2/2/2/2/2/2/2/2/2/2/2/2/2/2/2/2/2	125 125 126 127 126 127 126 127 126 127 126 127
H-352	% % % %	100000000000000000000000000000000000000
I-2422 /4 I-2240 /4 I-3134 /125 I-3874 /093 I-4527 /577 I-4881 /1 I-972 /1 I-5510 /1 I-5570 /2 I-6378 /2 I-6378 /2 I-6388 /4	% % % % % % % % % % % % % % % % % % %	.280 15 .1875 .0625 16 17 16 17 16 17 17 17 17 17 17 17 17 17 17 17 17 17
J-5180 29 J-5375 332	.623	.005 1

Table 29



Part No. A B-4 1 / 5 B-75	n 1% 341 1%	C Ne. of Cotts  78 5 .135 15 .020 13 .175 47 .4 61/2 .024 43 .024 29	D-4648 15 D-5325 15 E-935 15	n 1% %	C Cetts .063 9 .022 10½ .040 9	Part No. A G-3926	n 1111 1111	No. of Colls .011 10 .032 2½ .055 10 .048 13
B-75   18   19   19   19   19   19   19   19	131 2-14 3 1/4 2 1/4 2 1/4 2 1/4 1 1	% 6½ 43 .024 43 .024 43 .024 43 .024 43 .024 7 .028 12 .034 8 .100 3 .024 11 .025 18 .024 5 .026 6 .030 10	F-357 300 F-2014 †† G-32 % G-58 †† G-78 †† G-78 †† G-86 230 G-422 † G-672 † G-1955 320 G-1218 † G-3773 † G-3972 † G-3972 / G-3972 †	1 % 110 110 110 110 110 110 110 110 110	.040 11 .063 6 .049 10 .024 8 .016 12 .016 13 .048 6 .059 12 .070 9 .032 3 .042 46 .071 9 .063 3½ .040 14	H-1020 .181 H-1225 .181 H-2254 .28 H-2650 .28 H-2650 .49 H-3051 .49 H-3054 .49 H-3054 .49 H-3054 .49 L-6647 .49 L-6041 .14 L-6147 .337 L-6147 .337 L-6147 .337	% 5% 1% 1% 1% 1% 1% 1% 1% 1% 1% 1% 1% 1% 1%	.028 6 .028 7 .051 36 .034 12 .026 22 .046 6 .055 14 .57 80, 51/4 .042 6 .054 0 .040 7 .063 5

.024 .032 .032

.060 .036

Table 30



Part No

G-3406 G-3992 .160

Part No.

D-1378 .164
D-1384 ...
D-14073 ...
D-40618 ...
D-4061 ...
D-4062 ...
D-4062 ...
D-4062 ...
D-4062 ...
D-47705 ...
D-5013 ...
D

G-67. G-183







No. -1502	Bolt Sixe ¾	A di	B de	Part No. Stre F-2438 1/4	.109	3
-4534	$\chi^{0}_{ij}$	16	de.	F-2445#10 F-6655#10	2	1
-1654 -3479	1/4	4	10 to	G-2852 31	gA <sub>4</sub>	,
-3816 -4605	#8 #6	10 10 10 10 10 10 10 10 10 10 10 10 10 1	.044	J-6496#10 J-6498#4	.062 .047	j

.055 .086 .024 .146 .025 .074 .020 .020 .028 .063 .034 .010 .032 .0188 .018 .040 H-567. 1 H-1767. 1 H-2879. 1 H-2886. 5 H-3582. 100 H-3959. 1 H-5305. 100 .020 .024 .020 .020 .020 .020 I-808.... 1 I-1014....5725 .028 .024 I-1027 ... 1/4 I-1173 ... 1/3 .036 .063 .046 .050 .046 .114 .026 .045 .020 .063 .032 .032 .040 .063 .024 .114 .055 .114 .025 .045 .024 .024 .025

I-7414

I-7778... 15 I-7993... 1/4 I-8044... 1/4

.018 .024 .013 .028 .024 .024

## Table 32





Dia. & Thread				Dia. & Thread			
art No. I-5158	. 1/4×24	1/4	C 1/	Fart No. A I-5908 34x24	В	C 1/2	
I-5509	1/2×12	94	33	I-5909 4x2		73	
I-5527 I-5583 I-5872	3 x18	10 10 10	% % %	J-6182 1/4×24	4 3/2	de.	
1-00/2	748.04	34	78	1			

D-549 to D	-4457		INI	DEX TO PARTS 413				
D	D	D	D	D	D	D	D	D
Part Page 549 224	Part Page 840 146	Part Page 1231 35	Part Page 1660 234	Part Page 2422 244	Part Page 2934 248	Part Page	Part Page	Part Page
238	336	46, 52, 88	1662 234	2425 246		3198 210	3341	4170 252 4202 252
558	P2, 242, 246	134, 152, 166 214	1663 204	2452 182 184, 220, 256	2941 220 2944 68	3200 210 3202 230	3346 248 3348 254	4203 252 4205 248
567	847	1271 362 1273 342	1699 372 1711 222		256	3205 221	3350 216	4206
568 248		1274 362	1721	2463 978	2949 256	3209 214	3351 256 3332 256	4207 248 4211 242
570 244 571 248	875 . 224	1280 342 1282	1722 234 1725 234	2471 116 2503 342	2951 256 2954 216		3353 256 3354 257	
572 TO TO 186, 242, 248	882 234 905 92	1289 372	1724 234	2504 342		3211 258 3215	3353 256	4217 246 4218
254, 326	922 244	1302 256	210, 216	2505 342 2512 342	2973	3219 268 3220 268	3356 257 3357 . 254	4221 246 4272 241
573 248 582 . 263	923 244 924	1344 390 1361 248	1752 254 1765 182	2556 204 210, 218	2985 33T 2987 202	3230 248		4225 246
583 263	940 14	1361 248 1377 234	250	2603	2996 256	3233 948	3359 254 3361 252	4263 40 4283 210
584 8 56, 172, 178	950 86	1378 216	1844 220	2622 268 2626 239	3011 232 3012 232	3234 . 248 3242 . 210	3374 234 3375 234	4292 210 4341 210
601		1384 300	1805 154	2678 202		3245 230	3396	4351 236
248, 256, 252	965 36	112, 114, 232	1806 203	2678 202 2714 372 2731 244	3614 232 3615 232	3244 210 3245 230	3397	2354 220
646 248	112, 190, 252	1401 126	1856 230 1857 230	2735 202 2736 204	3019 233 3024 230		3404 64	
657 146 246, 302, 310	971 60	194, 954, 336	1867 84	210, 218	3025 230	236	3413 234	4364 248 242
663 241	972 . 38	1402 14 26, 108, 254	1882 86 1886 252	2739 10 2743 374 2745 374	3040 930	3250 236 3253 366	3497 232 3546 268	4365 242 4366 242
670 244	973 984	1604 258, 294, 366 254	1888 260 1889 260	2745 374 2745 372	3041	5259 254		
672 246	974	258	1890 . 240	2749 372	102, 230, 314	3260 254 3261 254	3557 248 3568 122	4372 942 4373 242
675 0	977 168	1434 252 1438 214	1891 210	2752 314 2754 314	3043 230	3262 254 3263 254	3615 100 102, 120	
677 224	978 86 112, 120, 146	1436	1896 230	2757 . 314	52, 188, 192	3264 254	3621 248	4379 234 4380 234
692 260	152	1434 244	1893 6	2759	246, 344, 346 3045 268	3265 254	3624 254 3634 224	4361 248 4582 210
693 210 694 240	979 48 48	1459 236 1462 234	1903 144, 246 210		3046 248	3266	3635 224 3663 . 246	4383 104
696 200	100, 184, 190	1475 230	218	2778 252 2779 254 2780 254	3053 270	3269 252	3664 246	4389 201
697 200 698 200	212, 214, 312 394	1477 158 1483 204	1965 262 1966 234		3035 270 3056 270	3279 312 3280 314	3665 248 3666 248	4390 236 4400 210
699 200	983 210 987 202	1525 188	1975 210 2031 232	2782 252 2789 248 2790 246	3057 270 3058 270	3281 372		4401 210
713 10 10	991 816	190	2159	2790 246	3661	3284 210	3668 248 3669 246	4402 210 4403 204
714 8	1012 302	1535 120 148, 178, 208	2172 234 234	2791 . 244 2792 . 244	3062 270 3063 210	3285 374 3287 244	3670 242 3614 254	4404 216 204
715 248	1015 258	210, 340, 302 322, 356, 362	2182	2842 . 234	3067 12	3288 270	3816	210. 214
717 30 46, 116, 268	1028 146	1548 220	2210 248 2211 248		3070 234	3289 . 270 3292 . 234	3818	4406 210 4409 204
210	1029 . 202 1030 . 108	252 2549 216	2211 248 2227 372	2807 263 2807 263 2808 213	3072 234 3073 234	3293 301	3819 254	210, 218
779 72	1034 26 1046 254	1574 8 18, 22, 24, 26		2809 290	3074 214	3294	3821 254 3831 244	4410 210 4411 . 226
782 224	1049 248	252, 204, 362	2228 312 2230 312 2245 264	2813 261	3075 234 3080 270	3297 362 3298 362	3852 244 3856 231	4413 242
783 224 802 4	1063 254 1064 . 254	1582 80 232	2262 220 220	2815 312 2816 312	3126 36	3299 342 3300 342		
8, 10, 28, 46 48, 54, 56, 60	1045 254	1587 120	263	2819 248	3141 96	3301	4959 230	4426 238 4427
68, 72, 105	1123 216	1605 306	2296 216 2299 254	2823 252 2913 214	3142 248 3145 268	3302 342 3316 202	4066 230 4067 258	
122, 126, 174 184, 262, 210	1152 . 90 234	1636	2299 254 2314 248 2317 248	2913 214 2915 216 2916 256	3146 110	3317 202	4069 258	4429 236 4432 238
224, 232, 234	1168 150	1638	2327 263	2918 256	263, 312 3147 248	3318 204 3319 201	4070 218	4431 235 4432 234
236, 252, 264 278, 288, 294	1170 234	1639 252 1651 252	2332 263 2333 263	2919 248 2920 176	3149 248 3134 244	3324 232	4071	
360, 314, 316 324, 324, 388	1221 254 1224 254	1653 814	2340 248	2922 234	3158 220	3326 192	4073	4435 236 4436 236
390	1227 234	1657 234	2414 224 2415 224	2923 234 2924 244	3162 208	3327	4103 258 4156 268	4437 236 4435 82
829 204 839 23	1229 220	1658 234	2416 224 2417 224	2925 256 2929 242	3169 370	3333		226
24, 268, 216	248	1659 234	2418 225	2933 248	3170 374 3171 374	3338 248 3340 268	4165	4456 82 4457 210

					_			_	_
D		D	D	D	D	D	D	D	D
	Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Pa
0	. 210	4649	4720	4811 166	4929 174 4930 174	5055 180	5198 234 5199 234	5283 174 180	5411
		4650 183	4722 160 4723 100	4812 . 214	4933 176	5054 186 5055 221	5200 . 281	5284 174	5413 1
3	366	4651 180 4652 194	4724 268	4813 214	4934	5057 176	5201 284	180	5415
MI	362	368		4814 216	4935 174	182	5208 174	5285	5417
18	208	368 4656	4726 208	4815 216	4936 176 4939 194	5061 221 5089 172	5209 184 5209 184	5286 182 5287	5427
5	. 208	4637 . 180 4638 . 174	4727 208 4728 184	4816 216	4948 238	5090	5211 264	5288 182	
9	236	180	4729	4817 . 208 4818 . 208	4941 . 194	5091 172	5212		5432
2	236	4659 182	4731 164	216	4942 194		5215 373	5290 182 5291 172	5437
5	36	4661 194	4732 160	4819 208	4945 802	5095 172 5094 172	5214 . 386 5215 . 386	178	5445
48, 52, 238	220	182	4733 100	4820 216 4821 208	4944 194	5096 172	5216 218	5292 178	5452
4	46	4665 174	4740 160	4822 216	4946	5097 172	5218	5295 178	5453
54		182	4741	4822 216 4823 . 204	4947 104	5101 232	5219 . 364	3294 172 178	5454
			4742 160	4825 204 4826 208	4949 194 4961 173	510Z 280 5103	5220 221 5221 232	5295 172	5456
1	208	4663 198	4745 160	4827 246	4962 195	5105 184	5222 234	178	5479
3	240	4666	208, 212, 216	4828 216	4965 208	5106 182	5223 214	5296 178	5481
		196, 392	4745 204	4829	4964 106	5108 104	5225 . 212	5297 178	5487
	. 312	4667 60	4747 230	4830 203 4831 106	4966 230	5109 242 5112 244	5226 160 5227 252	5298 172 178	5489
	874	4668 190	4748 238 4751 212	4831	4968 172	5113 248	5228 174	5299 118	5490
1.	863	4669	4752 212	4838 216	4980 221	5114 243	180	5300 178	5491
COMMO	302	104, 302	4757 234	4838 . 216 4839 216	4983 108	5124 242	5229 164	5301 178	5492
	. 302	4678 60	4758 234		4991 104	5125 246 5126 248	5230 221 5231 208	5302 58 60, 166, 168	5495
	. 302	72, 106, 392	4765 216 4766 216	4841 214 4844 208	4992 194 4994 194	5129 244	5232 208	196	5496
	362	4671 60 196, 892	4766	4844 208 4845 208	4995 104	5130 244	5233 234		5498
	202	4672 100	4768 202	4847 202	4996 194	5131 244	5237 284		5499
2 5	221	4673 100	4770 216	4849 203	258	5132 244	5247 220	5306	5500
	174	4674 190	4771 160	4856	4997 238 4998 104	5135	5248 252	5306 178	5502
184	174	4676	4772	4859 104	5001 194	5138 244	5249 168	5309	5503
184		4680 174	4774 208	4861	5002	5139 242	5250 214		5304
7	174	182	4775 210	4962 168	5009 210	5140 242	5251 100	5311 172	5505
184		4681 176	4776 104	4864	5010 230	5141 . 248 5142 240	5252 . 160 5254 . 160	5313 172	5507
184	174	4682 110	4777 164 4778 208	4867 218	5011 230 5013 230	5143 244	5255 166	5314 172	5507 5508
9	174	182	216	4868 216	5014 280	5144 249	5256	5315	5524
184		4683 176	4779 164	4867 218 4868 216 4869 216	5015 230	5147 244	5257 166	5316 172	5525
	184	182	4780	218	5016 232	5148 248 5150 374	5258 164 5259 164	5317 178 5321 172	5527
	184	4684 176 183	4781 . 214 4782 . 214	4872 118 4876 118	5017 232 5018 230	5151 . 179	5260 163	5322 172	5548
184	1. 114	4685 182	4783	4877 182	5019 231	5152 178	5261 106	5523 194	5549
	182	4686 300	4784 268	172, 178	5020 131	5154	5262 100 5265 100	5324 194 5525 194	5550
1	182	4687 170	4785 . 216	4880	5023 108 5024 208	5155 106	5264 100	5326 194	5558
182	176	4688 174	4786 . 216 4787 . 208 216		5029 208	182	5265 105	5328 196	5559
7	189	184	216	4885 194	5030 208	5156 104	5266 166	5360 243	5563
*	110	4699 179		4883 194 4884 190	5034 178	5157 2(8	5267	5361 244 5364 242	5572
182		4700 178	4789 . 216 4790 208		5035	5158 . 214 5159 104	5268 166 5269 166	5365 242	5574
	182	4701 194 365	216 208	4886 194 364	5037 178	5159 164 5174 172 178 5175 372	5270 168	5367 246	5585
5	100	4702 118	4791 208	4887 173		178	5271 166	5368 246	5586
	180	4704	4792 166	4888	178			5369 . 244 5370	5588
		4705 174	214		5042 164 168, 172, 178	5179 372 5185 243	5273 166	5372 244	5589
		4708 00	4793 . 214 4804 . 166	4915 281 4916 306	5843 172, 178	5186 244	5274 168	5392 250	5590
1	180	106, 168, 214	4805 166	4917 203	5044 182	5187 242	5275 . 180		5591
		4709 178	4806	4918 216	5045 180	5189	5276 180 5277 180		5592
4		4710 119	4807 214	4919 196	5046		5278	5394 286 5400 184	5597
5	. 180	4715 196	4808 166	4920 196 4924 208	5047 180 5048 180	5191 221 5193 238	5200 . 180	5401 164	5598
6	182	4715 238 4716 238	4809 168	4924 208	5049 180	5194	5281 189	5402 164	
182	176	4718 196	214	4926 174			5282 114	5410 204	5640
8	180	4719	4510 166	4928 174	5052 180	5197 234	180	210	5641

_				1		1			41
	D	D	D	D	D	D	D	E	E
art		Part Page	Part Page		Part Page	Part Page	Part Page	Part Page	Part Pag
42	218	5856 243 5887 243	6185	6290 168 6291 214	6450 238 6451 238	6585	6731 382	84	527
48	216	5898 . 224	6166 18:		6451 . 238 6452 238	6586 248 6590 . 230	6735 384 382	164, 214, 272 324	539 1
		5898 224 5965 230	190		6453	6591 231	884	90 4	\$22, 382, 3
	210	5988	6187 18		6454 374	6595 232	6850	128, 132, 138	392, 313
	230	5995 216 5996 216	6188 180	6301 198	6455 164 6456 200	6596 . 232 6597 232	6851 334	140, 252, 263	738
77	234	6011 . 374 6012 . 374 6013 . 374			6457	6598	6852 384 6853 386	98 302	124, 128, 1 168, 190, 2
		6012 374	6189 18	6310 190	6458	6599	6854	100 220	
79 80	234	6014 374	190		6459 198	6615 193	6856 334	258, 850, 354	921 3
81 .	234	6017	6190 181 195	6318 198 6320 214	6460 . 168 6461 . 198	6616	6858	103 40 119 . 38	
82	235	6018 366	6191 18:	6324 190	6462 198		6861 384	208, 216, 288	922
		6019 302			6463 188				935
85	235	6020 362 6021 362	6192 180 6193 180	6327 214 6328 198	6464	6625	4865	145 56	
56 .		6022 362	100	6329 192	6466 198	6638 168	4874 384	165 144	947 2
37 .	230	6023 302	6194 240			6641 200		102, 204, 210	134, 146, 5
	210	6024 362 6025 362	6200 181	6347	6471	6642 238	6877 386	218, 258	1020
	210	6026 368	182 181	6348 196	6472 238	6650	6878 384 6879 381	326 248	30, 46, 52
00	372	6027 362		6352 198	6474 238	6652 230	6895 384	175 174	146, 166, 5
		6048 364 6051 242	190	6355 200		6652	6895 384 6894 384	248, 274	288
3	374	6052 244	6208 181 6209 181	6357 191 4353 192	6488 232 6489 232	6654 103 6656	6897 388 6901 382	184 8	1079
14	210	6056 244	192	6359 192	6490 232	6657 218	6902 382	90, 276, 346 187 172	248
9	210		6210 181	6360	6491 232		6908 378	190 386	
0	210	6063	190	6361 . 192	6492 232	6659 216	6926 386	192 26	1200
4	. 210	6015	6211 200 6212 191	6364	6493	6660 243 6661 243	6928 384	40, 18, 234	1265
		6066 243	6215 201	6389 236	6495		6976 221 7603 384	230, 244, 248 194 252	1466
15 .		6048 244	6216 . 189 6217 . 384	6390 168		6668 244	7004 384	368	
ه ،	210	6073 242	388, 392	6392	6528 306 6529	6668 244 6679 243 6680 243 6686 237	7005		1522
17 :	210	6076 . 244	6218 371	6305 198	6539 244	6686 257	7009 . 334	106, 110, 125 204, 312, 3TS	1589 54, 88
9 .	210	6077 216	6232	6396 232	6540	6687 207	7021 384 7022 385	302	1654
2.	234	6078 243 6081	6233 386 6234 166		6541 364	6688 248	7049 384	224 132	
¥ .		6063 244	6236 386	6404 234	6542 361 6543 361	6690 248	7053	288, 324	1991
7.	. 284	6008 243	6237	6405 234	6545 364	6691 268 6701 382	7054 387	231 300	2012
ĸ.	374	6120 188	6238 10	6406 257	6546	6703 380	7055 885	245 201	
0	374	6141 188	6239 169 6240 169		6347 302 6343 304	6704	7056	267 64	2335
2 .	202	100	6241 . 168	6410	6549 302	6705 380 6706 380		301	188, 190,
з.	203	6142 188	6242	6414 190	6350 366	6707 180	E	304 . 36 46, 308	
9 .	202	6143 148	6243 168 6244 168	6415 190 6426 378	4551		9	356 286	2615
0 .	232	6147		6427 194	6553	6709 380	28, 130, 136	370 324	2720 154
1.	282	6150	195	364	6554 374	6712 380 6713 382	178, 306	371 328	106, 116,
2.	232	6151 188	6259 190	6428 104	6555	384	25 46	377 . 168	344, 346
4	232	6164 198 6166 198	6267	6429 194	6557 362 6558 364	6714 382	194, 328, 348 27	260 190	2739
7	214	389	6268 168	364	6565 . 342	384	54, 142, 160	424	178, 188
8	256	6170 192 6174 185	6269 214	6430 200		6715 . 382 6716 . 384	168, 212	332	2779
5	232	190	6270 190 6271	6432 221	6567 . 362 6568	386	38	135 102	2800
7 .	374	6176	6272 199	6433 208	6571 216	6717 382	153, 249, 956	466 248	2878
	374	6177 188	6273 190	6435 230	6572 366	6719 388 6720 384	366	484 98	
	374	6178 188	6274 . 190 6282 . 190	6436 231 6437 . 231	6574 374 6576	6724 380	42 236 274, 278	502 88	5235 1
3.		130	6283 199	6438 166	6577 364	6724 380 6725 380	45 28	503 100	3265
5.	374	6179 188			6578 364	6726 350	64 212	102, 116	168, 174, 1
0 .	374	6180 198 6182 188	6285 165 6286 190	6440 238 6441 238	6579	6727 350 6728 350	69 28	523 8	182, 184, 1
0.	374	6185 188	6287	6441 238 6443 238	6581 198 6582 214	6729 310	124, 394	188, 190, 236 324	190, 230, 1 314
1	374	6184 188	6288 199	6444 238 6449 238	6583 242	6730 382	75 28 348	525 142	3306
5 .	242	190	6289	6449 238	6584 246	884	82 284	268, 278	312

416			. IN	INDEX TO PARTS				E-3479 to G-2361		
E	F	F	F	G	G	G	G	G		
Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page		
3479 60	244 128	2462 384	8383 376 8384 376	33 364, 346	136	244 288	892 312	352 310		
134, 144, 196 388, 383	267 30	2478 190	8384 376 8385 376	34	48, 53, 56	246 130	910 54	1538 320		
3613 198	38, 90, 136	2479 316	8386 376	36	106, 112, 114 142, 148, 234	274 38	263, 212, 340 344, 846, 350	1540 . 320 1541 338		
3635 353	284, 286, 212 372	2625 98 102, 384	8388 376 8389 376	48 310 50 368	272, 360, 312	48, 52, 76, 89	354, 316	1547		
3674 148	357 264	2721 116	8395	310 51	316, 324, 336 142 82	86, 88, 100 102, 140, 184	912 276 932 276	1548		
3752	370	2771	8396 376 8398 376	58 330	230, 234, 376	934, 535	937 284	1566 368		
3816 126	463 8 54, 74, 104	2791 176 182, 252	8399 376 8402 376	67	144 286 145 286	277 . 280 282 313	938 192, 340	1567 310 1584 368		
174, 184, 188 182, 236, 252	105, 134, 136	2914 122	8402 376 8403 376	70 974	152 79	304	939 100	820		
376, 310	198, 203, 310	3115 134	8406	77 914 78 914	140, 196, 226 276, 314, 364	36, 72, 132 190, 200, 263	102, 188, 190 294, 328	1587 122 1588 278		
3819 188 3839 220	216, 226, 294 296, 308, 334	3230 258	8407 378 8408 378	79 914	155 . 286	320, 330, 358	955 264	1589 . 278		
264	496	3260 92	8409 378		156 51	308 8	956 46	1590		
3848 220	548 200	3854 200	8412 378 8427 376	95 280	70, 138, 232	136, 208, 358		1611 72		
3850 \$20	300	238	8428 376	204	284, 394, 344 340	322 144	1055 40	1635 74 59		
3851 220	584 . 213 236, 386	3899 08	8429 378 8430 378	96 286 98 286	157 286	346 . 100	244, 248, 346	256		
264	592 144	3969 116	8460 376	99 286	158 284		318	1636 332 1666 320		
3959 106 4065 36	593 368	4016 140	8601 578 8619 378	201	286, 294	334	1061 332 1065 288	1670 212		
4161 376	594 366	4586 378	8621 378	101 280	284, 282, 303	219, 309, 332	206 206	1682 . 274 1778 . 50		
4453 264	689 58 46, 54, 60, 86	4797 53 114, 364	8631 378 8659 378	102 286	160 286	357	1065 288	1783 252		
4455 964	210, 154, 200	4828 376	8690	204	206, 284, 292	374 180	1069 288	252, 360 1801 310		
265 220	340, 346, 366	5436	8691 376 8692 376	204 204	309	394 352 397 52	1071 288	312		
4457	717 30	304	8693 376	106 284	284, 288, 293	268, 336	1107 326	1806 316 1821		
4458 244 4459 220	46, 58, 236 258	5463	8694 879 8695 379	107 284 28	206	404 218	1134 190 1135 128	1881 310		
265	723 126	5527 142	8696 271	106 284	164 284	416 220	1168 134 1173 . TO	1883 310 1933 332		
4695 184 214, 376	810 54	5529 316 5545 378	8699 377 8699 377	113	296, 28G, 200 167 234	429	94, 338	1934		
4691 200	869 100	5599 72	8700 271		280, 284	432	1194 154	58, 72, 74 169, 176, 166		
	102, 140, 150 203, 348	5705 280	8701 STT 8702 STT	117 64	178 310 179 208	436	1213 . 74	214, 333		
_	861 154	5847 56	8703 377	79, 192, 284	181	312	174, 184	1938 350 1947 310		
F	904 136	3854 136 6014 146	8704 377 8703 277	118 281	160, 164, 212 214	439	1218 . 326 1269	1973 300		
14 218	1125	6103 388	8706 376 8707 379	292, 328, 338	336 272	613		1974 200 1996 284		
31 280 106	1266 . 232	6155 98	8710 . 876	119 379 8	190 158	614 286	1354 276	286		
110, 138	1383 378	6195 504	8711 . 378	64, 95, 168 202, 210, 216	197 8	645	1345 296 1354 276 1370 326 1371 274	2001 333		
64 28 154, 158, 212	1806 104	6296 130	8730 879	218, 250, 286	12, 172, 280	661 212	2,572 274	2016 314		
295, 224	1991 18	6359 281	8734 877	284, 992, 314 396, 376	198 280 201 208	666 184	1398 188	2017		
97 14	34, 340, 344 856	6655 280	8745 376 8754 376	121 230	204	698	1400 288	2029 368		
22, 24, GB	2160	6828 188		284, 286, 202	205	128, 152, 268 216, 285, 310	1402 288	2030 368		
112 4	2343 195	6952 40		122 . 284	219 284	312, 332	1404 288 1408 278	2042 288		
	312, 378	7415 56	G	123 48 284, 292, 302	220 \$86	739 94	1409 278	2043 368		
104, 296, 316 202 188	2344 54 100 122	7449 52 7847 106	7 368	125 236	221 310 228 284	744 60	1438 . 284 1459 . 288	2084 312		
	146, 340	243, 270, 276	12 158	286, 362	292, 310, 333	196, 388, 392 781	1460 288	2085		
120, 150	188, 102	8168 378 8192 378	13 308	126 312 334	286, 288	336, 390	1461 284	2178 284		
52	2438 6	8355	14 368	127 286	240 . 58 116 124 178	787 130 509 138	1479 284 1480 284	2199		
233 379 235 130	58, 188, 190 336, 338	8376 376 8378 . 376	15	129 308	188, 198, 276	829 294	1524 . 310	2260 330		
276, 318, 344	2443 40	8378 . 376 8379 . 376 8380 . 376	308, 320	130 308 131 270	288, 390, 326 330, 364	836 314 888 314	1525 . 310	2308 300		
236 112	48, 176, 182 236, 264, 312	8381 376	18 308 320	280, 308	241 280	889	1526 210	336, 352		
356	376, 378	8382 316	32	132 274	243	850 314	322	2361 286		

G-2362 to				DEX TO PA	KIS .	1		417
G	G	G	G	G	G	G	G	н
Part Page 2362 284	Part Page 2891 134	Part Page 3156 . 300	Part Page 3547 210	Part Page 3819 305	Part Page	Part Page	Part Page	Part Pag
2362 284 2370	138, 302, 384	3161 300	3347 320 3348 320	3819	3885 296 3886 296	3994 313 3995 313	4488 332 4489 332	15
332 332	2896	3162 322	3349 822 3350 822	3821	3387 296	3996	4490 332	26, 174, 189
332	2905	3163 300 3164 300	3350 322 3351	3824	3888 288 3889 293	3997 312 3998 312	4491	24
389 286	2929 344		3353 320	3826 328	3890 293	3999 64		25
1413 286 1415	2949	3175 300 3176 300	3355 328 3356 320	3827	3893 328 3894 292	128, 158, 263 312	4503 312 4508 206	96
1465 328		3177 300	3357 332	3829 \$28	3895 292	4029	4509 907	46 36, 48, 52
382	2991 294 2994 294	3178 302 3179 302	3358	3830	3896 392 3897 . 292	4933 286 4934 286	4514 394 4516 328 4519 384	56
300, 528	3001 302	3180 300	3363 330	328	3898 292	4936 . 286	4510 325 4519 324	310, 322, 33 384
1578 849 1615 . 30	3002 302 3003 302	3183 300 3186 . 302	3364 294	3832 828 3833 . 812	3899 392 3901 328	4037 286		71
218, 302, 358		3190 836	3369 . 284 3370 . 294	3833 . 812 824, 328	3902 328	4038 286 4040 286	4521 324 4522 324	46, 54, 58, 6 146, 300, 3
3616 90		3192	3371 394	3834 312	3903 828	4041 386	4923 . 100	390
1670 . 274	3007 300 3008 300	3193 286 3197	3372 354 3373 292	3835 524	3905 216 3906 216	4042 320 4043 322	4524 334 4540 292	74
	3009 800			3836		4044 322	4543	79
677 302 694 302	3010 300 3011 300	3199	3376	142, 156, 312 324, 380, 382	3911 320 3912 321	4045 322 4046 329	4545 993 4561 314	26
748 338	3012	3201 274		384, 386	3917	4047 320	4562 . 320	122
763 22 772 194	3013 . 592 3014 . 592	3203 328 3204 323	3381	3837 324 3838 328	3923 320 3924 320	4062	4601 524	26
374	3015 349	3205 322	3386 . 294 3396 . 280 3398 6	3839 262	3925 320	4066 213	4602 . 334	128
773 300	3016 302 3017 303	3209 302 3210 300	3396 280	3840 252 3841 254	3926	4070 280	4603 324	139 * 1
775 300	3018 302	3226 292	56, 58, 100	3842 294	3928 330	4071 . 340	4604	140 10
	3023 300		103, 109, 112	3843	3929 320	4183 324	4622 316 4623 . 316	10, 05, 08
780 3(0)	3028 320	3252 202	116, 160, 162 166, 183, 188	3844 394 3845 . 293	3930 . 399 3936 324	4684	4624 316	102, 103, 19
781 300	3030 322	3253 202	190, 196, 214	3846 913	3937		4625 316	198, 334, 34
782 300 787 300	3032 320 3034 326		276, 289, 319 328, 330, 338	3847 214 3848 212	3939 203 3940 201	4086	4626 316 4627 316	352, 354, 39
789 300	3035 326	3275 . 322 3276 322	846, 386	3849 204	3942	4088 200	4628 316	16
790 38	3036	3277	3404 320 3405 310	3850 294 3851 110	3944 296 3946 216	4089	4629 316 4630 316	152
148, 174, 17G	3038 320		322	228	3948	4112	4630 516 4631 816	165
182, 184, 184 268, 230, 268	3043 322	3288 . 556 3289 . 308 3290 308	3414 216 3445 320	3852 278 3854 206	3949 328 3950 328	4117 102 100, 314	4432 316	38, 48, 52, 6
310, 316, 324	3045	3290	3448 350	3855 302	3951 328	4118	4633 . 818 4634 . 810	254, 238, 31
328, 330, 346 368, 378	3047 . 328 3051 320	3291 310 3292 310	3538	3856 294 3857 294	3952 328 3955 328	4119	4635 336	170 1
792 302	3032 320	3293 310	3566 310	3858 20¢	3962 328	4120 312 4121 312	4637	171 1
793 300	3063 300 3077 280	3298 308 3299 308	3567 310	3859 293 3860 216	3963 324 3964 328	4122	4639 286 4640 284	26
795 300	3078 182	3306	3568 310	302	3974 290	4122 . 312 4126 . 312 4127 . 313	4641 286	94, 142, 150
797 122	3079 188, 190, 332 3079 233	3308	3569	3861 296 3862 296	3975 , 296 3976 , 296		4644 291 4651 320	180, 230, 23
799 302	3061 232	3311 384	3574	3893 296	3977 396	4146	4652 520	360, 336, 34 333, 354, 35
316	3085 60	3313 284	3581 284	3864 216	3978 296	4294 230	4653 320	181 14
902 174	3090 336	3315 284	3582 . 284 3583 284	3865	3979	4295 280 4296 280	4654 330 4655 320	182 1
170, 182, 184	3091 326	3318	3587 340	3868	3981 . 312	4358 324 4359	4656 329	184 4
294, 332	3092 326 3094 276	3328	3592	3869 324 3870 234	3982	4399 324 4362 328	4657 329 4658 330	192 7
28 300	3095 276		3397 329	3871 296	3984 288	4372 324	4638 330 4659 320	94, 386
31 302 45 278	3096 276 3106 294	3333	3610 399	3872 296	3985 288 3986 314	4373 328	4669 320	108, 266
52 164	3131 , 382	3337	3635	3873	3987 314	4394 328	4661 220 4667 220	221
214, 384 65 280	3133	3340 320 3341	3637 322 3635	3875 202 202	3988	4397 322	4667 320 4687 320	289 1
67 274		3342 333	3769 320	3878 213	3990 314	4401 324 4422 396	4710 320	304 1
72 286 73 286		3343 328 3344 328	3800	3881 296 3882 296	3991 314	4426 324	4814 320	306
74 286	3154 300	3345 320	3810 313	3883 297	3992 314 3993	4440 . 324	4862 319	308 1
377 72	3155 310	3346 330	3811 314	3884 294	312	4463	4865	326

2369 2376 2377 24, 68, 116 154, 198, 248 2379 2405

2440 16 16 16

-	-
418	
н	н
Part Page	Part Page
352 102	978 23
116, 158, 210	999 16
218, 276	1000 16
353 76	1001 14
84, 90, 96	316 313
112, 114, 116 134, 242	1070 28
374 250	1000 4
375 4	1082 4
250	1083 4
387 72	1115 150
96, 104, 198	1124 10
457	1138 176, 189
54, 96, 116	212, 265
142, 154, 183	1233 310
463 204	322
210, 218, 302	1240 72
472 8	226
104, 110	1241 4
489 10	1255 849
490 10	1299 274 1327 16
503 36 48, 58	
304 16	25, 72
28	1365 6
318 36	1438
44, 52, 58, 00	166
132, 154, 158	1482 4
160, 100, 192	28
533 14	1516
535 52	48, 52
72, 202	1585 . 14
544 28	26
GE	1586 12
535 12	20
557	1765
566	48, 52, 70, 74
567	1767 4
	20

2239 2240 2241 8 8 8 2449 2450

н	н	н	н	н	н
Part Page	Part Page	Part Page	Part Page	Part Page	Part Page
2455 8	2545	2654 43	2734 43	2841	3689 40 3690 33
2456 8 2458 8	2546 93 2547 33	2655 43 2656 43	2735 43 2736 43	2843 . 36 54, 60, 390	3690 38
	2549 33	2657 43	2737 43	2846	3693 38
2466 . 12	2530 23	2658 43	2738	2847 46	3694 60 3695 40
2467	2551	2659 43 2660 43	2739 43 2740 43	54, 56, 60 104, 388, 350	3696 38
	2554	2660 43 2661 43	2740 43 2741 43	2848 46	3697 38
2468 12	2353	2662 43	2742 43	54, 310	3702
2469 13 2472 12	2556 . 33 2558 . 33	2666 43 2667 43	2743	2850 58 2851 54	3703 40 3704 38
2473	2559	2668 43	2745 43	2852 54	
2478	2560 38	2669	2746 43	2455	45
2480 4	2562	2670 43 2672 43	2747 43 2748 . 43	2854 54 2855 54	3744 33
2482 4	2565 33	2673 43	2749 43	2856	3745 83
2483 18	2566 . 33	2674 43	2750 43	2857 56	3765 16
2484 18 2485 18	2567 33 2569 33	2675 43 2676 43	2753 43 2754 48	2838 56 2839 56	3765 16 3768 40
2486	2569 33 2570 33	2676 43	2756 43	2850 56	3769 40
2487	2571 33	2678 43	2758 43	2861 56	3770 . 60
2490	2573 33 2579 0	2679 43 2680 43	2760 43 2762 43	2862 56 2865 56	3772 41
2492 6	2579 0 2580 18	2681 43	2764 43	2867 56	3773 40
2495 6	2589 40	2682 43	2766 43	2868 56	3774 41
2494 6	2592 10	2683 43 2684 43	2768 43	2869 - 56	3775 . 14 3778 . 14
2495	2594 10	2685 43	2772 43	2871 56	3784 26
2497 8	2595	2686 . 43	2774 43	2580 58	3785 26
2498 8 2499 8	2598 40 2601 12	2687 43 2688 43	2776 43 2778 43	2885 . 56 2884 . 56	3786
2502	2607 10	2688 43	2780 43	2885 56	3748
52	2609 10	2690	2782 43	2889 926	3789 - 26
2505	2610 10	2691 43 2692 43	2784 43	2897 . 18 3198 40	3790 26 3791 26
2506 40 2507 40	2611 10 2612 12	2693 43	278K . 43	3213 10	3792 26
2515	2613 4	2694 43	2790 43	3216 10	3793 . 26
	2614 8	2695	2792 43	3215	3794 52
2517 36	2616 8	2696 43 2697 43	2794 43 2796 43	3216 - 10 3217 10	3795
2518	2618 8	2698 43	2798 43	3218 . 10	3796 36
52		2699 43 2700 43	2800 43 2802 43	3219 10 3220 48	3796 36
2339 36	2626 . 48	2701 43	2004 43	3221 . 202	3799 52
2520	2627 48	2702 43	2896 43	226	3800 52
2521	2629 46 2632 48	2703 43 2704 43	2810 . 43	3224 902	3611 28 3612 30
2521 37	2633 48	2705 48		3225 4	3813 30
2522	2634 48	2706	2814 43	3241 146 214, 380	3814 20
2523 23	2635 48 2636 48	2707 43 2708 43	2816	3549 8	3815
2525 23	2637 48	2709 43	2820 43	3550 8	3617 39
2526 23	2638 43	2710 . 43	2822 43	3551 8	3818
2527	2639 43 2640 43	2711 43 2712 43	2824 43 2826 43	3552 . 8 3577 38	3819 30 3820 30
2528 23 2530 33	2641 . 48	2713 43	2828 43	3578 . 38	3821 30
2531	2612	2714 43	2831 36	3582 28	3822 26
2532 :	2643 43 2644 43	2715 43 2719 43	2832	3391 88	3825
2534	2645 43	2723 43	2833 54	104	3825
2536 33	2646	2727 43	2834 54	3607 148	3826
2538	2647 43 2648 43	2728 43 2729 43	2835 54 2836 54	3682 38 3683 60	3827 30 3828 20
2540 33	2649 43	2730 43	2837 54	3684	3829
2541 38	2650 43	2731 43	2838		3830 26 3831 28
2542 33 2544 38	2652	2732 . 43 2733 . 43	2839 54 2840 54	3687 40 3688 38	3831 28 3832 28
- The 111 11 19	. 2000	2122	2010		

н	н	н	н	н	н	н	H	Н
Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Pag
833 26 834 26	3899 22 3900 23	4039 6	4150 51	4489	4785 8 4786 8	5526 18 5528 58	5702 86	5775 6
835 25	3901	4041 6	4154 51	4491 51	4787 8	5529	5703	48
	3902 28	4042 6	4156	4492 51	4789 8 4796 8	5530 58	5764 . 46	5775
337 26 339 26	3903 28 3904 28	196	4158 51 4159 51	4494 51	4791 8	5531 58 5533 38	5705 46	5776
340 26	3907 28	4044 56	4161 51	4496 51	4794 48	5534	390	5780
341 26	3916	4045	4165	4498 51 4500 51	4795 48	5535	5708 36	5781
342 26 343 26	3911 28	4046 196	4165	4500 51 4502 51	4796 48	5537 36 5538 36	5709 36	5782
144 26	3915 28	4047		4584 51	5277 56		46	5791 . 5792
45 28	3918 8	4049 51	4171 51	4506 51	5278	5541	5710	5793
146 22 147 22	3919 8 3928 8	4050	4173 51	4508 . 51 4510	5281 . 54 5282 . 56	5542	5711 48 48	5794
48 22	5921 202	4052 56	4177 51	4512	5285 56		5714 40	5795
24	224	4055 55	4179 51	4514 51	5284 60		5715 40	5796
349 22 350 22	3923	4056 . 55 4057 . 16	4181 51 4183 51	4516 51 4518 51	5285 60 5288 56	5546 ω	5716	5798
24	3925 6	4029 38		4520 51	5294 . 40	5547 60	5718 46	5799
51 22	3926 6	4060	4187 51	4522	5295		54	5800
24	3927	4063	4189 51 4196 52	4524	5296 40 5297 40	5549	5719 86 5720 86	
52 22	3950 6	4063	4191 68	4528 51	5298 38	5551 60	5721 36	5803
54 22	3951	4066 14	4192 52	4530 51	5300	3552	5724 45	5804
155 22	3952	4067 14 4075 56	4193 8	4532 51 4534 51	5301 . 40 5302 . 40	3553 (0	3727 45	
56 22 57 22	3934 4	60	4195	4556	5303 40	5620	5728 40 5729 41	5807
59 22	3935 6	4078 54	4196	4538 51	5304 40	5622 23	5730 18	2808
60	3937 54 3938 182	4079	4197	4540 . 51 4542 . 51	5309 28 5316 28	24	5751 - 45 5732 - 45	5810
61 22 62 22	3939 56	4052 52	4201 8	4544 . 51	5311 . 28	5623	5732 45 5734 45	5811
63 22	3940	4083 51	4208	4546 51	5312 28	5625 30	5735 45	5812
164 12	3942 56	4084	4432 14 4438 14	4548 51 4550 51	5513 30	5626 28	5736 45	5814
65	3942 56	4086 51	2.4	4550 . 51 4552 . 51	5314	5627 28 5636 30	5757 45 5758 45	
67 12	3945 6	4087 51	4439	4554	5319	5657	5739 . 45	5816
68		4038 51	4441 36 4442 48	4556	5525 16 5327 14	5638	5740 45 5741 45	
70 22	3947	4089 51 4090 88	4443	4908 51	5459	5640 30	5742 45	5819
71 22	3950	4091 40	4146 4	4962 51	5460 58	5641 30	5743 45	5826
72 22	(0)	4092	4450 52	4564 51 4566 51	5461 58 5462 58		5744 45 5745 45	5822
73 22	5951 56	4106 183	4453 52 4451 52	4568 51	5462 58 5463 58	5647 58 5648 58	5746 45	5825
75 22	5952	4113 48	4452	4570	5469 28	5649 58	5747 45	5824
76 22	3953 56	4114	4453	4580 51	5475 58	5630 28	5748 45	
77 19 78 22	3954 56	4116 16	4454	4581 51 4582 51	5491 . 18 5495 . 18	5633 16 5634 16	5749 45 5750 45	
79 22	60	4117 12	4456 52	4583 51	5498 18	2655	5751 45	5828 5829
80 22	3955 56	4121 52	4459 46	4584 51 51	5502 54	5656 16	5752 45	
81 22 82 22	3956 56	4122 52	4460 54	4585 51 4586 51	5503 54	5676 28 5678 28	5753 45 5754 45	1851
83 22	3958 47	4124 51 4126 51	4465 54	4290 51	5905	5679 28	5759 45	1832
84 22	3959 250	4128 51	4466 54	4591 51 4592 51	5506 55 5507 18	5686	5756 45 5757 45	5834
35	3960 14	4130 51	4475 51	4592 51 4593 51	5507	5687 25 5689 226	5757 45 5759 36	5835
87 22	3964 14	41.52	4477 51	4594 51	5509 12	5692 54	5760	5836
85		4134 51 4136 51	4478 51	4595	5510	5693 12	5761 40	5838
98 22	3967 45 3968 45	4138 51	4479	4296	5512 14	5694	5763	5839
91 23	3969 45	4146	4481 51	4598 51	5515 14	5696 60	5765 48	5840
92 22	3970 45	4142	4482 51	4599 51 4770 4	5516 16	5697 18	5766	5842
94 22	3971 45 4035 52	4144 51	4483 51 4484 51	12 4	5517 . 16 5518 16	5697 18 5698 18	5768 38	5845
95 28	4036	4145 51	4485 51	4776 28	5519 16	5699 46	5769 38	5844
96 22	52	4147 51	4486 51	4780 12	5523 16	5700 46	5770 36 5771 36	5845
97 22	4837 36	4148	4488 51	4781	5524 16 5525 14	5701 36	5771 36 5772 36	5847

	1.4821

			1146	JEK TO TA	KIJ		11-3010101-1021		
н	н	н	1	1	1	1	1	1	
Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	
45	5925 35	6437	447 92	1173 388	2515 128	3134 348	3511 133	3751 340	
45	5916 35	6438 392	467	1276 182	2522 . 112	354 96	3512	3752 840	
65	5917 35	6439 392 6440 392	477 312 324	1322 334 1453 88	2525 98	3309 00	3515	3753	
- 45	5918 35 5919 35	6473 399	498 88	1471 358	2527	3202 96	3517 . 354	3735 340	
45	5919 35 5920 35	6476 390	567 106		2527 . 98 2535 . 118	3207 36		3736	
45	5921 35	6477 390	328, 340		2536 . 116 154	46, 52, 56, 130, 134, 136	3523 354 3526 356	3757 340 3758	
45	5922 . 35	6478 390 6479 390	568 108 152	1531 138 1636 334	2539 112	152, 153, 164	3527 356	3759 340	
45	5923 35 5924 35	6480 390	570 818	1645 338	114, 158			3760	
. 45	3924 35 5925 35	6502 300	376	1682 136		3214 100	3531 354	3761 340	
- 45	5926 35	6503 390	382 28 390 258	1697 154 1701 96	112, 114, 158 284	3218 . 96 3220 . 138	3532 356 3533 356	3763	
35	5927		627 8	1721 8	2545 112	140	3536 354	352	
35	5928 85 5929 25	1	628 334	1807 158	2546 112	3223 96		3765	
35	5930 35		653 82	1821 122 1873 116	2547 113 2550 110	3231 96 3236 96	3538 , 356 3539	3766	
35	5931 10	5 310	654 30	138, 154, 158	2551 . 110	3254 82	3540		
35	5932 10 3933 10	109 88	636	1930 . 138	2576	3270 . 334	3341 356	153	
35	6101 310		665 316	1981 8	2673	3271 338 3272 338	3542 854 3343 354		
35	6106 300	111	212, 310, 350	1090 50	2674 358 2675 358	3272 338 3273 334	3544 354	3873	
35	63.43 24	82, 84, 312	856	1989 82	2676 353	3274 334	3543 354	3874	
35	6144 24	144 28 186	680 381	1991 82	2677 313	3275 334	3546 356	353	
35	6146 25	186	681 342, 348	2031 112 114, 134, 136	2679 318 2682 204	3277 534 3278 334	3347 856 3548 354	3675 340	
35	6147 25	140, 172, 176	230, 236, 316	166, 198, 208	208, 348, 354	3291 16	3549 354	3876 340	
35	6148 95 6149 95	200, 308, 316	340, 342, 348		2684 94	3292 16	3351	352	
35	6150 25	204	352, 354	2066 838 2079 106	2685 104	3294 14	3552 6	3878 94 3879 358	
35	6151 25	236 82	704 63	2008 82	2686	3296 10	3553	3892	
35	6152 25 6153 25	86	698	2088 82 2089 82	2689 313	3299 90	350, 310, 368	3912 86	
35	6154 95	237 82			2693 104	3303 98 3306 98	3554 6	3913 88 3921	
35	6155 25	239 82	788 89	2091 82 2101 86	2693 . 82	3307 98	3582 00	3926 88	
	6156 25 6157 25		340, 312	2102 86	100, 102	102	3583 00		
	6158 25		807 112	2105 86 2106 86	2763 83	3314 100 3317 82	3384 90 3383 90 3398 90	4031 88 4037 82	
35	6159 25	256 88	808 163	2107 . 80	2764 88 2765 88	3318 82	3288 00		
. 35	6160 25 6161 25	261	831 98	210E	2766 88	3322 86		4217 346	
	6161 25	275	140, 354		2767 88	3335 334 3344 88	3399 124	4400 . 146 4405 . 90	
35	6163 25	286	845 202	2127	2768 88 2795 138	3345 88	3614 354 3615 354	4437 . 120	
	6164 25 6165 25	299 84	874 02 04, 88 883 28		2795 138 2800 49	3353 88	3617 354	4482 148	
. 35	6165 25 6166 25		883	2152 86	112, 114, 202	3354 88 3371 140	3618	4486 148	
35	6167 25	336 84	82, 86, 88	2156	316		3619 96	4488 146	
35	6168 25	353	905 . 104	2176 34	2838	152	3621 92 3622 92	4495 116	
35	6169 25	357 82	368		2839 358 2840 358	3404 . 135 3405 . 135	3624 92	4506 90	
	6170 25	374 52	961 104	2192 82 2233 126	2931	3405 135 3409 136	3628	4522 120 122, 150	
35	6172 25	374 82 375 82	986	2258 32	3013 340	3416	3665 184	4325 150	
35	6173 25	377 . 82	994 82 1013 238	2291	3062 346	3416 136 3417 136	3667 100 3669 100	174, 182, 184	
	6174 25 6175 25	399 82	2014 220	2292 . 84 2293 . 84	356	3419 340 3420 340	3671 . 100	4527	
35	6176 25	401	1015 338	2338 264	3087 108	3422	3694 138	4718 150	
35	6177 . 28	402 . 82 403 . 82		2422 8	3088 140	352, 354	3724 . 346 3725 . 354		
35	6182 . 25 6183 . 25	349, 854	1028 . 96	2430	3089 134	3423 . 340 352, 354	3725	4722 150 4723 150	
35	6184 24	86 82	1072 . 28	52, 70, 136	3127 348	3424 340	3743 310		
	6185	416	116, 132, 154		354	352	3744 . 340 3745 340	4782 - 138 4783 - 138	
35	6186 590 6432 590	440 16	310, 288, 368 1079 96	2491 84 2492 84	3128	3425	3745	4783 138 4784	
35	6433 230	444 82	134	2493 84	3131 348		3747 349	4813 104	
	6434 388	84	1 1120 116	2494	3132	3504 134	3748 310	120, 378, 392	
35	6433 390 -6436 388	445 82	154, 163, 200 340	2495	3133 348	3507 138 3508 138	3749 340 3750 340	4821 . 166	
35	1 0430 . 338	1 00	1 010	1 2024		1 2010 1 100	3134		

I-4850 to I-	5878		INDEX TO PARTS					42
1-4850 to   1-48	5878   Page   Pa	Port   Page   Pa	Part   Program   Program	PART   Page   Pa	Part   Property   Pr	Person I Program	Part   Page   Pa	42    Post   Pos

422			INI	1-58	79 to 1-7828			
		ı	1	1	1	1	1	1
Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page
5879 98	3938 . 102 5939 96	6073	6241 346 6242 346	6322 . 116 6323 136	6390 142 6391 142	6661	7350 112	7634 148 7635 146
5882 106	5939 86 5940 . 110	6116 114	6243 844	6324 136	6392 143	6667 88	7399 142	7636 120
5886 144			6244 344 6246 344	6325 136 6326 136	6395 142	6668	7400 82 7402 344	7642
5887 128 5890 131	5942 116 3943 . 110	6148 144 6149 . 334	6247 356		6397 142	6673 168	7403 346	189
	5944		6248 354 6249 354	6328 116 6329 351	6398 142 6399 142	6693 . 134 6694 . 134	7414 346 7416 346	7644 359 7645 854
5893	3946 168	6153 128	6250 354	6330 185	6400 148	6695 , 134		7682 123 7684 124
		6154 188 6155 188	6251 352 6252 840	6331	6401 142 6402 148	6705 142 6706 142	7424 836 7425 836	7686 101
5897 334	T2. 148	6157 140	352	6333 116	6403 142	6707 136	7436 . 106	7687 125 7688 148
	5949 148	6138 104	6253 . 352 6254 . 199	6334	6405 152 6406 152	6708 136 6709 136	7457 846 7439 , 112	7689 148
5901 102 5902 102	5952 125	6159 104 6160 104	6235 138	140	6407 158	6710 186	7460 100	7690 122 7691 148
5903 100	5953 138 5954 138	6161 384	6256 188 6257 188	6335 356 6336 356	6408	6711 184 6712	7461 316 7471 346	7695 142
5904 100	5955 164	6362 \$34	6258 150	6337 256	6410 358	6714 180		7696 142 7702 148
5905 100	5936 104 3957 104	6163 338	6239 . 150 6260 . 188	6338 104 6339 351	6411 858 6412 858	6715 189 6716 130	7473 344	7703 148
103	5958 104	6164 338	6261 150		6413 318	6717 130	7488 344	7738 346
5906 100	324	6165 338	6262 188	6341 . 856 6342 . 141	6414 127 6415 184	6718 186	7349 100 7567 100	7739 346
5907 118	5959 104 5960 104	6167	6263 150	6343 144	6416 112	6719 126	7573 124	7741 346
5908 114, 154 112	5961 112	6168 . 334 6176 338	6264	6344 144	6417 86 6418	6720 137	7574 129 7575 123	7778 234
114, 154	3963 104	6186 128	6274 192	6346 144	6506	6721 126	7576 105	7786 344
5909 116	106	6189	6275 158 6276 158	6347 144	6307 358 6308 164	6728 96	7577	7787 112 7788 946
5910 100	5964 148 5965 140	6192		6349 140	6517		122	
5911 100	3967 148	6193 . 346 6194	6279 150 6280 153	6350 160 6351 162	6541 145	6730 834	7579 100	7791 844
102	5969	6310 145	6281 138	6352	6543 144	6732	7580	7792
5913 160	5971 104	6212 112 6215 100	6283 - 158 6284 - 185	6353	6344	6734 818 6735 884	7581 236 7582	7794 354
5914 100	5972 104	102	6285 134	6335 148	6567 135	6736 384	7583 836	7795
102	5974 104	6216 100	6286 134 6287 135	6356	6568 136 6569 136	6739 126	7584	7798 110
102	5975 104	6217 113	6288 158	6358 142	6570 185	6740 197	7587 104	7799 112
5917 102	5977 . 68	6218	6289 184	6359 152 6363 140	6571 144 6572	6824 144	7588 104 7589 123	7801 . 113
5918 100		6219	6292 358	6364 152		6826	843	7802
5919 PS	5978 93	6221	6294 13#	6365 141 6366 140	6589 189 6394 34¢	6827 164 6828 164	7590 122	7804
5920 138	5986 388	6223	6296 136	6367 140			7591 104	7805 120 7806 121
5921 98	6010 100	6224 98 6225 98	6397 . 186 6298	6368 144 6369 148	6396 . 340 6397 140	6830 . 144 6941 . 128	7594	7808 124
5922 18	6011 100	6226 48	136	6370 142	(398 142		7599 124	7809
5923 160	6012 100	6227 351 6228 116	6299 134 6300 136	6372 141 6373 142	6399	7122 348 7123 348	7600 . 394 7607 . 142	7811 120
1/9	102	6229		6374 142	6603 148	7135 318	7608 142	7812
5924 116 5925 116	6013 100	6230 116	6302 134 6303 136	6375 . 142 6376 142	6404 341	7137 344 7139 310	7610 344	7814 100
334	6014 100	140		6377 142	6606 148	7141 350	7612 346	7815 . 106 7816 106
5926 116	6038 854	6232 116 6233 116	6303 136 6306	6378 142 6379 142	6607 148 6608 146	7174	7614 128 7615 128	7817 100
5927 116	6062 92	6234 344	6307 144	6380 142	6609 840	7236 . 314	7616 100	7818
3928 116 3930 116	6063 92	6235 344	6308 136 6309 136	6381 146 6382 140	6610 340	7280 190 7336 186	7617 192 7618 106	7820 346
	6065 144	6236 344	6310 134	6383	6614 . 142	7337	7619 106	7821 846
5932 384 5933 116	6066	6237	6311 . 352 6313 . 348	6384	6615 142	7338 188 7339 334	7620 106	7823 344
5934 116	6068 . 123	354	351	6386 146	6617 . 142	7340 334	7622 148	7824 344 7825 344
5935	6069 93	6238 344	6314 134 6319 135	6387 . 148 6388 . 124	6618 142 6619 145	7343 116 7344 116	7624 100	7826
5936 96 5937 98	6071 188	6239 356		304	6620 142	7345 116	7630 346	7827
102	6072 193	6240 350	6321 186	6389 356	6649 148	7346	7633 148	1 /040 351

I-7829 to J	-5225		INDEX TO PARTS				423		
-	I	ı	J	J	j	J	J.	J	
Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	Part Page	
7829 354	8021	8664 318 8693 392	765 . T6 794 . 184	2462 16 2477 152	3238 62 3240 62	3331 . 207 3352 207	4787 . 7 4788 . 6	5145 184 5146 164	
7830	8023	8694 315	214, 246, 333	188, 162	3242 62	3333 207	4789 7	5147	
7832 106	8026 127	8696 363	878	2506 207	3244 62	3354 207	4790	5148 164	
7833 106 7834	8027 125 8030 108	8709 392 8721 392	800 294 804 10	2511 207 2512 207	3246 . 62 3248 . 62	5335 207 3536 210	46, 120, 168	5149	
7836 336	8031 166	U742 1002		2513 207	3250 62	3357 210	4806	5150 160	
7837	8032 128		982 . 160	2514 207 2515 207	3252 62 3234 62	3339 210 3361 210	4807	5131 160	
7839	8033 351	,	563 840			3362 210	4809 . 72	5152 160	
7840 356	8035 116	115	870		3258 62 3260 62		4810 72 4811 72	5154 160 5155 212	
7841	8036 166 8037 116	210, 218 136 16	995 . 310	2519	3262	3371	4812	5156	
7843	8035 130	26, 172, 234	997		3264 62	3375	4813	5157 160	
7844	8039	254, 322	1045 10	2522 201 2525 201	3266 . 62 3268 . 62	3377 . 120 3381 . 02	4814 . 72 4816 . 72	5158 160 5159 202	
7846 112	8041 106	30	26		3270 62	3383 . 62	4817 72	3160 160	
7847	8042 150	142 6 145 6	1030 86	2525 20T 2526 20T	3272 62 3274 62	3385 62 3387 62	4818	5162 212	
7848	8043 106 8044 120	145 6	1096 274	2527 201	3276	3389 62	4821 902	5163 212	
7850	8045 336		1182 159		3278 62	3391 62	4822 63	5164 212 5165 212	
7851 336 7854 358	8046 326 8047 326	24, 28, 68 158	1183 . 16 1218 . 278	2529 . 201 2530 . 207	3280	3393 42 3350 348	4823	5166 212	
7855 358	8048 106	176 52	386	2531 207	3282 62	3551 348	4828 68	5167 212	
7856 358	8050	T2, 174	1228 48 48 142, 146, 148	2532 207 2533 207	3283 65	3589	4531 68 4832 63	5169	
7860 94 7903 338	8031 124 8032 125	379 210	184, 168, 182	2560	3285 63	3625 154	4854 310	5173 160	
7910 106	8953 326	182 244	186, 190, 214		3298 03 3299 03	3669	4890 363 4891 363	5174 72	
7911 106 7959	8055	225 54 164, 168, 314	236, 274, 286 300, 312, 324	2753 64	3299 63 3300 63	3672	4892	5175 160	
7960	8056	324, 328, 312	328, 380	2755 64	3301 68	3685 64	4893 70		
7977 82 7978 82	8037 107	247 300	1235 166 214, 264	2756 64 2757 64	3303 368 3306 368	3721 64 3732 90	5102	5176 164 5177 164	
96	8038 107	322	1241 6	2758 61	3303 00	3756 76	3103 165		
7979 82	8060 125	254	1273 76	2759 64	3314 90	3809 18	5104 . 185 5103 . 165	5179 161 5180 160	
7982	8061 126 8062 131	327	1314 16	2760 64 2762 64	3316 90	4532 368 4682 74	5106 165	212	
7983 132	8067 128	362 16	78, 79, 90	2765 64	3317	4684	5107 165 5108 165	5181 100	
7984	8068 126	375	1317	2766 . 64 2769 64	3318	4685 14	5108 . 165 5109 164	5182	
7967 100	8069 126 8070 126	415 22	1318 . 76	2883 202	3321 72	4687	214, 216	142, 154, 160	
7988 126	9072 126		1519 . 76	226	3322 . 72	4709 16	5110 164 5111 214	5197 207	
7989 110 7990 130	8073 126 8074 120	453 172 178, 284	1404	3034 201 3035 207	74	4712 14	5112 214	5199 207	
	8077 126	465 6	1435 268	3078 154	3323 14	4713 14	5113 214 5114 214	5200 207 5201 207	
7992 110 7993 130	8078 126	54, 56, 94, 100 102, 104, 110	1451 28 1535 344	3145 T6 3146 T6	3325	4714	5115 148	3202 207	
7994 130	8239 378	120, 128, 142	1536 8	3147 76	3331 207	72, 74	5117 163	5203 201 5204 201	
7995 130 7996 128	8261	163, 198, 200 258, 280, 288	1554 10 1747 76	3148 T6 3149 T6	3332 207 3333 207	4716 72	5118 163 5119 160	5205 201	
7997 128	3267 379	312, 334, 336	1778 16	3160 76	3334 207	4717	164	5205 207	
7998 128 7999 104	8268 304	340, 344, 346	1784 8 84, 176, 182	3182 84	3335 207	4718 . 68 4720 . 68	5120 212	5207 201 5208 201	
7999	8270 378 8271 878	352, 354, 356 465	332	3183 84 3198	3336	4773 6	5121 212	5209 207	
8001	\$272 378	182	1869 310	3212 62	3538 207	4774 6	3124 165 5126 165	5210	
8002 124 8003 104	8278 318 8384 392	479 12 18, 48	1910 18 2018 86	3214 62 3216 62	3339 207	4775 6	5128 165	5212 . 207	
8004 104	8395 378	505 . 202	2168 6	3215 69	3541 207	4777	5130 165	5213 207	
154, 158	8392 8396 278	511 6 8, 104, 112	2170 6 2363 84	3220 62 3222 . 62	3342	4778 6 4779 6	5132 165	5214	
8006 139	8396 378 8563 378	114, 123, 136	2364	3224 62	3344	4780	5136 165	5216 207	
8006 344	£564 338	154, 252	2428 84	3226 62	3343 207 3346 207	4781 6 4782 6	5138	5217 207	
8009	8379 388 8580 388	616 6	2429 84 2430 76	3228 62 3230 63	3347 201	4782 6	5141 160	5219 267	
8011 342	8383 358	618 6	20	3232 62	3348 207	4784 6	5142 160	5224 74	
8019 111 8020 334	8654 378 8655 378	640 38	2460	3234 62 3236 62	3349 207 3350 207	4785 6	5143 164 5144 164	5225 14	
euzv 331	. 6000			- Jan 1	2004				

5429

207 218 218  . 164

174, 180, 214 252, 274, 336 5574 5575 

5589

6242 6246 6247

5678

